## CHANGES IN LUBRICATION SPECIFICATIONS WHICH APPLY TO ALL TELETYPE APPARATUS

The following lubricants have been standardized for use on all types of Teletype apparatus. These lubricants supersede those referred to in preceding Teletype specifications. The lubricants can be ordered from Teletype as follows:

88970	1 Qt. of KS-7470 011
88971	1 Gal. of KS-7470 011
88973	1 Lb. of KS-7471 Grease
*88975	KS-8319 Grease Gun
97116	4-oz. Tube of KS-7471 Grease

The above grease is recommended instead of oil for lubricating motors equipped with ball bearing. The 88975 grease gun should be used for injecting grease into the bearings of Teletype ball bearing motors. The gun may be used also for applying grease to other parts of the apparatus and no other grease container need be carried. If this grease gun is not available, the oil listed in the foregoing should be substituted for lubricating ball bearing motors.

\* Instructions for Filling the Grease Gun

- 1. Unscrew the lubricant tube from the cap casting of the grease gun.
- Insert fresh lubricant through the open end of the tube with the fingers. Apply gradually to eliminate air pockets.
- 3. Tamp the lubricant down solidly in the tube by pounding the closed end solidly against the palm of the hand. Continue to add lubricant until the tube is completely filled and the metal follower rests against the perforated tube cover.
- Fill the cap casting with lubricant flush to the bottom side of the tube threads.
- 5. Screw the lubricant tube into the cap casting part way only. Then insert a pencil or rod through the perforated tube cover and exert pressure against the metal follower so as to expel any entrapped air past the tube threads. When lubricant begins to cose through the threads, tighten the lubricant tube securely in the cap casting.
- 6. Operate the handle back and forth for several strokes or until lubricant is pumped from the nozzle. The gun is then ready for use. If the lubricant does not flow from the nozzle in a solid stream, it is an indication that all air has not been expelled from the lubricant tube. Invert the gun and pound the cap casting end against the palm of the hand to jar the lubricant into the pump cylinder.
- \* Instructions for Lubricating Motor Ball Bearings

The motor bearings are packed with grease before the motor leaves the factory and under ordinary operating conditions need no additional lubrication for

# Indicates change

31

EE-358 Issue 4, Page 2 November, 1940

approximately two months. At the regular lubricating intervals one or two strokes of the plunger of the gun should apply sufficient grease to each bearing. To lubricate, press the nozzle of the gun against the ball oiler and force the grease into the hole by pushing on the plunger of the gun. Care should be taken that the bearings are not overloaded. Overloading will result in the grease oozing out of the end castings and being forced into the motor or being thrown on other parts of the mechanism. After lubricating, the motor should be run for a few minutes and then any excess grease that has been forced out of the ends of the castings should be wiped off. Each time that the gun is used for lubricating a motor bearing, the plunger should first be depressed slightly to make sure that grease will be delivered.

562135 Issue 2, Page 1 August, 1957

## CHANGES AND ADDITIONS TO BULLETINS

127B,	Issue 3,	Model 14 Type Bar Tape Printer
138B,	Issue 5,	Model 15 Type Bar Page Frinter
159B,	Issue 2,	Model 26 Type Wheel Page Printer
178B,	Issue 1,	Reperforator Transmitter
182B,	Issue 1,	Multiplex Start-Stop Extensor Set
197B,	Issue 1,	Multiple Reperforator Set
1988,	Issue 1,	Model 27 Type Wheel Page Printer
*1.99B,	Issue 1,	Simplex-Diplex Converter
*201B,	Issue 1,	Sequential Control (SECO) System
*203B,		Reperforator Transmitter
*2103,	Issue 1,	Sequential Selector
#211B,	Issue 2,	Multiple Reperforator Transmitter
*220B,	Issue 1,	Model 14 Typing Reperforator
#1 2712	Page 0	*1000 D- 0.1

"12/B,	rage	9	*199B,	Page	2-1	
*138B,	Page	22	*201B,	Page		
#159B,	Page	1	*203B	Page		
*1783,	Page		*21.0B,	Page		
*182B,	Page		#211B,	Page		
*197B,	Page		*220B,	Page	1	
*193B,	Page	1 million 1			000	

\*SELECTOR MAGNET - Change the title and text of this adjustment to read as follows:

\*(a) SELECTOR CORE AND ARMATURE ALIGNMENT - Preliminary

When the armature is in its operated position, it should touch both magnet pole faces approximately at their centers, and the cores should be located equi-distant, with respect to the outer edge of the armature as gauged by eye when a light reflector such as a piece of white paper is held behind the magnet. To adjust, remove the selector magnet bracket from the typing unit and reposition the magnet core assembly with its mounting screws loosened while holding the assembly so that the cores are vertical and the armature, by its own weight, rests against the pole faces. Tighten the magnet core assembly mounting screws and replace the selector magnet bracket.

\*(b) SELECTOR CORE AND ARMATURE ALIGNMENT - Final

With the armature lever spring and the selector arm spring in position (hooked), manually rotate the shaft and selector cam sleeve so that the armature lever slowly moves the armature toward the magnet core. Observe that the armature ture touches both core ends simultaneously and approximately in the center of curvature; gauge by eye, holding a light reflector such as a piece of white paper behind the magnet and armature assembly. Adjust by repositioning the magnet core by means of its elongated mounting holes and mounting screws. Tighten the screws.

\* Indicates Change

\*NOTE 1: When the cores are in proper adjustment, it should require at least 3-1/2 pounds pull, with a 64 ounch scale applied at right angle to the armature edge in line with the armature lever, to separate the armature from the cores when a current of .020 amperes is flowing through the magnet coils (coils in series shunted by a 5000 ohm resistor).

"NOTE 2: The adjustment may have to be modified in order to obtain the required receiving margins and to prevent slow release of the armature due to oil-seal. The margin requirement and the minimum magnetic pull requirement of 3-1/2 pounds should be considered as "Final Check" for the armature and core alignment.

i

127B,	Page 13	197B,	Page 15
138B,	Page 26	198B,	Page 18
159B,	Page 5	*201B.	Page 5-4
178B,	Page 9	#210B,	Page 2-6
182B,	Page 16	*211B,	Page 2-5

SELECTOR ARM SPRING TENSION

Change this adjustment to read as follows:

Unhook the selector arm stop detent spring. With the armature extension on a high part of its cam, and the locking lever held away from the locking wedge, hook an 8 oz. scale over the end of the locking wedge and pull parallel to the selector arm spring. It should require 1-1/4 to 1-3/4 ozs. to start the selector arm moving. Reform the outer loop of the selector arm spring, if necessary, to meet this requirement. Replace the detent spring.

CAUTION: Care should be taken not to nick, crimp, or otherwise deform the spring or spring wire when reforming the loops.

\*210B, Page 2-19

\*SENSING BAIL - Add the following as a second paragraph to this adjustment:

\*Release the timer blocking bail and rotate the main shaft until the No. 4 selector cam does not interfere with the movement of the timer sensing bail. Continue to rotate the timer cam sleeve until the blocking lever just drops off the high part of No. 4 timer cam. The tip of the latch bail pawl should rest on the low part of the No. 5 cam, there should be some clearance between the latch bail extension and the upper edge of the cut-out in the side plate of the unit and the upper edge of the blocking lever latching extension, when brought in alignment with the latching surface of the blocking lever latch should clear it by at least .010". If necessary, remove material from the upper edge of the cut-out in the side plate, covering the timer and selector mechanisms to keep out filing chips.

NOTE: Future Sequential Selector Units will have a larger cut-out in the side plate.



\*210B, Page 2-20

Į

\*SENSING BAIL SPRING TENSION

\*

\*Change the sensing bail spring tension requirement to read 3 to 5-1/2 ozs. instead of 2 to 3 ozs.

\*

\*

EE-576 Issue 1 January, 1947

CHANGES IN BULLETINS 127 (ISSUE3) ADJUSTLENTS TYPE BAR TAPE PRINTER (MODEL 14); 165 (ISSUE 2) ADJUSTLENTS TYPING REPERFORATOR (MODEL 14); 171 (ISSUE 2) ADJUSTLENTS TYPING REPERFORATOR (FPR5H AND FPH26GS)

PAGE 19 OF BULLETIN 127 PAGE 34 OF BULLETIN 165 PAGE 18 OF BULLETIN 171

ţ

#### PULL BAR LOCKOUT LEVER ADJUSTLENT

Change this adjustment to read as follows:

- (a) With the platen in the FIGURES position, the BLANK combination selected, and the main shaft rotated until the main bail is in its uppermost position, there should be .004" to .020" clearance between the S or J rall bar (according to type) and the code bars.
- (b) There should be .004" to .020" clearance between the BELL pull bar and the code bars when the foregoing selection is applied with the platen in the LETTERS position.
- (c) With the platen in the FIGURES position, the BELL combination selected, and the main shaft rotated until the main bail has moved to approximately .010" below the bell pull bar notch, there should be at least .010" clearance between the BELL pull bar and the lockout lever roller that is in contact with the S or J pull bar. When measuring this clearance the play of the platen shaft, the shift rocker and the lockout lever should be taken up in the firection that minimizes the clearance.

To meet the foregoing requirements, position the adjusting lever by utilizing the play in its mounting holes.

\*

\*\*

\*

### ADDITION TO BULLETINS

Bulletin	127,	Issue	3,	Type Bar Tape Printer (Model 14), Page 36
				Typewheel Tape Printer (Ticker), Page 29
				Type Bar Page Printer (Model 15), Page 50
				Transmitter, Page 18
Bulletin	147,	Issue	2,	Single Magnet Reperforator, Page 14
				Typewheel Page Printer (Model 26), Page 36
				Type Bar Printer (Model 20), Page 38
				Multiple Transmitter Distributor and Base, Page 9
				Typing Reperforator, Page 22
				Single Unit Transmitter and Base, Page 8
				Translator Unit, Receiving Distributor and Panel, Page 8.
				Reperforator Transmitter Distributor, Page 46
Bulletin	182,	Issue	1,	Multiplex, Start-Stop Extensor Set, Page 22
Bulletin	183,	Issue	1,	Portable Signal Distortion Test Set, Page 5
				Multiple Transmitter Distributors and Base, Page 12
Bulletin	186,	Issue	1,	Two Channel Start-Stop Transmitter Distributor, Page 20
Bulletin	189,	Issue	1 3	KD79 and XD95 Distributors, Page 15
Bulletin	192,	Issue	1,	Teletype Automatic Wheatstone Perforator Set, Page 19
Bulletin	193,	Issue	1,	Reperforator Transmitter Distributor (Model 14), Page 39
Bulletin	197,	Issue	1,	Multiple Reperforator Set, Page 25
	Add	the fo	110	wing adjustment immediately preceding the "SDEED AD HIGTING

Add the following adjustment immediately preceding the "SPEED ADJUSTING WHEEL FRICTION WASHER SPRING TENSION ADJUSTMENT":

ADJUSTMENTS FOR ALIGNMENT AND SQUARENESS OF GOVERNOR CONTACTS

All governor contacts can be adjusted for alignment of edges; only those governor shells which provide alongated mounting holes for the fixed contact bracket permit adjustment of the contact for height by positioning the contact bracket.

The governor contacts should be in line and meet squarely so that maximum contact surface is provided. (Check with the retractile spring tension Adjusted so that the contacts just make, or the limit of the adjusting screw).

- (a) Line up edges of contacts by means of the floating contact hinge mounting screw.
- (b) Adjust contacts for squareness from right to left by positioning the height of the fixed contact bracked using the elongated mounting holes in the governor shell.
- (c) To adjust from front the cack, twist the floating contact hinge, applying pressure to the arm near the contact.
- NOTE: Check by use of a .002" gauge (smaller if available). Check with gauge between edges of contacts to see that the gauge enters (or does not enter equally on all sides.

\* \* \* \* \*

EE-611 Issue 1 January, 1948

## CHANGE IN BULLETINS

127, Issue 3, Model 14 Type Bar Tape Printer, Page 22 171, Issue 2, Model 14 Typing Reperforator, Page 13 178, Issue 1, Reperforator Transmitter Distributor, Page 17 193, Issue 1, Model 14 Reperforator Transmitter Distributor, Page 14

RIGHT AND LEFT RIBBON REVERSE PAWLS SFRING TENSION

Change the tension requirement to read "1-3/4 to 3-3/4 ozs." instead of "2-1/2 to 3-1/2 ozs."

EE-630 Issue 1 April, 1948

## CHANGE AND ADDITION TO BULLETIN 127, ISSUE 3 ADJUSTMENTS - TYPE BAR TAPE PRINTER MODEL 14

PAGE 19

FULL BAR LOCK-OUT LEVER ADJUSTMENT (Figures 35 and 36)

Change the last requirement in both paragraphs of this adjustment to read ".004" to .040" instead of ".004" to .020" and add the following note:

NOTE: As an increase in pull bar clearance also increases the load on the platen shift return spring, the platen shift mechanism should be checked (manually) for correct operation.

EE-667 Issue 1 April, 1949

#### CHANGES IN BULLETINS

127, Issue 3, Model 14 Type Bar Tape Printer, Page 29 165, Issue 3, Model 14 Typing Reperforator, Section II, Paragraph 2a(7)

BELL HAMMER SPRING TENSION

Change the tension requirement to read as follows:

It should require 3 to 5 ozs. for the one-piece design which measures approximately 2 inches in length between the pivot points, or 2 to 4 ozs. for the two-piece design which measures approximately 1 inch between the pivot points, to start the hammer moving.

\* \* \*

1.00.1

EE-676 Issue 1 May, 1949

## CORRECTION TO BULLETIN 127, ISSUE 3 ADJUSTMENTS - TYPE BAR TAPE PRINTER (MODEL 14)

## PAGE 22. RIGHT FUNCTION PULL BAR SPRING BRACKET ADJUSTMENT

Change the spring tension requirement to read: 3-1/2 to 5 ozs. Change Figure 45 accordingly.

\* \* \*

EE-695 Issue 1 February, 1950

ADDITION TO ADJUSTMENT BULLETINS

Bulletin 127.	Issue 3 - Type Bar Tape Printer (Model 14), Pages 7, 13
	Issue 5 - Type Bar Page Printer (Model 15), Pages 21, 26
	Issue 2 - Single Magnet Reperforator, Page 6
	Issue 1 - Start-Stop Regenerative Repeater, Page 8
Bulletin 159.	Issue 2 - Type Wheel Page Printer (Model 26), Page 6
Bulletin 160.	Issue 1 - Type Bar Page Printer (Model 20), Page 16
Bulletin 165.	Issue 3 - Typing Reperforator (Model 14), Pages 2-5, 2-8
Bulletin 171.	Issue 2 - Typing Reperforator, Page 7
Transfer T. S. C. M. WEINER, M. M. MARKER, M. M. M. M. M. M. M. M.	Issue 1 - Reperforator Transmitter Distributor, Page 9
	Issue 1 - Multiplex Start-Stop Extensor Set, Page 17
	Issue 1 - Reperforator Transmitter Distributor (Model 14), Page 8
	Issue 1 - Multiple Reperforator Set. Page 16
	Issue 1 - Type-Wheel Page Printer (Model 27), Page 18
	Issue 1 - Simplex-Diplex Converter, Page 2-4
	Issue 1 - Sequential Control (SECO) System, Page 5-5
	Issue 1 - Reperforator Transmitter (Model 14), Page 2-5
	Issue 1 - Sequential Selector (SOTUS), Page 3-6

The following adjustment applies to units equipped with the Adjustable Range Scale Assembly which permit regulation of the engagement between the stop arm on the selector cam sleeve and the stop lever on the range finder. The adjustment should be made immediately after the STOP LEVER SPRING TENSION ADJUST-MENT; bulletins and affected pages are listed above.

SELECTOR STOPARM AND STOP LEVER ENGAGEMENT ADJUSTLENT

With the selector magnet armature in the spacing position, rotate the selector cam sleeve until the stop arm moves the stop lever to its maximum travel beyond the step of the trip latch. Loosen the range scale assembly mounting screws and the positioning link mounting screw just enough to make them friction tight. Position the range scale assembly so that the overtravel of the stop lever beyond the trip latch is at least half but not more than the width of the stop lever. This should be checked with the range indicator set at 0, 60, and 120 on the range scale. Tighten the mounting screws and the positioning link screw.

\* \*

697EE Issue 2-January, 1954

CHANGE IN ADJUSTMENT BULLETINS 127B, ISSUE 3 MODEL 14 TYPE BAR TAPE PRINTER 165B, ISSUE 3 MODEL 14 TYPING REPERFORATOR \*171B, ISSUE 2 MODEL 14 TYPING REPERFORATOR

127B, Page 22 165B, Page 2-13 \*171B, Page 13

RIBBON FEED PAWL SPRING PRESSURE

Change this adjustment to read as follows:

With the ribbon feed shaft pushed to the right, the main shaft in its stop position and an 8 oz. scale hooked over the extreme front edge of the ribbon feed pawl and pulled at right angle to the pawl, it should require 6 to 8 ozs. to start the pawl moving away from the ribbon feed ratchet. Make certain that the feeding edge of the pawl does not bind against a tooth on the ratchet when tension is being measured. To adjust, bend the ribbon feed pawl spring.

165B, Page 2-16 \*171B, Page 18

SHIFT ROCKER

Change this adjustment to read as follows:

With the main bail spring set approximately for its operating tension (14 to 15 lbs.), place a spacer between the main bail spring adjusting lever and the spring adjusting screw so that the other end of the lever rests against the selector plate. Move the platen assembly to its forward (FIGURES) position and select the letters pull bar. Rotate the main shaft until the main bail roller is on the low part of its cam. This point is determined by rocking the motor shaft clockwise and counterclockwise and observing when the shift bell crank is in its rearmost position. (Main bail in its extreme upward position.) The vertical end of the shift bell crank should overtravel the rear shoulder of the shift lever by some not more than .015", when the play in the shift lever is taken up, at its left-hand end, toward the rear of the unit. Adjust the shift rocker by means of its adjusting screw to meet this requirement. Remove the spacer.

NOTE: On units equipped with "unshift on space" pull bars select both the LETTERS AND SPACE combination in succession and observe which pull bar gives the shift bell crank the least travel; select this combination to make the shift rocker adjustment.

\* Indicates Change

25

EE- 703 Issue 1 April, 1950

## ADDITION TO BULLETIN 127, ISSUE 3 ADJUSTMENTS - TYPE BAR TAPE PRINTER MODEL 14

On whits equipped with a type bar operated by the bell pull bar, substitute the following adjustment for the BELL HAMLER ECCENTRIC SCREW ADJUSTMENT in Bulletin 127:

PAGE 22

1.00

#### BELL HALMER ECCENTRIC SCREW ADJUSTMENT

With the bell pull bar selected and the main shaft rotated until the main bail is in its uppermost position, there should be a clearance of .020" to .040" between the bell hammer lip and the bell hammer post when the bell type bar with pallet is held against the platen. To adjust, position the bell hammer eccentric screw by means of its lock nut. Keep the high part of the eccentric to the rear.

#### ADDITION TO ADJUSTMENT BULLETINS

127, Issue 3 - Type Bar Tape Printer Model 14, Page 16 165, Issue 3 - Typing Reperforator Model 14, Page 2-10 171, Issue 2 - Typing Reperforator Model 14, Page 9

Insert the following adjustment immediately preceding the PULL BAR GUIDE ADJUSTMENT:

MAIN BAIL GUIDE POST ADJUSTMENT

NOTE

This adjustment applies only to units equipped with the main bail guide post and an adjustable eccentric bushing.

(a) The main bail should be free throughout its travel and the eccentric bushing should be so positioned that the following adjustments can be met:

Pull bar guide adjustment and main bail adjusting screw adjustment (preliminary and final on Model 14 Typing Reperforator units).

(b) To adjust the main bail guide post proceed as follows:

1. Position the pull bar guide so that it is in the middle of the adjustment provided by its elongated mounting holes.

2. With the BLANK combination set up, rotate the main shaft until the main bail is opposite the humps on the unselected pull bars. Position the eccentric bushing so that the guide post is away from the bottom of the bail slot and so that the clearance between the main bail and the LETTERS and FIGURES pull bar humps is approximately equal.

3. With the main bail roller on the high part of its cam see that the clearance between the code bars and the LETTERS and FIGURES pull bars is approximately equal. (It may be necessary to advance the main bail adjusting screw to obtain clearance between the pull bars and the code bars.)

4. Recheck adjustment 2. To obtain both requirements outlined in 2 and 3, it may be necessary to relocate either the eccentric bushing, the type bar basket or the pull bar guide.

5. After positioning the guide post, check adjustment (a).

\* \*

720EE Issue 3, Page 1 February, 1958

## CHANGES AND ADDITIONS TO ADJUSTMENT BULLETINS

127B, Issue 3 - Type Bar Tape Printer (Model 14) 159B, Issue 2 - Type Wheel Page Printer (Model 26) 171B, Issue 2 - Typing Reperforator 178B, Issue 1 - Reperforator Transmitter Distributor 182B, Issue 1 - Multiplex Start-Stop Extensor Set 197B, Issue 1 - Multiple Reperforator Set 198B, Issue 1 - Type-Wheel Page Printer (Model 27) 199B, Issue 1 - Simplex-Diplex Converter 201B, Issue 1 - Sequential Control (SECO) System 203B, Issue 1 - Reperforator Transmitter (Model 14) 210B, Issue 1 - Sequential Selector 211B, Issue 2 - Multiple Reperforator Transmitter 220B, Issue 1 - Typing Reperforator (Model 14)

127B,	Pages	s 8 and 1	4	199B,	Page	2-5	
159B,	Page	6		201B,	Page	5-5	
171B,	Page	8		203B,	Page	2-5	
178B,	Page	9		210B,	Page	2-7	
182B,	Page	17		211B,			
197B,	Page	16		220B,			
198B,	Page	18			1.		

ARMATURE TRIP-OFF ECCENTRIC SCREW ADJUSTMENT (pulling magnet); TRIP-OFF SCREW ADJUSTMENT (holding magnet)

Delete the present adjustment and substitute the following:

There should be some clearance, not more than .004" between the stop lever and the trip latch when the armature is in the unoperated position and the selector cam sleeve is rotated until the stopping edge of the stop lever is directly below the latching surface of the trip latch. While checking the above clearance, take up the play in the stop lever with a screwdriver applied axially adjacent to the spring hole as close to the bearing as possible with thrust in the direction of the trip latch. This clearance should be held to a minimum to favor the "at least .002" end play of the trip plunger.

The trip latch plunger should have at least .002" end play when the armature is held in the attracted position and when the stop lever is resting against its eccentric stop post.

To adjust, loosen the trip-off screw \*\*(trip-off eccentric screw) lock nut and position the screw \*\*(eccentric) to meet the first requirement. The latter requirement serves as a check on the trip-off screw \*\*(trip-off eccentric) adjustment and also on the adjustment of the selector magnet bracket \*\*(armature stops).

NOTE: Designations in parentheses marked with double asterisk (\*\*) pertain to pulling magnet selectors.

\*Indicates Change



\*178B, Page 35 \*203B, Page 2-22 \*211B, Page 2-20

1-1

\*DISTRIBUTOR (OR DISTRIBUTING) CONTACT ADJUSTMENTS

\*

Substitute the following note for the present note just under the title of the adjustment:

NOTE: Contact points must be centrally aligned with each other and square (as gauged by eye) when the distributor contact levers are on the low part of their respective cams and the adjusting screws are set to permit the contacts to remain in closed position. Adjust by bending the long and short contact springs as necessary. The following adjustments are to be made with the distributor contact levers on the high part of their cams:

\*

\*

Correction Sheet 737EE Issue 2 October, 1951

## ADDITIONS TO BULLETINS

127,	Issue	3,	Adjustments - Model 14 Printer, Page 23
			Adjustments - Typebar Page Printer (Model 15), Page 46
			Adjustments - Non-Typing Reperforator, Page 8
			Description and Adjustments - Start-Stop Regenerative Repeater, Page 9
159,	Issue	2,	Adjustments - Type Wheel Page Printer (Model 26), Page 29
Contraction of the second second			Adjustments - Typebar Page Printer (Model 20), Page 34
			Adjustments - Typing Reperforator (Model 14), Page 2-18
			Adjustments - Typing Reperforator (Model 14), Page 21
			Adjustments - Reperforator Transmitter (Model 14), Page 49
			Adjustments - Model 14 Reperforator Transmitter, Page 35
			Teletype Sequential Control (SECO) System, Page 5-8
			Adjustments - Reperforator Transmitter (Model 14), Page 2-25
			Description and Adjustments - Sequential Selector, Page 3-9
*197,	Issue	1,	Adjustments - Multiple Reperforator Set, Page 24

1. This correction sheet supersedes EE-661 dated August, 1949, and applies to all bulletins listed above.

2. Add the information contained in paragraphs 3 and 4 below to the SELECTOR CLUTCH TORQUE requirement.

3. A more convenient method of regulating the selector clutch torque has been devised by the substitution of a 119540 keyed nut, a 122974 capstan nut, and a 122838 spacer for the 72515 nut and 72517 keyed nut on the main shaft. Where these new parts are present, the torque may be regulated by positioning the capstan nut in the proper direction with a screwdriver.

NOTE: The 122974 capstan nut is split and the open ends are offset to insure a tight fit on the 119540 slotted nut. To install the capstan nut the offset ends must be held approximately in line by using a pair of pliers or a clamp. The slotted nut can then be screwed into place. To regulate the selector torque the capstan nut may be positioned with a screwdriver. To prevent the capstan nut from being turned downward against the bearing, the 122838 spacer should be installed between the 119540 slotted nut and the bearing.

4. On units equipped with the 72515 nut and 72517 keyed nut, the selector clutch torque may be adjusted by the use of shims which may be placed between the clutch spring and the 72515 nut. The selector clutch spring must be removed from the shaft in order to apply the shims. Shims are available under the following numbers:

> 96763 Shim (.012" thick) 96764 Shim (.016" thick) 96765 Shim (.020" thick)



119540 NUT, KEYED







122838 SPACER

\* Indicates change

754EE Issue 1 October, 1951

#### CHANGES IN ADJUSTMENT BULLETINS

127, Issue 3 - Model 14 Type Bar Tape Printer, Page 3 138, Issue 5 - Model 15 Type Bar Page Printer, Page 11 147, Issue 2 - Single Magnet Reperforator, Page 7 160, Issue 1 - Model 20 Type Bar Page Printer, Page 9 165, Issue 3 - Model 14 Typing Reperforator, Page 2-2 171, Issue 2 - Model 14 Typing Reperforator, Page 3 178, Issue 1 - Model 14 Reperforator Transmitter, Page 4 193, Issue 1 - Model 14 Reperforator Transmitter, Page 2 197, Issue 1 - Model 14 Reperforator Set, Page 10 203, Issue 1 - Model 14 Reperforator Transmitter, Page 2-1

In the bulletins listed above change the following adjustment to read as follows:

MAIN SHAFT CLUTCH THROWOUT LEVER ADJUSTMENT

With the motor operating, open and close the signal line and then stop the motor. There should be from .010" to .020" clearance between the teeth of the two clutch members. Adjust the clutch throw-out lever by means of its pilot.screws to obtain this clearance. After adjusting, the lever should be free, with not more than .002" end play.

Bulletin 127, Page 25 Bulletin 165, Page 2-22

CONTACT BRACKET ADJUSTMENT

In this adjustment the requirement .010" to .020" should be changed to: some clearance not more than .010".

Change appropriate figure accordingly.

BULLETIN 127, Page 29 BULLETIN 165, Page 2-24

Bulletin 127 Tape Lever Spring Tension Bulletin 165 Tape-Out Lever Spring Tension

Add the following note to these adjustments:

NOTE

The spring tension requirement on units equipped with the tape-out contact assembly should be 6 to 8 ozs.

\*



FIGURE I



FIGURE 2

769EE Issue 1 March, 1952

#### ADDITION TO ADJUSTMENT BULLETINS

BULLETIN 127, ISSUE 3 - TYPE BAR TAPE PRINTER (MODEL 14), PAGE 21 BULLETIN 165, ISSUE 3 - TYPING REPERFORATOR (MODEL 14), PAGES 2-11, 2-12 BULLETIN 171, ISSUE 2 - TYPING REPERFORATOR, PAGE 11 BULLETIN 178, ISSUE 1 - REPERFORATOR TRANSMITTER DISTRIBUTOR, PAGES 15, 16 BULLETIN 193, ISSUE 1 - REPERFORATOR TRANSMITTER DISTRIBUTOR (MODEL 14), PAGES 12, 13 BULLETIN 203, ISSUE 1 - REPERFORATOR TRANSMITTER DISTRIBUTOR (MODEL 14), PAGE 2-8

1. On units equipped with the ribbon reverse arm yield spring the following adjustments replace the standard adjustments appearing in the above bulletins.

a. LEFT RIBBON REVERSE ARM SHAFT ADJUSTMENT (Figure 1)

(1) On typing units and typing reperforators there should be from .005" to .025" clearance between the rear of the left spool cup and the front end of the ribbon reverse shaft when the ribbon reverse shaft is held forward to make this clearance a minimun.

(2) On reperforator transmitters the left ribbon reverse shaft should be set flush with the front of the ribbon spool bracket.

(3) To adjust, loosen the set screw of the spring block, and if necessary, the set screws of the ribbon reverse shaft collar and link. Position the shaft while holding the ribbon reverse arm against the ribbon spool bracket and the spring block against the reverse arm. Tighten the spring block set screw.

b. RIBBON REVERSE ARMS SHAFTS COLLAR ADJUSTMENT (Figure 1)

Both right and left ribbon reverse arm shafts should have some end play, not more than .010". To adjust, position the collar on each shaft by means of its set screw. Locate the set screws so that they are easily accessible when the ribbon reverse arms are held up against the ribbon spool cups.

c. RIBBON REVERSE PAWL LINKS ADJUSTMENT (Figure 2)

The ribbon reverse bail should clear both left and right-hand ribbon reverse pawls by .015" to .040" when the ribbon reverse bail is opposite the reverse pawls and the ribbon reverse arms are against the spool cups. When checking the .015" clearance, the play in the ribbon reverse bail should be taken up in a direction to make the clearance a minimum. When checking the .040" clearance, the play in the ribbon reverse bail should be taken up in a direction to make the clearance a minimum. When checking the .040" clearance, the play in the ribbon reverse bail should be taken up in a direction to make the clearance a maximum. To adjust, position the spring block on the left ribbon reverse shaft and the sleeve on the right ribbon reverse shaft. The following adjustments should follow the Ribbon Reverse Pawl Links Adjustment.

# d. RIBBON REVERSE ARM YIELD SPRING TENSION ADJUSTMENT (Figure 2)

Position the ribbon reverse bail so that it will block the full travel of the ribbon reverse arm, and with the ribbon reverse pawl resting against the ribbon reverse bail, apply the push end of an 8 oz. scale, held at a right angle to the ribbon reverse arm at the center where the ribbon is threaded. It should require  $1-\frac{1}{2}$  to  $4\frac{1}{2}$  ozs. to start the ribbon reverse arm moving. If it is necessary to increase or decrease the tension, remove the spring and adjust by bending.

2. The Stripper Spring Requirement has been added to the following bulletins and should precede the CODE PUNCH-BLOCK FEED-ROLL SHIMS ADJUSTMENT.

BULLETIN 193, PAGE 19 BULLETIN 203, PAGE 2-13

# STRIPPER SPRING REQUIREMENT

/

Remove the punch block from the unit. (Refer to next adjustment for removal of punch block). With an 8 oz. scale hooked under the shoulder of the stripper pins, pull in a horizontal direction. It should require at least 4 ozs. to start the punch stripper pins moving by compressing the springs.

## CHANGES IN ADJUSTMENT BULLETINS

The spring tension requirement in the bulletins listed below (for synchronous motors using the three brush starting switch) should read as indicated.

Bulletin	Page	Bulletin	Page	Bulletin	Page	Bulletin	Page
127	38	169	5	186	19	197	24
138	52	170	9	189	14	199	2-8
141	17	171	23	192	18	201	5-20
160	44	175	7	193	40	203	5-29
165	2-31	176	7	194	7		//
168	13	178	46	195	15		

## SPRING TENSION REQUIREMENTS

Frequency

Cycles	Old	New	Part Numbers
60	3 ozs. to 3-3/4 ozs.	2 ozs. to 2-1/2 ozs.	82843
50	1-1/2 ozs. to 2-1/2 ozs.	1-3/4 ozs. to 2 ozs.	86616

## CONTROL RELAY-CONTACT SPRING ADJUSTMENTS Change this adjustment to read as follows:

Bulletin	Page	Paragraph	
127	33	(A) (3)	
138	58	(A) (3)	
160	50	(A) (C)	
165	2-27	d(1) (A)	(C.)

when the relay plunger is in the unoperated position hook an 8 oz. scale over the middle contact spring as close as possible to the wiper contact and pull horizontally at right angle to the contact spring. A pull of 5 to 6 ozs. is required to cause the middle contact to break contact with the inside contact. To adjust, bend the middle contact spring and recheck adjustment  $\underline{b}$  or (2).

Change applicable figure accordingly.

\*

840EE Issue 1 July, 1954

## CHANGES AND ADDITIONS TO MODEL 14 ADJUSTMENT BULLETINS 127B, ISSUE 3 TYPE BAR PAGE PRINTER 165B, ISSUE 4 TYPING REPERFORATOR 171B, ISSUE 2 TYPING REPERFORATOR 178B, ISSUE 1 REPERFORATOR TRANSMITTER 203B, ISSUE 1 REPERFORATOR TRANSMITTER 220B, ISSUE 1 TYPING REPERFORATOR

127B, Page 4 and Figure 3 165B, Page 2-1 and Figure 1 171B, Page 4 and Figure 3 178B, Page 3 and Figure 2 203B, Page 2-1 and Figure 4 220B, Page 2-1 and Figure 1

A stronger main shaft clutch spring number 122059 (approximately .890" long) has been provided for use on units operating at 75 wpm speed. The 6993 spring (approximately .740" long) continues to be used on units operating at 60 wpm speed.

MAIN CLUTCH SPRING TENSION

Change this adjustment to read as follows:

With the teeth of the driven clutch member resting against the teeth of the driving member, but not engaged, hook a 32 ounce scale over the throwout cam on the driven clutch member and pull as nearly in line with the shaft as possible. It should require 24 to 30 ounces (for 60 wpm) and 32 to 42 ounces (for 75 wpm speed) to separate the clutch teeth. Change applicable figures accordingly.

127B, Page 4 after (16) 165B, Page 7-2 after 7 b. 171B, Page 25 Main Bail after (2) 178B, Page 50 Main Bail after (2) 203B, Page 2-30 Par. Par. d. after (2) 220B, Page 3-2 Par. 5 after b.

In order to provide better lubrication for the main bail plunger of 14 type units the present 75226 oil wick and the 78244 oiler of the 8474 and 102056 main bail plungers are omitted and three 122547 felt wicks are provided in the upper portion of the plungers. The oiler is replaced by a  $1/4 \times 32$  hexagonal screw.

Add the following note to read as follows:

On all units equipped for improved lubrication remove the 1/4 x 32 screw and lockwasher from the plunger bushing. Saturate oil wicks and fill plunger with oil. Replace lockwasher and screw.

856EE Issue 1 April, 1956

CHANGES AND ADDITIONS TO BULLETIN 127B, ISSUE 3 ADJUSTMENTS - MODEL 14 TYPE BAR TAPE FRINTER

## Page 18, TAPE CHUIE ADJUSTMENT

.

In place of the present adjustment, substitute the following:

The exit tape-chute should be in alignment with the left-hand tape guide; adjust by means of the chute mounting screws. There also should be from .015" to .040" clearance between the under surface of the left-hand tape guide and the top surface of the exit chute channel when the platen assembly is in either the "Letters" or "Figures" position. If necessary, adjust by bending the chute bracket.

\* \*

춦

897EE Issue 1 September, 1956

## CHANGES AND ADDITIONS TO ADJUSTMENT BULLETINS

127B, Issue 3 - Type Bar Tape Printer (Model 14), Page 7, 10 138B, Issue 5 - Type Bar Page Printer (Model 15), Pages 19, 23 159B, Issue 2 - Type Wheel Page Printer (Model 26), Page 3 171B, Issue 2 - Typing Reperforator, Page 7 178B, Issue 1 - Reperforator Transmitter Distributor, Page 6 182B, Issue 1 - Multiplex Start-Stop Extensor Set, Page 14 197B, Issue 1 - Multiple Reperforator Set, Page 13 198B, Issue 1 - Multiple Reperforator Set, Page 13 198B, Issue 1 - Type-Wheel Page Printer (Model 27), Page 15 199B, Issue 1 - Simplex-Diplex Converter, Page 2-2 201B, Issue 1 - Sequential Control (SECO) System, Page 5-3 203E, Issue 1 - Reperforator Transmitter (Model 14), Page 2-3 210B, Issue 1 - Sequential Selector, Page 2-4 211B, Issue 2 - Multiple Reperforator Transmitter, Page 2-3

(ARMATURE ) LOCKING WEDGE

Change the requirement of the present adjustment as follows: (Bulletins and affected pages are listed above).

For pulling magnet selectors, from ".008" to .012" to read: .006" to .012". For holding magnet selectors, from ".006" to .010" to read: .005" to .012". Change applicable figure accordingly.

1 1.

• • •

898EE Issue 1, Page 1 November, 1956

#### CHANGES AND ADDITIONS TO ADJUSTMENT BULLETINS

127B, Issue 3 - Type Bar Tape Printer
138B, Issue 5 - Type Bar Page Printer
148B, Issue 2 - Perforator Transmitter
159B, Issue 2 - Type Wheel Page Printer
165B, Issue 4 - Typing Reperforator
166B, Issue 2 - Perforator Transmitter
170B, Issue 1 - Multiple Transmitter Distributor and Base
175B, Issue 1 - Single Unit Transmitter and Base
176B, Issue 1 - Translator Unit, Receiving Distributor and Panel
182B, Issue 1 - Multiple Transmitter Distributor and Base
200B, Issue 1 - Multiple Transmitter Distributor and Base
200B, Issue 1 - Multiple Transmitter Distributor and Base
200B, Issue 1 - Multiple Transmitter Distributor and Base
200B, Issue 1 - Multiple Transmitter Distributor and Base
200B, Issue 1 - Multiple Transmitter Distributor and Base
201B, Issue 1 - Multiple Transmitter Distributor and Base

TRANSMITTING CONTACTS GAP ADJUSTMENT (For following Bulletins)

127B,	Page	30	170B,	Page	2
138B,		The Party of the P	175B,	Page	2
148B,			176B,	Page	5
159B,		Company and Company an	185B,	Page	6
165B,	Carlos Ca		200B,	Page	3-10
166B,		and the second s	and a second		

Change this adjustment to read as follows:

With each contact lever on the high part of its cam, the contact gap should be .017" to .025" (.015" to .025" for start-stop contacts).

NOTE: If no signal measuring device is available, <u>ALL</u> contact gaps should be:

.017" to .023" for units operating at 60 or 75 WPM .020" to .025" for units operating at 100 WPM

To adjust, bend the shorter contact springs.

TRANSMITTING CONTACTS GAP ADJUSTMENT (For following Bulletin) 1828, Page 11

Change this adjustment to read as follows:

The contact bracket should be positioned so that the mounting screws are approximately in the center of their holes (See Figure 23 in Bulletin). Under this condition and with each contact lever on the high part of its cam, the contact gap should be .017" to .025" (.015" to .025" for start-stop contacts).

- 2 -(898EE)

NOTE: If no signal measuring device is available, <u>ALL</u> contact gaps should be: .017" to .023" for units operating at 60 or 75 WPM. .020" to .025" for units operating at 100 WPM

To adjust, bend the shorter contact springs.

T

TRANSMITTING CONTACTS GAP ADJUSTMENT (For following Bulletins) 2018, Page 5-16 2218, Page 4

Change this adjustment to read as follows:

With each contact lever on the high part of its cam, the contact gap should be .017" to .025" (.015" to .025" for start-stop contacts).

NOTE: If no signal measuring device is available, <u>ALL</u> contact gaps should be: .017" to .023" for units operating at 60 or 75 WPM. .020" to .025" for units operating at 100 WPM The shorter contact springs should rest against their backstops with a pressure of 4 to 8 ozs., measured by applying the push end of an 8 oz. scale at a right angle to the end of the shorter contact springs.

To adjust, bend the shorter contact springs and position the backstop adjusting screws to meet the above requirements. Tighten the adjusting screw lock nuts and recheck the requirements.

BACKSPACE MECHANISM SPRING TENSION REQUIREMENT (For following Bulletins) 148B, Page 17, Paragraph A.1. 166B, Page 18, Paragraph A.

Change the requirement to read 3 to 6 bzs. instead of 4 to 6 ozs.

Change applicable figure accordingly.

BULLETIN NO. 127 ISSUE 3 SEPTEMBER, 1946

# TELETYPE PRINTING TELEGRAPH SYSTEMS

BULLETIN NO. 127

ADJUSTMENTS

TYPE BAR TAPE PRINTER MODEL 14



Western Electric Company CHICAGO, U.S.A.

BULLETIN NO. 127 ISSUE 3 SEPTEMBER, 1946

# **TELETYPE** PRINTING TELEGRAPH SYSTEMS

ADJUSTMENTS

TYPE BAR TAPE PRINTER MODEL 14



Copyright 1936 and 1946 by Teletype Corporation

ą.

-





MODEL 14 SENDING- RECEIVING TAPE PRINTER ( LESS COVER )



## - A -(B-127)

# CONTENTS

	Page
GENERAL	1
GOVERNOR ADJUSTMENTS	36
Governor Adjusting Bracket Adjustment	38
Governor Brush Position	37
Governor Brush Spring Plate Bracket Adjustment	37
Governor Brush Spring Pressure	37
Inner Disc Brush Spring	37
Outer Disc Brush Spring	38
Governor Brush Spring Requirement	36 36
Governor Shims Adjustment	37
Speed Adjusting Lever Stop Plate Adjustment	36
Speed Adjusting Wheel Friction Washer Spring	50
Tension Adjustment	36
Tension wajus menterererererererererererererererererere	20
KEYBOARD BASE ADJUSTMENTS	28
Bell Hammer Extension Stop Adjustment	29
Bell Hammer Spring Tension	29
Clutch Spring Compression	30
Clutch Throwout Lever Adjustment	30
Clutch Throwout Lever Eccentric Adjustment	31
Clutch Throwout Lever Spring Tension	31
Control Relay Adjustments	33
Gear Guard Adjustment	29
Intermediate Pawl Eccentric Adjustment	31
Locking Lever Shaft Adjustment	30
Locking Lever Travel	30 29
Locking Pawl Spring Tension	30
Lock Loop Roller AdjustmentLock Loop Spring Tension	29
Mechanical Motor Control Mechanism Adjustment	34
Armature Stop Adjustment	34
Inner Contact Assembly Adjustment	
Latch Backstop Screw Adjustment	34
Latch Spring Tension	35
Outer Contact Assembly Adjustment	35
Start Magnet Armature Spring Tension	35
Start Magnet Bracket Adjustment	34
Start Magnet Core Adjustment	
Stop Magnet Armature Spring Tension	
Stop Magnet Bracket Adjustment	
Stop Magnet Core Adjustment	
Repeat on "S" Mechanism Adjustment	
Repeat Space Rod Spring Tension	33
Repeat Yoke Lug Adjustment	33 32
Repeat on Space Mechanism Adjustments	
Jack Spring Tension	1
Key Lever Spring Tension	24

•

\*

.

	Page
Repeat Space Rod Adjustment	32
Repeat Space Rod Bracket Adjustment	
Tape Guide Tube Adjustment	32
Typing Unit Slip Connections Spring Tension Adjustment	32
Tape Lever Adjusting Clamp Adjustment	28
Tape Lever Spring Tension	29
Tape-Out Bell Adjustment	29
Transmitting Cam Cylinder Adjustment	30
Transmitting Contacts Gap Adjustment	
Transmitting Contacts Spring Pressure	30
Trip-off Pawl Eccentric Adjustment	31
Trip-Off Pawl Spring Tension	32
Trip-Off Pawl Stop Plate Adjustment	
Universal Bar Pilot Screws Adjustment	28
TIME TON	
LUBRICATION	
Bell and Break Contact Mechanism Adjustments	
Keyboard	42
Mechanical End-of-Line Indicator Mechanism	
Motor Control on Upper Case "H" Mechanism	42
Suppression of Printing and Spacing on Lower Case of	10
Blank Mechanism	
Typing Unit	40
MISCELLANEOUS INSTRUCTIONS	1
To Adjust Motor Speed	
To Measure Receiving Range	
	~
SYNCHRONOUS MOTORS	38
Starting Switch Adjustments	
TYPING UNIT	3
Bell and Break Contact Mechanism Adjustment	23
Double Contact Mechanism	
Bell Hammer Adjustment	
Break Signal Contact Spring Adjustment	
Contact Mounting Screws Adjustment	
Contact Springs Adjustment	
Detent Arm Spring Tension	
Single Contact Mechanism	24
Contact Springs Adjustment for Single Contact	
Mechanism	
Bell Hammer Eccentric Screw Adjustment	
Carriage Bracket Locating Plate	
Carriage Capstan Nuts Adjustment	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
Carriage Extension Adjustment	
Carriage Locking Pawl Post Adjustment	
Carriage Locking Pawl Spring Tension	
Carriage Locking Toe Adjustment	
Carriage Return Spring Tension	and the second second
Figures Stop Screw Adjustment	
Function Bar Bracket Plates Adjustment	
Armature Pivot Screw Adjustment	
VINTATAL LIAOP DCLAM VOINPULPOOD	9
N

0

9

• . ŝ.-

	Page
Armature Spring Tension Adjustment	12
Locking Lever Spring Tension	11
Locking Wedge Adjustment	10
Selector Arm Bracket Ad justment	10
Selector Arm Operating Screw Adjustment	13
Selector Arm Pivot Screw Adjustment	.9
Selector Arm Spring Tension	13
Selector Arm Stop Detent Ad justment	11
Selector Arm Stop Detent Spring Tension	
Selector Lever Spring Tension	11
Selector Magnet Adjustment	.9
Selector Magnet Bracket Adjustment	12 11
Stop Lever Recentric Screw Adjustment	13
Stop Lever Spring Tension	13
Trip Latch Spring Compression	
Trip-Off Screw Adjustment	
Instructions for Removing a Type Bar	
Left Function Pull Bar Spring Bracket Adjustment	
Left Tape Guide Adjustment	
Main Bail Adjusting Screw Adjustment	16
Main Bail Cam Clutch Torque	23
Main Shaft Adjustment	3
Main Shaft Clutch Spring Tension	
Main Shaft Clutch Throwout Lever Adjustment	3
Main Shaft Clutch Throwout Lever Spring Tension	3
Mechanical End-of-Line Indicator Adjustment	24
Cam Lever Spring Tension	25
Contact Bracket Adjustment	25 25
Feed Pawl Spring Tension	24
Lamp Contact Adjustment	25
Worm Follower Adjustment	25
Worm Follower Spring Tension	25
Worm Shaft End Play	24
Mechanical Motor Control Mechanism Which Functions	
on Upper Case "H" Adjustments	26
Contact Lever Adjusting Screw Adjustment	28
Contact Lever Bracket Adjustment	26
Contact Lever Spring Tension	27
Latch Lever Bracket Extension Adjustment	26
Latch Lever Extension Adjustment	
Latch Lever Spring Tension	27
Main Bail Spring Adjustment	28
Motor Control Contacts Adjustments	27
Operating Lever Spring Tension	27
Mechanism to Prevent Printing and Spacing on Lower	
Blank Adjustments	25
Space Suppression Lever Adjustment	
Space Suppression Lever Stop Arm Adjustment	26 4
Motor Position Adjustment	16
Pull Bar Guide Adjustment Pull Bar Lock-Out Lever Adjustment	
LATT Dat. FORV-OAD TOACL WAINS MIGHTONNESS	-/

	Page
Pull Bar Springs Tension	15
Pulling Magnet Selector Mechanism Adjustments	4
Armature Locking Lever Spring Tension	7
Armature Locking Wedge Adjustment	7 7
Armature Stops Adjustment	
Armature Trip-Off Eccentric Screw Adjustment	8
Magnet Bracket Adjustment	8 8
Magnet Coils Adjustment	e
Selector Armature Adjustment	4
Selector Armature Bracket Adjustment	4 5 5
Selector Armature Bracket Link Adjustment	?
Selector Armature Bracket Link Friction Adjustment	4477
Selector Lever Spring Tension	4
Stop Lever Eccentric Screw Adjustment	4
Stop Lever Spring Tension	8
Trip Latch Spring Compression	21
Ribbon Check Pawl Adjustment	21 22
Ribbon Check Pawl Spring Pressure	15
Ribbon Feed Lever Spring Tension	22
Ribbon Feed Pawl Adjustment	
Ribbon Feed Pawl Spring Pressure Adjustment	21
Ribbon Feed Shaft Detent Plunger Spring Compression	21
Ribbon Feed Shaft Safety Spring Compression	0.032.03
Ribbon Guide Adjustment	102.22
Ribbon Reverse Arm Shaft Adjustment	21
Ribbon Reverse Pawl Link Adjustments	21
Ribbon Spool Bracket Adjustment	20
Ribbon Spool Cups Adjustment	20
Ribbon Spool Shaft Slot Adjustment	21
Ribbon Spool Shaft Spring Compression Adjustment	20
Right and Left Ribbon Reverse Pawls Spring Tension	22
Right and Left Ribbon Spool Shaft Gears Adjustments	20
Right Function Pull Bar Spring Bracket Adjustment	22
Right Tape Guide Adjustment	17
Selector Clutch Torque	23
Selector Separator Plate	3
Shift Rocker Adjustment	19
Shift Rocker Lever Post Adjustment	18
Shift Rocker Post Adjustment	18
Signal Bell Adjustment	23
Spacer Detent Adjustment	14
Spacer Detent Lever Spring Tension	15
Spacer Feed Pawl Spring Tension	15
Spacer Locking Bail Finger Adjustment	16
Spacer Locking Bail Spring Tension	15
Spacer Locking Pawl Bracket Adjustment	16
Spacer Locking Pawl Spring Tension	17
Spacer Operating Lever Spring Tension	15
Tape Chute Adjustment	18
Tape Feed Roll Spring Tension	18

- D -(B-127)

2

.

.

Ĵ

#### ADJUSTMENTS

GENERAL

This bulletin covers requirements and adjusting procedures for the maintenance of Model 14 Printers. Adjustments are arranged in a sequence that would be followed if a complete readjustment of a unit were undertaken. In following such a procedure, parts or assemblies which are removed to facilitate adjustment should not be replaced until all other adjustments are made which would be facilitated by the removal of these parts. If one adjustment is changed, related adjustments should be checked.

The spring tension values indicated in this bulletin are scale readings which should be obtained when Teletype scales are used as specified. Springs which do not meet the requirements specified and for which no adjusting procedure is given should be replaced by new springs. Ordering information may be obtained from the Teletype parts bulletin.

Before proceeding with any adjustment, read the applicable portion of the adjusting text carefully. After the adjustment is completed, be sure to tighten any screws or nuts which may have been loosened. If a part that is mounted on shims is to be dismantled, the number of shims used at each of its mounting screws should be noted so that the same shim pile-ups can be replaced when the part is remounted.

Care should be exercised in removing or installing the cover to avoid damaging parts in close proximity. As a precaution, raise or lower the cover slowly with a vertical movement.

#### MISCELLANEOUS INSTRUCTIONS

TO ADJUST MOTOR SPEED

110 volt 50 or 60 cycle synchronous motors may be used on 110 volt 50 or 60 cycle alternating current power supply unless the frequency varies more than plus or minus .75%; in which case series wound governed motors should be used. When governed motors are used, a speed indicating fork is required for the purpose of checking the motor speed. The fork is equipped with shutters attached to the end of the times. The governor is equipped with a target having alternate black and white spots (Figure 85).

To check the speed, the target should be well illuminated. Tap the fork gently to make it vibrate. Hold the fork so that the shutters are close to the eye and view the target through the openings in the shutters. If the motor is running at the correct speed, the target will appear stationary. If the motor speed is too fast, the target will appear to be moving in the direction of rotation; if too slow, in the opposite direction.

NOTE: There is a possibility of setting the speed incorrectly, due to getting a speed multiple; i.e., the speed could be half the desired speed, or some multiple thereof, even though the spots appear stationary when viewed through the shutters on the tuning fork. This should be kept in mind if trouble is experienced in the operation of the unit.

When increasing or decreasing the motor speed, the speed adjusting lever or the governor adjusting bracket, respectively, should be momentarily depressed. (See Figure 85 for location of parts).

#### TO MEASURE RECEIVING RANGE

Mounted on the selector above the end of the main shaft is a range finder assembly which is used for the purpose of orientating the selector to incoming signals.

Before proceeding to measure the receiving range on a unit equipped with a pulling magnet selector, turn the selector armature spring adjusting screw to a position where it will require 6 to 6-3/8 ozs.\* to stretch the armature spring to its position length. Then transmit RY (the letters R and Y sent alternately) to the printer continually while the receiving range is being determined. This procedure is described in the following paragraphs.

While RY is being received, loosen the index arm thumb screw and shift the index arm of the range finder toward 0 until errors appear in the copy. Then move the arm back slowly until errors no longer appear; at least 72 characters should be received without error. This position indicates one limit of the orientation range. Note the position of the index arm on the scale. Determine the opposite end of the receiving range by repeating the foregoing procedure with the index arm near the opposite end of the scale. After the two limits of the receiving range have been found, set the index arm of the range scale midway between these two points.

NOTE: If facilities for transmitting biased test signals to the receiving unit are available, the index arm should be set at the optimum setting for the reception of biased signals.

THE FOLLOWING PARAGRAPH APPLIES ONLY TO UNITS EQUIPPED WITH PULLING MAGNET SELECTORS

- (1) When a distortion test set is available for measuring the receiving margins of a unit, the armature spring tension may be varied from 6 to 7 ounces in order to obtain the specified receiving margins. This tension should be checked with the armature in the marking position and the spring stretched to position length.
- (2) When no distortion test set is available, but the unit is equipped with a line relay, the selector armature spring adjusting screw should be positioned so that it will require from 6 to 6-3/8 ounces to stretch the spring to position length when the armature is in its marking position.

To check, unbook the spring from the adjusting screw, hook an 8 oz. scale in the spring eye, and pull in line with the screw.

\* 1

(\*) If unit is equipped with a holding magnet selector - See Page 12.

- (3) When no distortion test set is available and the unit is not equipped with a line relay, turn the armature spring adjusting screw in a clockwise direction until errors appear in the copy. Then, from this point, count the number of turns the adjusting screw can be turned in a counterclockwise direction before errors again appear in the copy. Turn the adjusting screw back (clockwise) half this number of turns to a point midway between the two failing points (the middle of the armature spring margins) and lock the adjusting screw with its lock nut.
- NOTE: To secure reliable clutch trip, the tension should be checked to ascertain that it is not below 4-1/2 ozs.

If no errors appear in the copy throughout the entire physical range of the spring so that the above procedure cannot be followed, set the spring tension at 6 to 6-3/8 ozs. and lock the adjusting screw. The orientation range should be rechecked after the armature spring range has been determined.

#### TYPING UNIT

#### SELECTOR SEPARATOR PLATE ADJUSTMENT (Figure 1)

NOTE: The separator plate leaf springs are adjusted during the initial assembly of the unit and should require attention only if the selector has been damaged or dismantled. If it is found necessary to check the adjustment, extreme care should be exercised in the removal and replacement of the selector lever springs to guard against distorting them. The subsequent selector adjustments will be facilitated if the swords and selector levers are replaced in the identical location they formerly occupied.

The leaf springs should exert a light pressure against the swords. To adjust, bend the leaf springs at the narrow portions so that the ends of the springs are .050" to .060" below the under surface of the straight portions.

## MAIN SHAFT ADJUSTMENT

When the main shaft is rotated, the selector cams on the selector cam sleeve should line up with their respective selector levers. To adjust, loosen the four screws that hold the main shaft bearing brackets (Figure 2), and set the position of the main shaft.

MAIN SHAFT CLUTCH THROW-OUT LEVER ADJUSTMENT (Figure 2A)

The clutch teeth should be separated by .010" to .020" when fully disengaged. To secure this clearance, adjust the clutch throw-out lever by means of its pilot screws. After the clearance is obtained, the clutch throwout lever should be free in its bearings with no perceptible end play.

MAIN SHAFT CLUTCH THROW-OUT LEVER SPRING TENSION (Figure 2A)

With the clutch throw-out lever on the low surface of the driven clutch member, hook an 8 oz. scale over the clutch throw-out lever at the spring hole, and pull horizontally at right angles to the clutch throw-out lever. It should require 2-1/2 to 4 ozs. to start the lever moving.

MAIN SHAFT CLUTCH SPRING TENSION (Figure 2B)

With the teeth of the driven clutch member resting against the teeth of the driving clutch member but not engaged, hook a 32 oz. scale over the throw-out can on the driven clutch member and pull down as nearly in line with the shaft as possible. It should require 24 to 30 ozs. to separate the clutch teeth.

#### MOTOR POSITION ADJUSTMENT

There should be a minimum backlash without binding between the motor pinion and the main shaft gear. Check this backlash for one complete revolution of the main shaft. The position of the motor may be adjusted by means of the motor mounting screws.

PULLING MAGNET SELECTOR MECHANISM ADJUSTMENTS

The pulling magnet selector illustrated in Figure 6 should meet the following requirements: (See Page 9 for HOLDING MAGNET SELECTOR MECHANISM ADJUSTMENTS.)

REMOVE THE RANGE FINDER

SELECTOR ARMATURE BRACKET LINK FRICTION ADJUSTMENT (Figure 3)

Remove the selector bracket link screw. With an 8 oz. scale hooked in the link screw hole and pulled at right angles to the link, it should require some tension, not over 8 ozs., to start the link moving. If necessary, remove the link and adjust the slotted end to obtain this friction. Replace the link and screws.

#### SELECTOR LEVER SPRING TENSION (Figure 3)

With the code bars in the MARKING position and with the main bail in its highest position, move the swords manually to the SPACING position. Hook a 32 os. scale over the end of each selector lever at the selector cam sleeve and pull radially to the main shaft. It shall require from 6 to 10 ozs. to start each selector lever moving.

NOTE: When making this check, be sure that the selector levers are free and without bind.

SELECTOR ARMATURE ADJUSTMENT (Figure 4)

The armature should be free on its pivot screws, with barely perceptible end play. There should be some clearance, not more than .008", between the lower surface of the armature locking wedge and the No. 1 sword under the following conditions:

- (1) No. 1 selector lever resting on the peak of its cam.
- (2) No. 1 sword held against the upper separator plate without bending the latter.

(3) Armature end play taken up in a direction to reduce the specified clearance to a minimum.

To adjust, proceed as follows:

If there is no clearance between the armature locking wedge and the No. 1 sword, loosen the lock nut on the upper pivot screw and adjust to obtain clearance, noting that a quarter-turn of the screw is equivalent to approximately .006". Remove the armature bracket and adjust lower pivot screw to obtain the proper armature end play. Replace the armature bracket.

If there is more than .008" clearance, remove the armature bracket and adjust the lower pivot screw. Replace the bracket and adjust the armature end play by means of the upper pivot screw.

SELECTOR ARMATURE BRACKET LINK ADJUSTMENT (Figures 5 and 6) - See Note (A)

The position of the armature bracket should be such that a line through the center of the No. 1 sword extends approximately through the centers of the armature pivot screws when the swords are held midway between the stop posts by means of the No. 72581 gauge pins. To adjust, proceed as follows:

- (1) Unhook the locking lever spring, loosen the magnet bracket mounting screws, and move the bracket to its rearmost position. Loosen the armature bracket mounting screws, the link screw, and back off the armature stops. Move the bracket eccentric out of the way, so that it will not interfere with the adjustment. Rotate the main shaft until the No. 1 selector lever rests on the peak of its cam.
- (2) Hold the swords in a position midway between the two stop posts by means of the No. 7258l gauge pins inserted between the stop posts and the swords. Be sure that both the armature extension arms are between the arms of the swords. With the swords held in this position, place the No. 73370 locating gauge over the ends of the No. 1 sword, so that the two legs of the gauge are against the ends of the sword arms. Move the bracket to a position where both the armature extension arms are against the flat surface between the legs of the gauge.
- (3) Hold the bracket in this position and tighten the link screw only. Remove the locating gauge and the two gauge pins.

SELECTOR ARMATURE BRACKET ADJUSTMENT (Figure 6) - See Note (A)

The position of the armature bracket should be such as to provide some clearance, not more than .040", between each sword and either stop post under the following conditions:

\* \* \*

Rotate the main shaft until the No. 1 selector lever is resting on the peak of its cam. With the armature in its unoperated SPACING position, move the spacing arm of the No. 1 sword against the armature extension. Place a .040" wire gauge against the spacing stop post and move the armature slowly toward the MARKING position. The blade of the sword should strike the .040" gauge before the armature leaves the spacing arm of the sword. Under these conditions, the armature will move the sword to within not more than .040" of the stop post. Remove the .040" gauge and repeat the foregoing procedure. The armature should leave the spacing arm of the sword before the blade of the sword strikes the spacing stop post. Under these conditions, there should be

some clearance between the sword and the stop post.

- 6 -(B-127)

Unhook the armature spring at its adjusting screw and, with the selector armature in its operated MARKING position, move the marking arm of the No. 1 sword against the selector armature extension. Then rotate the armature slowly toward the SPACING position until the armature just leaves the marking arm of the No. 1 sword. Check the clearance between the No. 1 sword and the marking stop post in the same manner as described in the foregoing paragraph. With each selector lever on the peak of its cam, each associated sword should be tried for the foregoing requirement of some clearance, not more than .040", between each sword and the stop posts.

To adjust, tighten the armature bracket mounting screws just enough so that the bracket may be moved by tapping it lightly. By rotating the bracket on its pivot, the clearance between the swords and the stop posts may be regulated. If this clearance is more than .040", move the bracket in a direction to bring the armature toward the sword. If there is no clearance, move the bracket in the opposite direction to bring the armature away from the sword.

If the clearance between the sword and one stop post is close to zero and the clearance between the sword and the other stop post is more than .040", it will be necessary to refine the SELECTOR ARMATURE BRACKET LINK as follows:

Loosen the armature bracket mounting screws and the armature bracket link screw and move the armature bracket to the right or left so that the rear end of the link will move in a direction corresponding to the post at which a greater clearance is desired; i.e., if the clearance between the sword and the right stop post is less than that between the sword and the left stop post, move the bracket to the right. Tighten the bracket link screw and proceed to adjust the armature bracket according to the preceding paragraphs.

After the bracket is set and both screws are tightened, move the bracket eccentric against the bracket and tighten its screw. The eccentric and link will, therefore, determine the position of the bracket. The bracket may be removed by simply removing the two bracket screws. In replacing, the bracket should be held against the eccentric stop, while the two bracket screws are tightened.

## ARMATURE STOPS ADJUSTMENT (Figures 6 and 7) - See Note (A)

The No. 1 sword arms (right and left) should clear the associated arm of the selector armature extension by .035" to .037"\* when the front edge of the opposite sword arm is against its armature extension arm and the No. 1 selector lever is on the high part of its cam. To adjust the clearance of the right arm, remove the locking lever spring and reposition the unoperated stop screw with the armature in its unoperated position. To adjust the clearance of the left arm, reposition the operated stop nut with the armature in the operated position, and with the coils energized. If either clearance is changed, recheck the clearance of the other arm. If necessary, pinch the nut to make it tight on its screw. Replace the locking lever spring.

(\*) The upper limit may be increased up to .042" only if necessary in order to permit meeting the requirements for clearance given under the heading ARMATURE TRIP-OFF ECCENTRIC SCREW ADJUSTMENT.

ARMATURE LOCKING WEDGE ADJUSTMENT (Figure 8)

There should be .008" to .012" clearance between the point of the armature locking wedge and the point of the locking lever when the locking lever is on the long high part of the locking cam and the two points are in line. To adjust, move the locking wedge forward or backward in its slot in the armature extension by means of the locking wedge lock nut.

ARMATURE LOCKING LEVER SPRING TENSION (Figure 8)

With the locking lever on the high part of the locking cam, hook a 32 oz. scale in the spring hole of the locking lever and pull in line with the spring. It should require 10 to 14 ozs. to start the lever moving.

STOP LEVER ECCENTRIC SCREW ADJUSTMENT (Figure 9) - See Note (A)

The stop lever on the range finder assembly should overtravel the latching surface of the trip latch by some, not more than .006", clearance. To adjust, position the stop lever eccentric screw by means of its lock nut, making certain that the tightening of the eccentric screw lock nut does not disturb the adjustment.

STOP LEVER SPRING TENSION (Figure 10) - See Note (A)

NOTE: Be sure that the stop lever eccentric has been adjusted before taking this reading.

With the trip latch plunger held operated, hook an 8 oz. scale at the end of the stop lever on the range finder assembly. It should require 3/4 to 1-1/4 ozs. to start the lever moving.

\* \* \*

TRIP LATCH SPRING COMPRESSION (Figure 9) - See Note (A)

When measuring this requirement, the range finder assembly should be held in a horizontal position. When an 8 oz. scale, held in a vertical position, is applied to the trip latch as near to the stop lever as possible and pushed upward, it should require 1 to 1-1/2 ozs. to start the trip latch moving.

REPLACE THE RANGE FINDER ASSEMBLY TAKING CARE TO AVOID JAMMING THE TRIP LATCH PLUNGER AGAINST THE ARMATURE TRIP-OFF ECCENTRIC SCREW WHEN REMOUNTING.

ARMATURE TRIP-OFF ECCENTRIC SCREW ADJUSTMENT (Figure 11)

There should be some clearance, not more than .002", between the stop lever and the trip latch when the armature is in the unoperated position and the main shaft is rotated until the stopping edge of the stop lever is directly below the latching surface of the trip latch.

The trip latch plunger should have at least .002" end play (See Figure 9) when the armature is held in the attracted position and with the stop lever against its eccentric screw.

To adjust, position the armature trip-off eccentric screw by means of its lock nut to meet the first requirement. The latter adjustment serves as a check on the trip-off eccentric screw adjustment and also on the armature stops adjustment.

#### MAGNET COILS ADJUSTMENT

The top edge of the core of the upper magnet coil should align (within 1/64") with the top edge of the armature. Adjust by means of the magnet coil mounting screws.

#### MAGNET BRACKET ADJUSTMENT

There should be .002" to .007"\* clearance between each magnet core and the armature antifreeze strip when the magnet coils are energized and the armature is against the operated stop nut (marking stop). The faces of the cores should be parallel to the face of the armature. To adjust, position the bracket by means of its enlarged mounting holes. See Figure 6 for location of parts.

(\*) This clearance should be .003" to .010" when a chromium plated armature is used.

#### \* \* \*

#### HOLDING MAGNET SELECTOR MECHANISM ADJUSTMENTS

The holding magnet selector illustrated in Figure 12 should meet the following requirements: (See page 4 for Pulling Magnet Selector Mechanism Adjustments).

REMOVE THE RANGE FINDER ASSEMBLY

ARMATURE PIVOT SCREW ADJUSTMENT (Figure 12)

With the armature spring and the selector arm spring unhooked, the armature should be free on its pivots with barely perceptible end play. To adjust, loosen the armature upper pivot screw lock nut and position the armature by means of its upper pivot screw. Tighten the lock nut and replace the selector magnet bracket.

Rehook the armature spring and the selector arm spring.

SELECTOR MAGNET ADJUSTMENT (Figure 13)

When the armature is in its operated position, it should touch both magnet cores at approximately the centers of their pole-faces, and the cores should be centrally located with respect to the armature as gauged by eye when holding a light background behind the magnet and armature assembly. To adjust, remove the selector magnet bracket and reposition the magnet core assembly by means of its mounting screws while holding the assembly so that the cores are vertical and the armature, by its own weight, rests against the pole-faces. Replace the selector magnet bracket.

NOTE: When the cores are in proper adjustment, it should require at least 3-1/2 lbs. pull, with a 64 oz. scale hooked to the armature edge in line with the armature extension, to separate the armature from the cores when a current of .020 amperes is flowing through the magnet coils (coils in series shunted by 5000 ohm resistance).

SELECTOR ARM PIVOT SCREW ADJUSTMENT (Figures 14 and 15) - See Note (A)

With the armature spring, the selector arm spring, and selector arm stop detent spring unhooked, the selector arm should be free on its pivots with barely perceptible end play, and the locking lever should over-travel the top and bottom edges of the locking wedge. There should also be .008" minimum clearance between the selector arm and the armature extension, and a minimum clearance of .010" between the selector arm and the selector arm stop detent when the play in the detent is taken up in a direction to make this clearance a minimum. The end play should be adjusted by means of the upper pivot screw. If the minimum clearance requirements are not met, it will be necessary to remove the selector magnet bracket, the selector arm bracket, and adjust both pivot screws of the selector arm.

\* \* \*

## SELECTOR ARM BRACKET ADJUSTMENT (Figure 12) - See Note (A)

The position of the selector arm bracket should be such as to provide some clearance, not more than .040", between each sword and either stop post, under the following conditions:

Remove the locking lever spring, the armature spring, selector arm stop detent spring, and the selector arm spring. Rotate the main shaft until the No. 1 selector lever is resting on the peak of its cam. With the selector arm in its unoperated (SPACING) position, move the spacing arm of the No. 1 sword against the selector arm extension. Then rotate the selector arm slowly toward the MARKING position until the selector arm just leaves the spacing arm of the No. 1 sword. There should be some clearance, not more than .040", between the No. 1 sword and the spacing stop post.

With the selector arm in its operated (MARKING) position, move the marking arm of the No. 1 sword against the selector arm extension. Then rotate the selector arm slowly toward the SPACING position until the selector arm just leaves the marking arm of the No. 1 sword. There should be some clearance, not more than .040", between the No. 1 sword and the marking stop post.

With each selector lever on the peak of its cam, each associated sword should be tried for the foregoing requirement of some clearance, not more than .040". To adjust, loosen the selector arm bracket mounting screws just enough to make the bracket friction tight. Then, to equalize the clearance between the swords and the stop posts, loosen the centralizing eccentric screw lock nut and turn the eccentric screw clockwise to provide more clearance on the SPACING side or counterclockwise to provide more clearance on the MARKING side.

NOTE: Be sure that the selector arm stop detent does not interfere with the adjustment.

The centralizing eccentric screw should always be located so that its indicating line is adjacent to the marked scale that has been provided on the bracket to aid in gauging the amount the screw must be turned. Tighten the lock nut when the selector arm has been centralized. To obtain the "some clearance, not more than .040"," requirement between the swords and the stop posts, insert the No. 90783 adjusting wrench in one of the two holes provided and turn the wrench to move the bracket closer to or farther from the swords as required. Then tighten the selector arm bracket mounting screws. Replace the locking lever spring, selector arm spring, and armature spring.

#### LOCKING WEDGE ADJUSTMENT (Figure 16)

With the locking lever on a high part of its cam, the end of the locking wedge should clear the locking lever by .006" to .010" when the end of the wedge is held in line with the locking lever. To adjust, loosen the locking wedge mounting screw and position the locking wedge in its guide: then

\* \*

- 11 -(B-127)

tighten the mounting screw.

LOCKING LEVER SPRING TENSION (Figure 16)

With the locking lever on the high part of its cam, hook an 8 oz. scale on the end of the locking lever, at the spring hole, and pull in line with the spring. It should require 4 to 5-1/2 ozs. to start the lever moving away from the cam.

SELECTOR ARM STOP DETENT ADJUSTMENT (Figure 14)

With the locking lever on the low part of its cam, there should be an equal amount of clearance, within .003", between the sides of the locking wedge and the locking lever when the selector arm is in the MARKING or SPACING position.

NOTE: When checking the MARKING position, be sure that the selector arm operating screw does not interfere with the movement of the selector arm.

To adjust, loosen the screw that mounts the selector arm stop detent eccentric post just enough to make the post friction tight. Position the stop detent by turning the post; then tighten the post mounting screw.

SELECTOR ARM STOP DETENT SPRING TENSION (Figure 14)

Unhook the stop detent spring from the locking lever guide and hook an 8 oz. scale in the spring eye. It should require 4 to 5 ozs. to pull the spring to its position length.

SELECTOR LEVER SPRING TENSION (Figure 16)

With the code bars in the MARKING position and with the main bail in its highest position, move the swords manually to the SPACING position. Hook a 32 oz. scale over the end of each selector lever at the selector cam sleeve and pull radially to the main shaft. It shall require from 6 to 10 ozs. to start each selector lever moving.

NOTE: When making this check, be sure that the selector levers are free and without bind.

SELECTOR MAGNET BRACKET POSITION ADJUSTMENT (Figure 17)

With the main shaft in the stop position, rotate the selector cam sleeve until the locking lever just drops off the high part of its cam; then rotate the cam sleeve backward until the rotation is stopped by the locking lever. Under this condition there should be a clearance of .060" to .065" between the armature extension and the face of a tooth on the armature cam. To adjust, loosen the selector magnet bracket mounting screws and the selector magnet bracket adjusting arm mounting screws just enough to make the bracket and adjusting arm friction tight. Then position the selector magnet bracket by means of the adjusting arm, using the No. 90783 adjusting wrench. To do this, insert the adjusting wrench in the hole above the end of the adjusting arm and rotate the wrench. Tighten the bracket and adjusting arm mounting screws.

NOTE: When checking the above requirement, the armature extension should be held approximately .045" from the bottom of the notch of its cam.

SELECTOR MAGNET BRACKET ADJUSTMENT (Figure 13)

NOTE: When making this adjustment the selector arm should be kept in the MARKING position.

With the selector magnet energized, the clearance between the selector arm operating screw and the selector arm should be .004" to .006" greater when the armature lever is on a peak of its cam than when the armature is opposite an indent on the cam.

- (1) To adjust, de-energize the selector magnet and rotate the selector cam sleeve until the armature extension is resting on the peak of the armature cam. Holding the cam sleeve in this position, turn the main shaft to a point where it moves the armature the greatest distance.
- (2) With the selector magnet still de-energized, loosen the selector magnet bracket mounting screws and, by means of its adjusting screw, rotate the selector magnet bracket so that the armature just touches the pole-faces; then turn the adjusting screw an additional one-tenth of a turn counterclockwise. This will press the armature firmly against the magnet cores. (While making the one-tenth of a turn adjustment, be careful to avoid lost motion by taking up the slack in the adjusting screw.)
- (3) With the selector magnet energized, measure the clearance between the selector arm operating screw and the selector arm and if there is no clearance, back off the selector arm operating screw to provide at least .006" clearance. Then rotate the selector cam sleeve so that the armature extension is opposite an indent of its cam and again measure the clearance between the selector arm operating screw and the selector arm. If the difference in the two clearances exceeds .006", the selector magnet bracket adjusting screw should be turned clockwise. If the difference in the clearance is less than .004", turn the screw counterclockwise. Tighten the selector magnet bracket mounting screws.

ARMATURE SPRING TENSION ADJUSTMENT (Figure 13-A)

Unhook the armature spring from its spring arm and rotate the main shaft until the armature extension is on a high part of its cam. With a 32 oz. scale hooked in its spring eye, pull the spring to its position length. The following tension should apply:

- (A) If a distortion test set is available, the spring tension should be set at the optimum value within the limits of 13 to 24 ozs.
- (B) If no distortion test set is available, the spring tension should be 17 to 19 ozs., except when coils are connected in parallel without a

1000 ohm shunt. Under this latter condition the tension should be 13 to 15 ozs. To adjust, loosen the spring arm mounting nut and position the spring arm. Then tighten the mounting nut. Rehook the armature spring.

SELECTOR ARM OPERATING SCREW ADJUSTMENT (Figure 18)

With the selector magnet energized and the selector cam sleeve rotated so that the armature extension is opposite an indent of its cam, there should be a clearance of .003" to .006" between the selector arm operating screw and the selector arm. To adjust, loosen the selector arm operating screw lock nut and position the screw; then tighten the lock nut.

SELECTOR ARM SPRING TENSION (Figure 19)

Unhook the selector arm stop detent spring. With the armature extension on a high part of its cam, hook an 8 oz. scale over the end of the locking wedge and pull parallel to the selector arm spring. It should require 1-1/4 to 1-3/4 ozs. to start the selector arm moving. Replace the detent spring.

STOP LEVER ECCENTRIC SCREW ADJUSTMENT (Figure 20) - See Note (A)

The stop lever on the range finder assembly should overtravel the latching face of the trip latch by not more than .006". To adjust, loosen the stop lever eccentric screw lock nut and position the screw; then tighten the lock nut, making certain that the tightening of the lock nut does not disturb the adjustment.

TRIP LATCH SPRING COMPRESSION (Figure 20) - See Note (A)

When measuring this requirement, the range finder assembly should be held in a horizontal position. Apply the push end of an 8 oz. scale, held in a vertical position to the trip latch, as near to the stop lever as possible and push upward. It should require 1 to 1-1/2 ozs. to start the trip latch moving.

STOP LEVER SPRING TENSION (Figure 10) - See Note (A)

NOTE: Be sure that the stop lever eccentric has been adjusted before checking this requirement.

With the trip latch plunger held operated, hook an 8 oz. scale on the end of the stop lever of the range finder assembly and pull horizontally at right angles to the stop lever. It should require 3/4 to 1-1/4 ozs. to start the lever moving.

REPLACE THE RANGE FINDER ASSEMBLY, TAKING CARE TO AVOID JAMMING THE TRIP LATCH PLUNGER AGAINST THE ARMATURE TRIP-OFF SCREW WHEN REMOUNTING.

#### \* \* \*

# TRIP-OFF SCREW ADJUSTMENT (Figure 21)

There should be some clearance, not more than .002", between the stop lever and the trip latch when the armature is in the unoperated position and the selector cam sleeve is rotated until the stopping edge of the stop lever is directly below the latching surface of the trip latch. The trip latch plunger should have at least .002" end play (see Figure 20) when the armature is held in the attracted position and with the stop lever against its eccentric screw. To adjust, loosen the trip-off screw lock nut and position the screw to meet the first requirement. The latter requirement serves as a check on the tripoff screw adjustment and also on the adjustment of the selector magnet bracket.

# END OF HOLDING MAGNET SELECTOR MECHANISM ADJUSTMENTS

NOTE: Before making the following adjustments, it is necessary to remove the type basket from the typing unit. In order to avoid stretching springs and the possible bending of levers, the following method is suggested: Unhook the code bar locking lever spring, the signal bell hammer spring, letters pull bar spring, the space release pull bar spring, and locking bail spring, if the unit is equipped with a mechanism to prevent printing and spacing on lower case blank. Remove the three type basket assembly mounting screws. Remove the right ribbon spool bracket front mounting screw, loosen the rear mounting screw, and swing the bracket so that the ribbon spool cup will not interfere with the basket. Remove the bell-and-break signal mechanism. Hold the pull bars out of engagement with the pull bar guide (as an aid in holding the pull bars out of engagement with the pull bar guide, use a piece of wire or string around the upper ends of the pull bars). Disengage lower end of function pull bars from mechanism on base, and slide the assembly upward. Care should be taken that the pull bar toes are not jammed against the spacer locking bail or the signal bell hammer.

SPACER DETENT ADJUSTMENT (Figures 22 and 23) - See Note (B)

There should be .002" to .012" clearance between the face of the spacer feed pawl and the face of a tooth on the spacer ratchet wheel, when the spacer operating lever roller is resting in the bottom of the main bail plunger indent and the detent roller is resting in the hollow between two teeth. Gauge throughout one complete revolution of the ratchet wheel. To adjust, loosen the left front motor plate mounting screw and remove the two rear screws that hold the motor plate to the base. Remove the keyboard drive gear assembly and swing the motor out so as to gain access to the detent lever plate adjusting screw with a screwdriver. Adjust the detent lever plate, by means of these screws, to meet the foregoing requirements.

NOTE: It is possible to set the spacer detent in a position one full tooth off. This error, however, will affect the detent spring tension. Recheck the spring tension.

\* \*

NOTE (B) These requirements should be checked with the type basket removed.

SPACER DETENT LEVER SPRING TENSION (Figure 22) - See Note (B)

With the detent roller resting in the hollow between two teeth, hock a 4 lb. scale in the spring hole and pull in line with the spring. It should require 3-1/4 to 3-3/4 lbs. to start the detent lever moving.

SPACER FEED PAWL SPRING TENSION (Figure 22) - See Note (B)

Hook an 8 oz. scale over the spacer feed pawl just below the sloped edge of the pawl and pull as nearly at right angles to the pawl as possible. It should require 1 to 2 ozs. to start the pawl moving.

SPACER OPERATING LEVER SPRING TENSION (Figure 23) - See Note (B)

Hook a 12 lb. scale over the spacer operating lever just below the roller and pull as nearly parallel to the spring as possible. It should require 5 to 6 lbs. to start the lever moving.

RIBBON FEED LEVER SPRING TENSION (Figure 24) - See Note (B)

Loosen the ribbon feed pawl and move it out of engagement with the ribbon feed ratchet. With the ribbon feed lever roller in the plunger indent, hook a 32 oz. scale over the top of the ribbon feed lever and pull horizontally toward the front of the unit. It should require 12 to 18 ozs. to start the lever moving. Tighten the ribbon feed pawl.

SPACER LOCKING BAIL SPRING TENSION (Figure 25) - See Note (B)

Hook an 8 oz. scale under the spring hole in the right extension of the spacer locking bail and pull up vertically. It should require 1-1/2 to 2 ozs. to start the bail moving.

NOTE: When taking this tension, hold the spacer locking pawl away from the bail.

FUNCTION BAR BRACKET PLATES ADJUSTMENT (Figure 26)

The two end pull bars supported by the function bar bracket plates should have an equal amount of play in the segment. Adjust both the right and left function bar bracket plates by rotating them on their mounting screws.

PULL BAR SPRINGS TENSION (Figure 27) - See Note (B)

Unbook the spring from each pull bar. With an 8 oz. scale held in a vertical position, hook the scale in the spring eye. It should require 3 to 4 ozs. to pull each character pull bar spring to its position length and 5-1/2 to 6-3/4 ozs. to pull corresponding function pull bar springs to their position length. Rehook springs.

Remount the type basket. Care should be taken that the pull bar toes are not jammed against the spacer locking bail and the signal bell hammer.

\* \*

NOTE (B) These requirements should be checked with the type basket removed.

Replace the type basket assembly mounting screws. Replace the right ribbon spool bracket front mounting screw and tighten rear mounting screw. See that the function bar spring bracket is replaced. Replace the code bar locking lever spring, the letters pull bar spring, the space release pull bar spring, and the signal bell hammer spring. Replace the bell and break mechanism.

- 16 -(B-127)

NOTE: If the code bar assembly is removed from the pull bar guide plate, care must be used in replacing, as excessive tightening of the code bar post nuts may cause the code bar separator collar to become embedded in the German silver separator washers. To prevent this, tighten the nuts as follows: First back off the nuts and turn the lower nut until the lock washer is pressed flat. Then, with a wrench, hold the lower nut in this position while tightening the lock nut.

## PULL BAR GUIDE ADJUSTMENT (Figure 28)

With the BLANK combination set up, there should be .008" to .020" clearance between the unselected pull bars and the main bail, when the main bail is opposite the pull bar humps and the play of the main bail is taken up in a direction to make this clearance a minimum. With the LETTERS combination set up, there should be .008" to .020" clearance between the main bail and the blank pull bar.

There should be .004" to .080" clearance between the end of the No. 1 T-lever and the bottom of the slot in the code bar, measured at the point of closest approach. Also see that there is some clearance between the ends of Nos. 2, 3, 4, and 5 T-levers and their respective code bars, measured at the point of closest approach. To meet these requirements, adjust the position of the pull bar guide by means of its mounting screws.

### MAIN BAIL ADJUSTING SCREW ADJUSTMENT (Figure 1)

Rotate the main shaft until the main bail has reached its stop position (main bail roller on the high part of its cam). With the code bars in the MARKING position, there should be .010" to .050" clearance between the pull bars and the code bars when the play in the main bail and the pull bars is taken up to make this clearance a minimum. Check this clearance with the code bars in the SPACING position. To adjust, position the main bail adjusting screw by means of its lock nut.

#### SPACER LOCKING PAWL BRACKET ADJUSTMENT (Figure 25)

The shoulder on the spacer locking pawl should clear the notched part of the spacer operating lever by .040" to .050" when FIGURES combination is selected and the main shaft is rotated until the spacer operating lever roller is on the high part of the main bail plunger. To adjust, position the spacer locking pawl bracket by means of its mounting screws.

### SPACER LOCKING BAIL FINGER ADJUSTMENT (Figure 29)

There should be .015" to .025" clearance between the latching edge of the spacer operating lever and the latching edge of the spacer locking pawl when the "E" combination is set up and the main shaft rotated until the two edges are in line. To adjust, hold the spacer locking bail by means of the No. 72574 holding tool inserted under the type bar segment, alongside the carriage shaft gear and bend the spacer locking bail finger with the No. 72575 bending tool. The bending tool should be inserted horizontally between the motor and the main casting (on the left side of the unit).

SPACER LOCKING PAWL SPRING TENSION (Figure 25)

Set up the BLANK combination and rotate the main shaft until the main bail is in its extreme upper position. Place the typing unit on its back (resting on the motor). Hook an 8 oz. scale over the spacer locking pawl and pull up vertically. It should require 1-1/2 to 2-1/2 ozs. to start the pawl moving.

#### CARRIAGE BRACKET LOCATING PLATE

After the front carriage bracket has been set in a position where the carriage moves freely back and forth in all positions of the spacing gear, the carriage bracket locating plate should be moved against the bracket so that its three projections make contact with the bracket, and fastened in place. Thus, if the bracket is moved thereafter, it may be replaced in its proper position without further adjustment.

FIGURES STOP SCREW ADJUSTMENT (Figure 30)

The figure "2" should print in the middle of the platen roll. Adjust by means of the FIGURES stop screw and gauge by printing directly on the platen roll.

#### CARRIAGE LOCKING PAWL POST ADJUSTMENT

When in the LETTERS position, the carriage locking pawl should set fully on the locking toe when the play of the pawl is taken up in either direction. To adjust, position the locking pawl post by means of its lock nut. (See Figure 31 for location of parts.)

CARRIAGE LOCKING TOE ADJUSTMENT (Figure 31)

With the platen in the LETTERS position, the letter W should print in the middle of the platen roll, when printed directly on the platen and gauged by eye. To adjust, loosen the carriage locking toe mounting screw and position the carriage locking toe. Tighten the mounting screw.

LEFT TAPE GUIDE ADJUSTMENT (Figure 32)

The left tape guide should clear the platen roll by .004" to .010" throughout one complete revolution of the platen roll. Adjust by means of its mounting screw.

RIGHT TAPE GUIDE ADJUSTMENT (Figure 32)

The right tape guide should be so adjusted that when a piece of tape is inserted through both right and left tape guides, it will align with the platen roll and the printing will be in the center of the tape. Adjust the right tape guide by means of its mounting screw.

There should be .010" to .020" clearance between the platen roll and the end of the right tape guide when gauged throughout one complete revolution of the platen roll. Adjust by bending the right tape guide.

TAPE FEED HOLL SPRING TENSION (Figure 32)

With the tape feed roll resting on the platen, hook an 8 oz. scale over the end of the tape feed roll bearing screw and pull at right angles to the tape feed roll lever. It should require 6 to 8 ozs. to start the lever moving.

### TAPE CHUTE ADJUSTMENT

The tape chute should be in alignment with the tape guide and should clear the tape guide from .010" to .020". Adjust by means of its mounting screws.

SHIFT ROCKER POST ADJUSTMENT (Figure 33)

The sides of the shift rocker post should be parallel to the carriage shaft. Adjust by means of the shift rocker post lock nut.

CARRIAGE RETURN SPRING TENSION (Figure 30)

Unhook the carriage return spring from the spring post. With the carriage in the LETTERS position, hook an 8 oz. scale in the spring eye and pull the spring to its normal position length. It should require 6-1/2 to 7-1/2 ozs. Replace spring.

CARRIAGE LOCKING PAWL SPRING TENSION (Figure 31)

With the carriage held back far enough so that there is a clearance between the carriage locking toe and the carriage locking pawl, hook an 8 oz. scale over the carriage locking pawl just below the spring hole and pull up in line with the spring. It should require 1-1/2 to 2-1/2 ozs. to start the pawl moving.

SHIFT ROCKER LEVER POST ADJUSTMENT (Figure 34)

The front surface of the shift rocker lever post should be parallel to the front edge of the base plate. Position the post by means of its lock nut.

CARRIAGE EXTENSION ADJUSTMENT (Figure 33)

The carriage extension should travel equally on either side of a vertical line through the center of the shift rocker bearing screw, when the carriage is moved from the FIGURES to the LETTERS position. Adjust by means of the carriage extension mounting screws.

#### SHIFT ROCKER ADJUSTMENT

With the carriage in the FIGURES position, select the LETTERS combination and rotate the main shaft until the main bail roller is on the low part of its cam. Lift the main bail by hand to its highest position. The carriage locking toe should overtravel the carriage locking pawl not more than .020". Adjust the shift rocker by means of its adjusting screw to meet this requirement. See Figure 34 for location of parts.

NOTE: On those printers arranged to unshift on SPACE as well as on LETTERS combination, determine if the UNSHIFT ON SPACE gives the carriage a shorter travel. If so, use this combination instead of the LETTERS combination in making the adjustment.

#### INSTRUCTIONS FOR REMOVING A TYPE BAR

Remove the carriage spring, the ribbon from the guide, and the two screws from the carriage front bracket. Lift off the carriage assembly. Move the type bar forward and downward until the teeth on the type bar are disengaged from those on the pull bar. The type bar may then be unhooked from the fulcrum rod and removed.

To replace a type bar, hook it over the fulcrum rod. If the teeth are meshed properly, the type bar will rest against the pad when the top of its pull bar is in line with the other pull bars. If the type bar does not rest against the pad, move the type bar downward again until the teeth are out of mesh and then raise the pull bar as many teeth as is necessary to permit the type bar to resume its correct position. Replace the carriage making sure that the bracket is against the positioning plate, and tighten the bracket mounting screws.

The type bars should be free in their segment slots with a minimum amount of side play. To check the freeness of a type bar, move it down so that the pallet rests lightly on the platen roll. Then, when the type bar is released, it should return to its normal position against the type bar pad. If necessary, the sides of the type bar may be lapped on a fine stone to prevent binding in the segment slot.

CARRIAGE CAPSTAN NUTS ADJUSTMENT (Figure 31)

The carriage locking toe should overtravel the notch in the carriage locking pawl by .020" to .025" when the carriage capstan nuts are against the front carriage bearing. Adjust by means of the carriage capstan nuts.

PULL BAR LOCK-OUT LEVER ADJUSTMENT (Figures 35 and 36)

With the platen in the FIGURES position and the bell pull bar selected, rotate the main shaft to a point where the main bail is approximately .010" below the bell pull bar notch (Figure 35-A). There should then be .010" to .040" clearance between the side of the bell pull bar and the pull bar lockout lever roller (Figure 35-B), and the J or S pull bar (depending upon the type of printer) should be cammed out of the code bar slot by .004" to .020" (Figure 35-C). - 20 -(B-127)

Place the carriage in LETTERS position. With the BELL combination set up, rotate the main shaft until the main bail is moved to within approximately .010" of the notch in the J or S pull bar. The bell pull bar should be cammed out of the code bar slot by .004" to .020". (See Figures 36A-B-C). The requirements in the two foregoing paragraphs may be obtained by adjusting the position of the adjusting lever by means of its adjusting screws.

#### RIBBON GUIDE ADJUSTMENT

There should be .040" to .050" clearance between the printing surface of the platen roll and both sides of the ribbon guide. To measure this clearance, insert the gauge horizontally between the printing surface of the platen roll and both sides of the ribbon guide. To adjust, position the ribbon guide by means of its mounting screws. There should be 3/16" to 7/32" clearance between the tongue of the guide and the side of the platen roll. Bend the guide if necessary. Recheck the previous adjustment.

#### RIBBON SPOOL CUPS ADJUSTMENT (Figure 37)

The centers of both ribbon spool cup rollers should be within 4-11/16" to 4-13/16" of the typing unit base plate. To adjust, loosen the ribbon spool cup lock nuts and rotate the cups; tighten the lock nuts.

RIGHT AND LEFT RIBBON SPOOL SHAFT GEARS ADJUSTMENT (Figure 38)

The right and left ribbon spool shafts should have some end play, not more than .004". To adjust, position the bevel gears on the ends of the shafts.

NOTE: If the unit is equipped with an end-of-line indicator or a tape feedout control mechanism, obtain the .004" end play on the right-hand ribbon spool shaft by means of the rear set collar.

#### RIBBON SPOOL BRACKETS ADJUSTMENT

The ribbon spool brackets should align with the edges of the base plate and there should be a minimum amount of backlash between the bevel gears on the ribbon spool shafts and the bevel gears on the ribbon feed shaft throughout a complete revolution of the ribbon spool shafts when the ribbon feed shaft is in its extreme left-hand and right-hand position, respectively. To adjust, position the ribbon spool brackets.

NOTE: If the unit is equipped with an end-of-line indicator mechanism or a tape feed-out counter mechanism, the right-hand bracket should be adjusted so that the front edge of the right-hand ribbon spool cup is approximately in line with the front edge of the left-hand ribbon spool cup, and the gear backlash should be obtained by positioning the gear on the right-hand ribbon spool shaft.

## RIBBON SPOOL SHAFTS SPRING COMPRESSION ADJUSTMENT (Figure 38)

Move the ribbon feed shaft to its left-hand position. Hook an 8 oz. scale over the pin in the right ribbon spool shaft and pull horizontally at right angles to a line through the center of the pin and the center of the ribbon spool shaft. It should require 2-1/2 to 5 ozs. to start the ribbon spool shaft moving. The proper compression of the ribbon spool shaft spring can be obtained by means of the spring adjusting collar. Move the ribbon feed shaft to its right-hand position and adjust the left-hand spring compression in the same manner.

#### RIBBON REVERSE ARM SHAFTS ADJUSTMENTS (Figure 39)

The front ends of the right and left ribbon reverse arm shafts should clear their respective ribbon spool cups by .005" to .025" when the ribbon reverse arms are held against the brackets to make the clearance a minimum. To adjust, position the ribbon reverse arms on the ribbon reverse arm shafts by means of their set screws.

## RIBBON REVERSE ARM SHAFTS COLLAR ADJUSTMENTS (Figure 39)

Both right and left ribbon reverse arm shafts should have some end play, not more than .004". To adjust, position the collar on each shaft by means of its set screw. Locate the set screws so that they are easily accessible when the ribbon reverse arms are against the ribbon spool cups.

## RIBBON REVERSE PAWL LINKS ADJUSTMENT (Figure 40)

The ribbon reverse bail should clear both left and right-hand ribbon reverse pawls by .015" to .040" when the ribbon reverse bail is opposite the reverse pawls and the ribbon reverse arms are against the ribbon spool cups. When checking the .015" clearance between either ribbon reverse pawl and the ribbon reverse bail, the play in the ribbon reverse bail should be taken up in a direction to make the clearance a minimum. When checking for the .040" clearance, the play in the ribbon reverse bail should be taken up in a direction to make the clearance a maximum. To adjust, position the ribbon reverse arms by means of their set screws. The ribbon reverse pawl links should not bind on their shoulder screws.

#### RIBBON SPOOL SHAFT SLOT ADJUSTMENT

The ribbon spools should be held firmly in place on the ribbon spool shafts. To adjust, spread the prongs at the end of the shafts. See Figure 39. RIBBON FEED SHAFT SAFETY SPRING COMPRESSION (Figure 41)

With the main bail in its extreme upper position, slide the ribbon feed shaft to its left-hand position. Apply the push end of a 12 lb. scale to the upper end of the right ribbon reverse pawl, and push down vertically. It should require 3 to 5 lbs. to start the spring collar moving.

NOTE: Hold the ribbon feed shaft to prevent it from moving. Slide the ribbon feed shaft to its right-hand position and check the ribbon feed shaft left safety spring in a similar manner.

## RIBBON FEED SHAFT DETENT PLUNGER SPRING COMPRESSION (Figure 42)

Remove the ribbon reed pawl and check pawl. With the ribbon feed shaft in its left-hand position, apply the push end of a 12 lb. scale to the left end of the shaft and push in line with the shaft. It should require 1-1/2 to 3-1/2 lbs. to move the shaft to its right-hand position.

### RIBBON CHECK PAWL ADJUSTMENT

The upper end of the ribbon check pawl (Figure 43) should be 1/16" (plus or minus 1/64") below the lower surface of the pull bar guide. Adjust by means of the ribbon check pawl mounting screw. RIBBON CHECK PAWL SPRING PRESSURE (Figure 43)

With an 8 oz. scale hooked over the extreme lower end of the ribbon check pawl and pulled at right angles to the pawl, it should require 6 to 8 ozs. to start the pawl moving away from the ratchet. Make certain that the working edge of the pawl does not bind against a tooth on the ratchet when taking this pressure. Adjust by bending the pawl.

#### RIBBON FEED PAWL ADJUSTMENT

The ribbon feed pawl should be so positioned that the ratchet will be moved one or two teeth throughout a complete revolution of the main shaft. To adjust, position the ribbon feed pawl by means of its mounting screw.

RIBBON FEED PAWL SPRING PRESSURE ADJUSTMENT (Figure 43)

With the main shaft in its stop position and an 8 oz. scale booked over the extreme front edge of the ribbon feed pawl and pulled at right angles to the pawl, it should require 6 to 8 ozs. to start the pawl moving away from the ribbon feed ratchet. Make certain that the feeding edge of the pawl does not bind against a tooth on the ratchet when taking this pressure. To adjust, bend the ribbon feed pawl spring.

RIGHT AND LEFT RIBBON REVERSE PAWLS SPRING TENSION (Figure 41)

With the ribbon feed shaft in its left-hand position, hook an 8 oz. scale over the spring post on the left ribbon reverse lever and pull in line with the spring. It should require 2-1/2 to 3-1/2 ozs. to start the lever moving. Move the ribbon feed shaft to its right-hand position and check the right ribbon reverse pawl spring in the same manner.

LEFT FUNCTION PULL BAR SPRING BRACKET ADJUSTMENT (Figure 44)

With the main bail in its extreme downward position, hook an 8 oz. scale over the LETTERS pull bar, just below the hump, and pull horizontally at right angles to the pull bar. It should require 1 to 1-1/2 ozs. to start the pull bar moving. Adjust the position of the spring bracket by means of its lock nut to meet this requirement.

RIGHT FUNCTION PULL BAR SPRING BRACKET ADJUSTMENT (Figure 45)

With the main bail in its extreme upward position, hook an 8 os. scale over the code bar locking lever just above the No. 1 code bar and pull horizontally at right angles to the locking lever. It should require 5 to 6 ozs. to start the locking lever moving. Adjust by positioning the right function pull bar spring bracket by means of its lock nut.

BELL HAMMER ECCENTRIC SCREW ADJUSTMENT (Figure 46)

With the bell pull bar selected and the main bail lifted by hand to its extreme upward position, the end of the bell pull bar toe should align with the outer edge of the bell hammer eccentric screw and there should be .045" to .075" clearance between the bell hammer lip and the bell hammer post. Adjust the position of the bell hammer post for the pull bar toe and eccentric screw alignment and adjust the bell hammer eccentric screw to provide the specified clearance.

#### SIGNAL BELL ADJUSTMENT

The signal bell should be positioned so as to obtain the most satisfactory tone. It should also be positioned to provide at least .010" clearance between the bell and all brackets and screws, and at least .004" between the bell and the tape chute or platform. Adjust by means of its mounting screw.

## MAIN BAIL CAM CLUTCH TORQUE (Figure 47)

Remove the gear guard and the tape reel container. This torque should be taken with the motor running at least 10 minutes, and when the selector magnet is energized. Press down on the main bail so as to move the main bail roller away from its cam. With a 32 oz. scale hooked into the screw hole on top of the main bail cam and pulling at right angles to the radius, it should require a pull of 18 to 24 ozs. to start the cam moving opposite to its normal direction of rotation.

## SELECTOR CLUTCH TORQUE (Figure 48)

This torque should be measured after the motor has been running at least ten minutes with the selector cam sleeve stationary. Hook a 32 oz. scale to the selector cam sleeve stop arm. It should require a pull of 14 to 18 ozs. to hold the selector cam sleeve stationary. This clutch torque depends on the condition of the felt friction washers and the friction clutch spring. If difficulty is encountered in securing the specified torque, shims may be placed at the lower end of the friction clutch spring. The selector cam sleeve must be removed from the shaft in order to insert the shims. Shims are available under the following numbers:

96763	Shim	(.012")
96764	Shim	(.016")
96765	Shim	(.020*)

#### BELL-AND-BREAK CONTACT MECHANISM ADJUSTMENTS

#### DOUBLE-CONTACT MECHANISM

DETENT ARM SPRING TENSION (Figure 49)

Unhook the detent arm spring from the spring post and hook a 32 os. scale in the spring eye. It should require 18 to 22 ozs. to pull the spring to its position length. When taking this tension, the finger arm should be against its upper stop. Replace the spring.

## BELL HAMMER ADJUSTMENT (Figure 50)

With the finger arm against its lower stop, there should be some clearance, not more than .010", between the bell and the bell hammer. This clearance may be obtained by bending the bell hammer wire.

### CONTACT MOUNTING SCREWS ADJUSTMENT (Figure 50)

The contact arm should clear the ends of the contact guards by at least .020" when all of the play in the contact arm is taken up in a direction to make this clearance a minimum. This adjustment can be made by means of the contact mounting screws.

- 24 -(B-127)

#### CONTACT SPRINGS ADJUSTMENT

With the finger arm against the upper stop (See Figure 49), there should be a gap of .015" to .020" between the break contacts (left pair of contacts). Adjust the upper contact spring of these break contacts to obtain the clearance. Place the finger arm against its lower stop (See Figure 50). There should be a gap of .015" to .020" between the transmitter distributor contact springs (right pair of contacts), and the break contacts should be closed. Adjust, by bending, the transmitter distributor contact springs. Again place the finger arm in its upper position (See Figure 49), and recheck the break contacts gap. Under this condition, the transmitter distributor contacts should be closed. To adjust, bend the lower contact spring. 5.

BREAK SIGNAL CONTACT SPRING TENSION (Figure 50-A)

Place the finger arm against its lower stop. Place the push end of an 8 oz. scale vertically on the fibre extension of the lower contact spring just in front of the contact arm, and push downward. It should require 3 to 4 ozs. to break the contact.

#### SINGLE-CONTACT MECHANISM

The adjustments for the single contact bell and break mechanism are the same as those for the double contact mechanism with the exception of the Contact Springs Adjustment. This adjustment should read as follows:

CONTACT SPRINGS ADJUSTMENT FOR SINGLE CONTACT MECHANISM (Figure 50-B)

With the finger arm against the upper stop, adjust the upper contact spring so that there will be .015" to .020" clearance between the contacts.

> MECHANICAL END-OF-LINE INDICATOR ADJUSTMENTS (Located to the Right of the Right Hand Ribbon Spool Shaft)

### WORM SHAFT END PLAY

The worm shaft should be free to rotate, with a minimum amount of end play, when the worm shaft spring is detached from the contact bracket. Adjust by means of the worm shaft collar and set screw. See Figure 51.

## LAMP CONTACT ADJUSTMENT (Figure 51)

With the push end of an 8 oz. scale applied to the front contact spring near the contact point, it should require 3 to 4 ozs. to start the spring moving away from its stiffener. To adjust, remove the spring from the contact assembly and bend it.

There should be a gap of .015" to .025" between the contacts. Adjust the rear contact spring, by bending, to meet this requirement.

## CONTACT BRACKET ADJUSTMENT (Figure 52)

With the worm follower resting in the groove at the front end of the worm, the lamp contacts should be closed and there should be .010" to .020" clearance between the front lamp contact spring and the lower end of its stiffener. To adjust, position the contact bracket by means of its mounting screws.

### WORM FOLLOWER ADJUSTMENT

The lamp contacts should close, not sooner than with the 62nd operation of the printer and not later than the 67th operation when the printer is operated under power.

To adjust, rotate the main shaft to a position where the manual operation of the cam lever will advance the worm shaft ratchet one tooth at a time. With the worm follower in its rearmost position, operate the cam lever by pressing toward the left at its forward end until the pin on the worm follower just enters a thread on the worm. Continue to operate the cam lever 62 additional times. Then adjust the position of the release bail, by means of the sleeve and the adjusting bracket mounting screws, so that the contacts just close. Check the adjustment several times with the printer operating under power. See Figure 51.

WORM FOLLOWER SPRING TENSION (Figure 53)

Hook an 8 oz. scale over the end of the worm follower and pull approximately parallel to the spring, holding the release bail so that the follower pin is away from the worm. It should require 1-1/2 to 3-1/2 ozs. to move the worm follower to a point where it touches the rear contact spring insulator.

#### RELEASE BAIL SPRING TENSION (Figure 54)

Hook a 32 oz. scale over the edge of the release bail near the spring hole, and pull up. It should require 7 to 11 ozs. to start the bail moving.

FEED PAWL SPRING TENSION (Figure 55)

With the cam lever roller on the high part of the main bail cam, hook an 8 oz. scale over the end of the feed pawl at the spring hole, and pull in line with the spring. It should require 3 to 5-1/2 ozs. to start the feed pawl moving.

#### CAM LEVER SPRING TENSION (Figure 56)

With the cam lever roller on the low part of the main bail cam, hook a 64 oz. scale over the cam lever at the spring hole and pull in line with the spring. It should require 28 to 38 ozs. to start the cam lever moving.

> MECHANISM TO PREVENT PRINTING AND SPACING ON LOWER CASE BLANK ADJUSTMENTS

Substitute the following paragraph for the Spacer Locking Bail Spring

Tension on Fage 15.

"With an 8 oz. scale hooked in the locking bail spring eye, pulling upward, a tension of 7-1/2 to 8-1/2 ozs. should be required to stretch the spring to its normal position length."

## SPACE SUPPRESSION LEVER STOP ARM ADJUSTMENT (Figure 57-A)

With the printer in its stop position (pull bars held away from the code bars) and the carriage in its unshifted position, there should be .010" to .075" clearance between the lower edge of the space suppression lever and the upper edge of the blank pull bar projection. Adjust the space suppression lever stop arm, by bending, to meet this requirement.

SPACE SUPPRESSION LEVER ADJUSTMENT (Figures 57-B and 57-C)

- (1) With the blank combination set up and the carriage in the FIGURES position, rotate the main shaft until the blank pull bar moves into the path set up for it in the code bars. There should be .006" to .040" clearance between the rear edge of the space suppression lever and the blank pull bar.
- (2) Rotate the main shaft until the pull bars are resting against the code bars. The end of the space suppression lever should clear the vertical edge of the blank pull bar by .006" to .020" when the carriage is moved to a position to bring the space suppression lever opposite the pull bar.
- (3) The requirements given in (1) and (2) may be obtained by positioning the space suppression lever by means of the suppression lever mounting plate clamp screws. Both requirements should be checked before tightening the clamp screws.

## MECHANICAL MOTOR CONTROL MECHANISM WHICH FUNCTIONS ON UPPER CASE "H" ADJUSTMENTS

#### CONTACT LEVER BRACKET ADJUSTMENT

With the main bail roller on the high part of its cam, the contact lever should rest approximately in the middle of the upper end of the latch lever extension, and there should be .010" to .045" clearance between the side of the contact lever and the side of the space release pull bar. (See Figure 58 for location of parts.) To adjust, position the contact lever bracket by means of its mounting screws.

LATCH LEVER BRACKET EXTENSION ADJUSTMENT (Figure 58)

With the main bail roller on the high part of its cam and the contact lever resting against the main bail, there should be .015" to .030" clearance between the upper end of the latch lever extension and the lower latching surface of the contact lever. To adjust, loosen the latch lever extension clamping screws and set the extension approximately at the mid-point on its adjustable limits, then position the bell bracket extension by means of its mounting screws to meet the foregoing requirements.

## LATCH LEVER EXTENSION ADJUSTMENT (Figure 59)

With the carriage in the FIGURES position, the main bail roller on the high part of its cam, and the H type bar resting on the platen roll, the latch lever extension should overtravel the lower latching surface of the contact lever by .010" to .025". To adjust position the latch lever extension by means of its clamping screws, and recheck the Bell Bracket Extension Adjustment.

CONTACT LEVER SPRING TENSION (Figure 58)

With the main bail in its downward position, hook a 32 oz. scale under the end of the contact lever and pull up vertically. It should require 9 to 12 ozs. to start the lever moving.

LATCH LEVER SPRING TENSION (Figure 58)

With the main bail in its downward position, hook an 8 oz. scale over the latch lever at the spring eye, and pull horizontally. It should require 1 to 2 ozs. to start the lever moving.

OPERATING LEVER SPRING TENSION (Figure 58)

Hook an 8 oz. scale under the right edge of the operating lever and pull up vertically. It should require 1/2 to 1-1/2 ozs. to start the lever moving.

MOTOR CONTROL CONTACTS ADJUSTMENTS (Figure 60)

With the motor control contact guard removed and the main bail roller on the high part of its cam, the motor control contacts should meet the following requirements:

- The fibre insulator on the lower long contact spring should align with the head of the contact lever adjusting screw. To adjust, position the contact assembly by means of its mounting screws.
- (2) The lower short contact spring should be straight and should bear against its stiffener with a perceptible tension when the other contact springs are held off. To adjust, bend the lower short contact spring and stiffener.
- (3) With an 8 oz. scale hooked under the lower long contact spring at the contact and pulled up vertically, it should require 3/4 to 1-1/2 ozs. to separate the contacts with the upper long contact spring held off. To adjust, bend the lower long contact spring.
- (4) With an 8 oz. scale hooked under the upper long contact spring at the contact and pulled up vertically, it should require 1/2 to 1 oz. to start the fibre insulator on the upper long spring moving away from the lower long spring. When taking this reading, hold off the upper contact spring. To adjust, bend the upper long contact spring.

(5) With an 8 oz. scale hooked under the upper contact spring at the contact and pulling vertically upward, it should require 1 to 2 ozs. to start the spring moving away from the stiffener, and there should be .010" to .020" gap between the contacts of the two upper contact springs. To adjust, bend the upper contact spring and stiffener.

## CONTACT LEVER ADJUSTING SCREW ADJUSTMENT (Figure 61)

With the main bail raised by hand to its extreme upward position and the latch lever latched on the upper latching surface of the contact lever, there should be .008" to .015" space between the upper short contact spring and its stiffener. Adjust by means of the contact lever adjusting screw. Replace the motor control contact guard.

#### MAIN BAIL SPRING ADJUSTMENT

The printing blow, i.e., the force with which the type bars strike the platen, can be adjusted by means of the main bail spring adjusting screw. This adjusting screw is mounted just to the left of the upper clutch throw-out lever pivot screw, which is shown in Figure 1.

While the printer is printing, loosen the lock nut holding the main bail spring adjusting screw, and turn the screw in a counterclockwise direction until the printer starts to fail to print. Now turn this screw in a clockwise direction until a good clear copy is obtained without embossing the paper. Tighten the lock nut.

## KEYBOARD BASE ADJUSTMENTS

#### REMOVE THE KEYBOARD BASE PLATE

#### UNIVERSAL BAR PILOT SCREWS ADJUSTMENT - See Note (C)

The trip-off pawl should be approximately midway between the sides of the slot in the casting, and the universal bar should have some end play, not more than .010". Adjust by means of the universal bar pilot screws (See Figure 62 to location of parts).

## TAPE LEVER ADJUSTING CLAMP ADJUSTMENT (Figure 63) - See Note (C)

There should be a clearance of 1/4" (plus or minus 1/32") between the tape lever roller and the tape roller, with the locking pawl touching the front face of the bell hammer extension and the play of the bell hammer taken up in a direction away from the bell. To adjust, position the adjusting clamp by means of its clamping screw, making sure that the locking pawl bushing has no end play between the shoulder on the shaft and the adjusting clamp, when the clamping screw has been tightened.

TRIP-OFF PAWL STOP PLATE ADJUSTMENT (Figure 62) - See Note (C)

There should be .040" to .060" clearance between all key levers and the universal bar. Adjust by means of the trip-off pawl stop plate.

\*

NOTE (C) This requirement should be checked with the keyboard base plate removed.

GEAR GUARD ADJUSTMENT (Figure 64)

There should be some clearance, not more than .008", between the bell hammer extension and the bell operating post, when the bell hammer is held in its locked position by the locking pawl and the play is taken up to make this clearance a minimum. To adjust, remove the tape reel container and position the gear guard.

TAPE-OUT BELL ADJUSTMENT (Figure 65)

There should be .002" to .004" clearance between the bell hammer and the bell when the bell hammer is resting against the gear guard. To adjust, position the bell by means of its mounting screw.

BELL HAMMER EXTENSION STOP ADJUSTMENT (Figure 64) - See Note (D)

With the locking pawl engaging the bell hammer extension, there should be .020" to .040" clearance between the lower side of the bell hammer extension and the bell hammer extension stop. To adjust, position the bell hammer extension stop.

BELL HAMMER SPRING TENSION (Figure 64) - See Note (D)

Remove the tape lever and locking pawl springs. With the bell hammer resting against the gear guard, hook an 8 oz. scale at the spring hole and pull in line with the spring. It should require 3 to 5 ozs. to start the hammer moving. Replace the tape lever spring.

TAPE LEVER SPRING TENSION - See Note (D)

Remove the locking pawl spring. Hook an 8 oz. scale at the locking pawl spring hole and pull toward the rear of the base at right angles to the front edge of the pawl. With the bell operating post rotated out of the way, it should require 3 to 4-1/2 ozs. to cause the locking pawl to just butt against the bell hammer extension. Replace the locking pawl spring.

LOCKING PAWL SPRING TENSION (Figure 66)

With the locking pawl resting against the front face of the bell hammer extension and the tape lever held down, hook an 8 oz. scale at the spring hole and pull in line with the spring toward the front. It should require 1/2 to 1-1/2 ozs. to start the pawl moving.

LOCK LOOP SPRING TENSION (Figure 67)

Rotate the transmitting shaft until the lock loop roller is resting on the low part of its cam. Hook an 8 oz. scale under the lock loop spring hole and pull in line with the spring. It should require 4 to 5 ozs. to start the lock loop moving.

\* \* \*

NOTE (D) These requirements should be checked with the tape reel container removed.

# TRANSMITTING CAM CYLINDER ADJUSTMENT (Figure 68)

The transmitting cam cylinder should have some end play, not more than .002". Adjust the bushing in the rear bearing bracket by means of its adjusting nuts.

## LOCKING LEVER SHAFT ADJUSTMENT (Figure 67)

With all the contact levers on the high part of their cams and the locking levers in their spacing position, there should be some clearance, not more than .010", between the locking levers and the contact levers when the locking levers are pressed downward by hand to make the clearance a minimum. Adjust the position of the locking lever shaft to meet this requirement.

### LOCKING LEVER TRAVEL (Figure 67)

With the LETTERS key depressed and the lock loop roller resting on the low part of its cam, there should be at least .010" clearance between any locking lever finger and the lock loop blade. Make a similar check when the BLANK key is depressed. This adjustment can be made by loosening the four screws which hold the main bracket and shifting the bracket.

## TRANSMITTING CONTACTS GAP ADJUSTMENT (Figure 67)

With each contact lever on the high part of its cam, the contact gap should be .020" to .025". Bend the shorter contact spring to obtain this clearance. START-STOP contact gap may be .015" to .025".

#### TRANSMITTING CONTACT SPRING PRESSURE (Figure 69)

With each contact lever in the low part of its cam, it should require a pressure of 4-1/2 to 5-1/2 ozs. to open the contacts when pressing against the spring above the contact point. To adjust, bend the longer contact spring. Recheck the contact gaps adjustment.

## CLUTCH THROW-OUT LEVER ADJUSTMENT (Figure 62)

There should be .005" to .015" clearance between the clutch teeth when the clutch is fully disengaged. To adjust, position the clutch throw-out lever by means of shims placed between the throw-out lever post and the bracket.

## CLUTCH SPRING COMPRESSION (Figure 70)

It should require 9 to 12 ozs. to separate the clutch teeth. Hook a 32 oz. scale to the driven member projection and pull directly in line with the shaft.

## LOCK LOOP ROLLER ADJUSTMENT

NOTE: This adjustment applies only to those keyboards equipped with lock loops having an elongated hole for the roller pivot screw. Rotate the keyboard shaft until the clutch teeth are disengaged. Press the lock loop roller against the cam to fully disengage the clutch teeth and position the locking levers directly below the lock loop blade to make the clearance a minimum. Under these conditions, there should be .008" to .015" clearance between the lock loop blade and the locking lever having the least clearance. To adjust, position the roller pivot screw by means of its elongated mounting hole.\* (See Figure 67 for location of parts.)

(\*) On some keyboards an eccentric roller pivot screw is used which provides extra adjusting margin. In these cases the shoulder screw should be mounted with the high part of its eccentric extending toward either end of the slot in the lock loop, depending upon which direction the additional margin of adjustment is required.

INTERMEDIATE PAWL ECCENTRIC ADJUSTMENT (Figure 62)

There should be .050" to .060" clearance between the trip-off pawl and the intermediate pawl, when the trip-off pawl is resting against the stop plate and the intermediate pawl is against its eccentric. Adjust by means of the intermediate pawl eccentric.

#### CLUTCH THROW-OUT LEVER ECCENTRIC ADJUSTMENT

With the transmitter shaft in the stop position and the clutch fully disengaged, hold the clutch throw-out lever against the driven clutch member. Under this condition the intermediate pawl should be held firmly between the clutch throw-out lever and the intermediate pawl eccentric. See Figure 62.

NOTE: On some units the driven clutch member has a tendency to settle back when the clutch throwout lever is held against it, slightly altering the stop position. On units where this condition prevails, the clutch throwout lever eccentric adjustment shall be made and checked after this settling has occurred. Adjust by means of the eccentric.

#### TRIP-OFF PAWL ECCENTRIC ADJUSTMENT

Hold the clutch throwout lever against the high part of the cam on the driven clutch member, and at the same time hold the clutch throwout lever eccentric against the clutch throwout lever. Under this condition, the point on the trip-off pawl should clear the point on the intermediate pawl by not more than .004" when a key lever is being depressed. Adjust by means of the trip-off pawl eccentric. (See Figure 62 for location of parts.)

NOTE: When making this adjustment, the high part of the eccentric should be positioned toward the rear of the keyboard.

#### CLUTCH THROWOUT LEVER SPRING TENSION

With the clutch teeth engaged and the clutch throwout lever resting against the low part of the driven clutch member, hold the intermediate pawl against its eccentric; at the same time hook an 8 oz. scale over the throwout lever just above the spring hole and pull in line with the spring. It should require 1-1/2 to 2-1/2 ozs. to start the throwout lever moving. (See Figure 62 for location of parts.) - 32 -(B-127)

## TRIP-OFF PAWL SPRING TENSION (Figure 71)

Unhook the trip-off pawl spring. With an 8 oz. scale hooked in the spring eye, it should require 2-3/4 to 3-3/4 ozs. to pull it to its normal position length. Replace the spring.

THE FOLLOWING ADJUSTMENT APPLIES ONLY TO THOSE KEYBOARD BASES EQUIPPED WITH REPEAT ON SPACE MECHANISM:

#### REPEAT SPACE ROD ADJUSTMENT

There should be .010" to .020" clearance between the clutch throwout lever and the high part of the throwout cam, with the spacer bar held depressed by applying pressure at approximately the center of the spacer bar until the loop rests lightly on the rubber stop. Adjust the repeat space rod by means of its adjusting nuts. (See Figure 62).

#### REPEAT SPACE ROD BRACKET ADJUSTMENT

The repeat space rod bracket should be adjusted so that the face of the section with the elongated hole is parallel to the rear edge of the rear transmitter bracket in order to assure free movement of the repeat space rod. The repeat space rod end should engage the intermediate pawl at least 1/2 the thickness of the pawl when the space bar is fully depressed.

#### TAFE GUIDE TUBE ADJUSTMENT

The right-hand end of the tape guide tube should be approximately 1/32" from the outside edge of the keyboard. Adjust the position of the tape guide tube by means of the adjusting clamp.

#### JACK SPRING TENSION

A pressure of 1-1/2 to 3 lbs. thould be required to open the jack to the extent of .030" when pressure with a 12 lb. scale is applied to the curved portion of the jack. To adjust, remove and bend the jack spring.

#### TYPING UNIT SLIP CONNECTIONS SPRING TENSION ADJUSTMENT

The slip connection springs should be adjusted so that there is a space of 7/16" to 15/32" between a line across the inside of the two mounting posts of the slip connection block and the high part of the crimped portion of the two end springs that make contact with the terminal screws on the typing unit, when measured with a 6" scale held against a post and parallel to the front edge of the keyboard casting. There should be some clearance, not more than .015", between the inner springs and a straight edge placed against the crimped part of the two end springs. Adjust the slip connection springs by bending.

KEY LEVER SPRING ADJUSTMENT (Figure 72) - See Note (C)

The opening between the ends of all key lever springs, excepting the spacer key lever spring, should measure 1-3/16". The spacer key lever spring should measure 1-15/16" across the opening between the ends. Adjust by bending.

THE FOLLOWING ADJUSTMENTS APPLY ONLY TO THOSE KEYBOARD BASES EQUIPPED WITH REPEAT ON S MECHANISM:

NOTE (C) These adjustments should be made with the keyboard base cover plate removed.

## REPEAT SPACE ROD SPRING TENSION (Figure 73)

in.

Hold the repeat yoke unoperated. Hook an 8 oz. scale over the repeat space rod, just below the spring, and pull horizontally toward the front of the keyboard. It should require 3/4 to 1-3/4 ozs. to start the rod moving.

REPEAT YOKE LUG ADJUSTMENT (Figure 74) - See Note (C)

There should be .010" to .020" between the clutch throw-out lever and the high part of the throw-out cam when the S key lever is depressed until it bottoms in the selector bar slots. Adjust by means of the lug mounting screws on the repeat yoke.

#### CONTROL RELAY ADJUSTMENTS

- (A) For BREAK operation, the control relay should be adjusted to meet the following requirements: - See Note (C)
  - There should be a gap of .005" to .015" between the outer spring contact and the middle spring contact, when the plunger is held operated. (See Figure 75) Adjust by bending the outer spring.
  - (2) There should be a gap of .025" to .030" between the inner spring contact and the middle spring contact, when the plunger is held operated. Adjust by bending the inner spring.
  - (3) A pull of 5 to 6 ozs. should be required to cause the middle spring to break contact with the inner spring, when an 8 oz. scale is hooked over the middle spring at the side of the contact and pulled horizontally at right angles to the spring. Adjust by bending the middle spring and recheck adjustment (2).
- (B) For MAKE operation, the control relay should be adjusted to meet the following requirements: - (Figure 76) See Note (C)
  - (1) With the magnet plunger held operated (See Figure 76), a pull of 12 to 16 ozs. should be required to cause the outer spring to just break contact with the middle spring when a 32 oz. scale is hooked over the end of the outer spring and pulled horizontally at right angles to the spring. Adjust by bending the outer spring.
  - (2) There should be .030" to .040" gap between the contacts of the inner and middle spring, when the magnet plunger is held operated. Adjust by bending the inner spring.
  - (3) A pull of 1-1/2 to 2 ozs. should be required to cause the middle spring to just break contact with the inner spring when an 8 oz. scale is hooked over the middle spring at the side of the contact and pulled horizontally at right angles to the spring. Adjust by bending the middle spring and recheck adjustment (2).

NOTE (C) These requirements should be checked with the keyboard base plate removed.

The value of the operating current for the control relay should be between .050 and .060 amperes when adjusted for either MAKE or BREAK operation.

- 34 -(B-127)

MECHANICAL MOTOR CONTROL MECHANISM ADJUSTMENTS (Functions on Upper Case H)

## START MAGNET CORE ADJUSTMENT - See Note (C)

With the start magnet armature held in the operated position, there should be not more than .004" clearance between the start magnet armature and the shorter core. Adjust by varying the number of shims between the start magnet cores and the yoke. (See Figure 77 for location of parts.)

STOP MAGNET CORE ADJUSTMENT - See Note (C)

With the stop magnet armature held in the operated position, there should be not more than .004" clearance between the stop magnet armature and the stop magnet core or yoke. Adjust by varying the number of shims between the rear end of the stop magnet core and the yoke. (See Figure 77 for location of parts.)

# START MAGNET BRACKET ADJUSTMENT (Figure 77) - See Note (C)

With the start magnet armature held operated and the stop magnet armature held so that its inner edge aligns with the outer shoulder on the start magnet armature, there should be .004" to .008" clearance between the end of the stop magnet armature and the start magnet armature. To adjust, position the start magnet bracket by means of its mounting screws.

STOP MAGNET BRACKET ADJUSTMENT (Figure 78) - See Note (C)

With the stop magnet armature held in the operated position by its latch, there should be .004" to .008" clearance between the stop magnet armature and the outer face of the yoke when measured at the closest point. To adjust, remove the resistor and position the stop magnet bracket by means of its mounting screws. Replace the resistor.

ARMATURE STOP ADJUSTMENT (Figure 77) - See Note (C)

With the stop magnet armature against the armature stop, there should be .070" to .080" clearance between the stop magnet armature and the outer face of the yoke. Adjust the armature stop by means of its mounting screws.

LATCH BACKSTOP SCREW ADJUSTMENT (Figure 79) - See Note (C)

With the stop magnet armature held in the operated position by the notch in the start magnet armature, there should be some clearance, not more than .008", between the high part of the latching surface of the latch and the end of the slot in the stop magnet armature. Adjust by means of the latch backstop screw.

\* \*

NOTE (C) These requirements should be checked with the keyboard base plate removed.
STOP MAGNET ARMATURE SPRING TENSION (Figure 78) - See Note (C)

With the stop magnet armature held operated and the stop magnet armature spring unhooked, hook a 32 oz. scale in the spring eye and pull the spring to its normal position length. This requirement should be 14 to 16 ozs. Adjust by means of the adjustable spring post.

START MAGNET ARMATURE SPRING TENSION (Figure 78) - See Note (C)

With the stop magnet armature held against its pole faces, hook an 8 oz. scale over the end of the spring post on the start magnet armature and pull horizontally in line with the spring. It should require 3-1/2 to 4-1/2 ozs. to start the armature moving.

LATCH SPRING TENSION (Figure 77) - See Note (C)

With both armatures released, hook an 8 oz. scale over the latch between the spring and the shoulder and pull horizontally. It should require 1-1/2 to 2-1/2 ozs. to start the latch moving.

INNER CONTACT ASSEMBLY ADJUSTMENTS (Figure 79) - See Note (C)

- (1) With the stop magnet armature held in the operated position by the notch in the start magnet armature, hook an 8 oz. scale over the spring alongside the insulator and pull at right angles to the spring. It should require 1-1/2 to 2 ozs. to start the long spring moving away from the stop magnet armature. To adjust, remove the outer contact assembly, if necessary, and bend the long contact spring.
- (2) With the stop magnet armature held in the operated position by the notch in the start magnet armature, there should be a gap of .015" to .020" between the contacts. To adjust, bend the short contact spring.

OUTER CONTACT ASSEMBLY ADJUSTMENTS (Figure 80) - See Note (C)

- NOTE: The stop magnet armature should be held operated by the notch in the start magnet armature during each of the following adjustments:
  - (1) The short contact spring nearest the armature should bear against its stiffener with perceptible pressure when the other springs are held off. Adjust by bending the short contact spring.
  - (2) There should be some clearance, not more than .006", between the insulator on the long contact spring and the stop magnet armature. Adjust by bending the spring stiffener nearest the armature. Recheck (1).
  - (3) With an 8 oz. scale hooked over the long contact spring nearest the stop magnet armature at the contact point and pulled at right angles

\* \* \*

NOTE (C) These requirements should be checked with the keyboard base plate removed.

to the spring, it should require 1 to 1-1/2 ozs. to separate the contacts when the long contact spring farthest from the stop magnet armature is held away. Adjust by bending the long contact spring nearest the armature.

- 36 -(B-127)

- (4) The long contact spring farthest from the stop magnet armature should bear lightly against the long contact spring nearest the stop magnet armature. Adjust by bending the long contact spring farthest from the armature.
- (5) Hook an 8 oz. scale over the short contact spring farthest from the stop magnet armature at the contact and pull at right angles to the spring. It should require 1 to 2 ozs. to start the spring moving away from its stiffener. Adjust by bending the short contact spring and stiffener. Recheck adjustment (2).

REPLACE THE KEYBOARD BASE PLATE

#### GOVERNOR ADJUSTMENT

REMOVE THE GOVERNOR ADJUSTING BRACKET, BRUSH SPRING PLATE, TARGET, GOVERNOR COVER, AND GOVERNOR.

SPEED ADJUSTING WHEEL FRICTION WASHER SPRING TENSION ADJUSTMENT (Figure 81)

Turn the adjusting wheel so that the tension on the governor contact is 13 to 14 ozs. Measure by hooking a 32 oz. scale over the contact spring arm next to the contact and pulling parallel to the speed adjusting spring.

To measure the pressure of the speed adjusting wheel friction washer, insert a bank pin in the leather rim (radially), and hook a 32 oz. scale over the pin at the periphery of the adjusting wheel and pull at right angles to the radius. It should require 16 to 24 ozs. to start the wheel moving. To adjust this tension, remove the friction washer and bend the large projections.

GOVERNOR BRUSH SPRING REQUIREMENT (Figure 82) (Collector Ring Governor Only)

It should require 3 to 4 ozs. pressure, using an 8 oz. scale, to depress a brush spring to its required position; that is, to within .015" to .050" of the brush holder. The pigtails should be soldered to both the carbon brush and the brass inserts of the brush screws. Replace the governor.

# GOVERNOR SHIMS ADJUSTMENTS

There should be at least .006" clearance between the adjusting lever wearing strip and the adjusting wheel when the adjusting wheel is opposite the wearing strip and the play of the armature is taken up in a direction to make this clearance a minimum by overcoming the armature end thrust spring. To adjust, install shims on the armature shaft between the governor hub and the motor end frame casting if necessary. See Figure 85 for location of parts.

# SPEED ADJUSTING LEVER STOP PLATE ADJUSTMENT

There should be .006" to .050" clearance between the adjusting lever

wearing strip and the governor shell when the speed adjusting lever is held against the stop plate. To adjust, loosen the stop plate mounting screws and position the plate. Tighten the screws. See Figure 85 for location of parts.

GOVERNOR BRUSH POSITION (Collector Ring Governor Only)

The governor brushes should ride in the center of the collector rings and should project .015" to .050" beyond the brush holder. Elongated holes are provided in the brush holder bracket to allow for this adjustment. See Figure 82 for location of parts.

INNER AND OUTER DISC CONTACT SPRING ADJUSTMENT (Figure 83)

- NOTE: These requirements should be checked with the governor adjusting bracket, brush spring plate, target and governor cover removed.
  - The distance from the inside surface of the governor cover to the highest point on the contact springs should be 25/32" to 27/32".
  - (2) Place a D (89955) socket wrench over the nut (located in the center of the governor cover) that is used to hold the contact springs in place. With a 6" scale, measure the radial distance from the vertical surface of the wrench to the point where the scale touches the curved surface of the inner disc contact spring. This should be 17/32" to 19/32".
  - (3) In a similar manner, measure the distance from the wrench to the point of contact on the outer disc contact spring. This should be 7/16" to 1/2".

These requirements may be obtained by bending the contact springs. Replace the governor cover, target, and brush spring plate.

GOVERNOR BRUSH SPRING PLATE BRACKET ADJUSTMENT

The governor brush spring plate bracket should be set so that:

- A line established by the center of the outer disc and the center of one of the brushes should pass through some portion of the other brush. (Figure 84).
- (2) The surface of the brush spring plate bracket, on which the brush spring plate is mounted, aligns with the outer surface of that part of the governor cover on which the target is mounted. (Figure 85).
- (3) The bracket is parallel to the edge of the motor base plate. Adjust the brush spring plate bracket by means of its enlarged mounting holes. See Figure 85 for location of parts.

GOVERNOR BRUSH SPRING PRESSURE (Figure 85)

(A) INNER DISC BRUSH SPRING Hook an 8 oz. scale over the inner spring just in front of the carbon contact brush. Pulling horizontally away from the motor, it should require 4-1/2 to 5-1/2 ozs. to start the brush moving away from the disc.

(B) OUTER DISC BRUSH SPRING

Apply the push end of an 8 oz. scale against the outer brush spring, just in front of the carbon contact brush. Pushing horizontally toward the motor, it should require 4-1/2 to 5-1/2 ozs. to start the brush moving away from the disc.

To obtain the correct brush spring pressure, remove and bend the brush springs. When the springs are replaced and the pressure obtained, take care that the contact brushes lie flat against their respective discs, and that the outer edges of the brushes are either flush with, or not more than 3/64" inside, the outer edges of the discs.

NOTE: If necessary, level off the brushes by passing a piece of No. 0000 sandpaper between the brush and the disc.

REPLACE THE GOVERNOR ADJUSTING BRACKET

GOVERNOR ADJUSTING BRACKET ADJUSTMENT (Figure 85)

The adjusting surface of the governor adjusting bracket should clear the speed adjusting wheel by .020" to .060". Bend the governor adjusting bracket if necessary to secure this clearance.

#### SYNCHRONOUS MOTORS

#### STARTING SWITCH ADJUSTMENTS

- NOTE: These requirements should not be checked unless there is reason to believe the starting switch is out of adjustment.
  - (1) Remove the motor from the base and remove the motor fan and pinion.
  - (2) Remove the switch end shield screws and the switch commutator mounting screws, also the switch end shield.
  - (3) Pull out the rotor until the brush holder spring is accessible and remove the spring.
  - (4) Spring tension for 50 and 60 cycle motors should be 1-1/2 to 2-1/2 ozs., and 3 to 3-3/4 ozs. respectively, when extended to a length of 5 inches, using an 8 oz. scale.
  - (5) The brush holders should be mounted by means of the center set of mounting holes and should be free.
  - (6) The brush holder stop pins should be safely within the holes of the fibre disc when all the play in the brush holders has been taken up to make the engagement of the pins with the disc a minimum.
  - (7) Replace the brush holder spring, making certain that the spring eyes are fully engaged with each other.

(8) Replace the switch commutator screws and tighten the two screws alternately, a little at a time, until both screws are tight.

- 39 - (B-127)

- (9) Replace the switch end shield screws, using the same precaution in tightening as above.
- (10) Apply the push end of a 12 lb. scale against the fan end of the shaft and push parallel with the shaft. It should require at least 7 lbs. pressure to start the shaft moving.
- (11) Replace the motor fan and pinion. Replace the motor unit on the base and check the motor plate adjustment.

Same

#### LUBRICATION

The oil and grease specified in the supplement furnished with this bulletin should be used to lubricate the Model 14 printer.

Unless otherwise specified, one or two drops of oil at each of the places indicated will be sufficient. Use oil for lubrication at all of the places listed below, except where the use of grease is specified.

Oil both loops of all helical springs that exert a nominal tension of less than 2-1/2 pounds.

Apply grease to both loops of all helical springs that exert a nominal tension of 2-1/2 pounds or more.

#### TYPING UNIT

- (1) Stop lever, trip latch, trip latch bell crank, and trip latch plunger of range finder assembly.
- (2) Selector cam sleeve drop of oil on each cam peak.
- Locking cam felt oiler saturate.
- (4) Pivots of locking lever and selector levers.
- (5) Selector sword bearings drop oil through rear end of slots in separator plates.
- (6) Selector "T" levers pivots and all points of contact.
- \*(6A) Selector Arm 2 pivot screws, 2 sword contact points, locking tip and detent.

(\*) On HOLDING TYPE SELECTOR only.

- (7) Locking wedge.
  (8) Code bars at posts.
- (9) Armature bearings very sparingly.
- (10) Main shaft remove rear screw of orientation plate and swing plate to expose top of main shaft. Fill shaft through hole in center of retaining disc. Wipe excess oil off top of retaining disc.
- NOTE: In printers not equipped with drilled main shafts, lubricate the main shaft clutch and sleeve as follows:

Oil liberally through the two opposite oil holes in sleeve just above the main shaft gear. Also squirt oil liberally on top of ball bearing just above the clutch. This oil will work down through the groove in the sleeve, oiling the clutch and the sleeve.

- (11) Selector clutch felt friction washers pry the driving discs apart with screw driver and saturate felts with oil. Do this at two diametrically opposite places at both top and bottom felt washers.
- (12) Clutch throw-out lever 2 pivots.
- (13) Main bail cam clutch saturate felt washer by applying oil between edge of disc and main shaft gear. A drop of oil should be applied through the spring to each disc prong.
- (14) Main bail cam prongs apply oil through spring. Swing motor back.
- (15) Main bail roller oil, grease, oil.
- (16) Main bail plunger fill oil cup.

# - 41 - (B-127)

- (17) Main bail lever fill oil cup just above typing unit terminal block. Also oil end of lever in main bail plunger.
   (18) Main bail fill success with sill and such days of sill an tax of
- (18) Main bail fill groove with oil and put drop of oil on top of square vertical guide post.
- (19) Pull bars one drop of oil on top of each pull bar.
- (20) Type bar gears pull each type bar down against platen. Put drop of oil on top of type bar gear at rear of segment slot.
- (21) Ribbon feed ratchet and ribbon feed gears drop of oil on teeth.
- (22) Ribbon feed shaft detent plunger.
- (23) Ribbon feed shaft 2 oil holes.
- (24) Ribbon feed lever oil hole.
- (25) Ribbon feed lever roller.
- (26) Ribbon spool shafts 2 bearings each.
- (27) Hibbon reverse pawls and links 4 bearings each side of printer.
- (28) Ribbon reverse shafts 2 bearings each.
- (29) Tape feed roll oil hole.
- (30) Shift rocker and shift rocker lever 2 pivot bearings.
- (31) Pull bar lock-out lever pivot and 2 rollers.
- (32) Signal bell hammer pivot.
- (33) Carriage locking pawl 1 pivot bearing.
- (34) Spacer locking bail 2 pivots.
- (35) Spacer locking pawl 1 pivot bearing.
- (36) Platen shaft 4 bearings.
- (37) Platen guide.
- (38) Spacer shaft 2 bearings and gear. The rear bearing may be oiled from the rear of the printer.
- (39) Spacer detent lever pivot and roller.
- (40) Spacer operating lever and roller.
- (41) Spacer feed pawl.
- (42) Motor bearings two ball oilers use grease according to instructions contained in the supplement furnished with this bulletin, or one drop of oil in each ball oiler.
- (43) Keyboard driving gears 2 oil cups.
- (44) All spring anchors.

Grease should be applied to the following:

- (1) Five large gears at right rear of typing unit.
- (2) Main bail adjusting screw end of screw.
- (3) Each anchor for main bail spring, spacer lever spring, and spacer detent lever spring.
- (4) Code bar locking lever where it bears on main bail.
- (5) Trace of grease on surface of each cam of the transmitting cam sleeve.
- (6) Ribbon feed shaft detent.
- (7) Clutch throw-out lever end of lever on camming surface.

Typing units equipped with any of the following mechanisms should also be lubricated at the places specified:

## BELL AND BREAK CONTACT MECHANISM ADJUSTMENTS

- (1) Finger arm, detent arm, and contact arm pivots.
- (2) Extension of detent arm in finger arm fork.

- 42 -(B-127)

# MECHANICAL END-OF-LINE INDICATOR MECHANISM

- (1) Worm shaft and release bail 2 bearings each.
- (2) Feed pawl.
- (3) Cam lever roller.

Grease should be applied to:

Worm shaft, detent drag spring, feed ratchet, and cam lever roller surface.

SUPPRESSION OF PRINTING AND SPACING ON LOWER CASE OF BLANK MECHANISM

(1) Space suppression lever - 2 bearings.

MOTOR CONTROL ON UPPER CASE "H" MECHANISM

(1) Contact lever, latch lever, operating lever - 2 bearings each.

After lubricating the typing unit, excess oil should be wiped off the following:

- (1) Magnet armature and cores. This may be done by inserting printer tape between armature and cores.
- (2) Type bar segment.
- (3) Printer base.

# KEYBOARD

- (1) Keyboard shaft bearings 2 oil cups.
- (2) Driven clutch 2 drops of oil through coils of spring.
- (3) Intermediate pawl pivot.
- (4) Trip-off pawl pivot and surface bearing on trip-off pawl eccentric.
- (5) Clutch throw-out lever 2 bearings.
- (6) Lock loop 2 bearings.
- (7) Lock loop roller.
- (8) Tape lever drop of oil either side of bearing.
- (9) Tape bell hammer 2 pivots.
- (10) Locking levers 5 bearings.
- (11) Contact levers one drop of oil on side of each lever placed so that the oil will run down on pivot.
- (12) Spacer bar 4 pivots and rivet for spacer key lever.
- Tip keyboard up on back. Remove base plate.
- (13) Universal bar 2 pivots.
- (14) Selector bar rollers 1 pivot each.
- (15) Selector bars at each guide bracket.
- (16) Key levers drop of oil on each key lever just in front of selector bars.
- (17) Rear key lever bearing drop of oil on bearing rod at four equidistant points.
- (18) Repeat space rod at bearing points and points of contact.
- (19) Keyboard gear grease.
- (20) Cams apply light film of grease to surface of cams.

On keyboards equipped with motor control on upper case of "H" mechanism, oil the following very sparingly:

- Stop magnet armature.
   Start magnet armature.
   Latch.

i.e.i

.

Apply grease to the keyboard gear.

SEPARATOR PLATE -



FIGURE I









FIGURE 4

























SIL







ni Lineacht























































FIGURE 41























FIGURE 50



FIGURE 51





FEED PAWL SPRING



































FIGURE 68

















2-3/4 TO 3-3/4 OZS. WHEN PULLED TO ITS POSITION LENGTH

TRIP-OFF PAWL SPRING

KEYLEVER SPRING

























1970 A. 19



FIGURE 78

















FIGURE 85

	5		•	5.	1.6		8	۲	•				•	•	1		•								•							
	4			•	•		•	•		_	•	•	÷	•	•	•			•				•		۲				•			•
		+	-	-	-		-	-	-	-	-	4		-	-	-	-	•				٠	•		•	•					۲	•
	3										-		-	-		-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	~
	FEED HOLES	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
	2			•	L.,			•		•	•	•	•				•															
	1	•	•		۰	•	۲				•	۰	-		1			۰		٠		•		•	•	•	•					
	LOWER CASE	A	в	¢	D	E	F	G	н	1	J	к	L	м	N	0	P	Q	R	5	т	U	۷	w	x	Y	z	BLAN	C.R.	Ľ,	92	LTR.
	No. of Contraction	-	÷	•	9	-	÷	a	~	0	-	1	/	•	,	э	90	1	4	4	D	1	;	2	1	6		U	$\leq$	Ξ	ACE	SE
CASE	COMMUNICATIONS	1-	2		0	1	1	8	£	8		1	1	F-	-		1	-	-	~	-	-	W	6	1	0	7	-	N	-		t
UPPER	WEATHER SYMBOLS	11	0	0	1	3	+	1	1	8	1	-	1		(D)	9	ø	1	4	A	5	7	(m)	2	1	6	4		17	Ξ	T	1.1.1