TELETYPE CORPORATION

MODEL 40/3

Sets & Stations

with 9140 STATION CONTROLLER

INSTALLATION MANUAL 395

©1980 by Teletype Corporation
All rights reserved
Printed in U.S.A.

On the following page is a list of Teletype Corporation Product Service locations which provide maintenance service and repair on all Teletype Corporation products. For more information call toll free (US 800-323-4226) (IL 800-942-4192) 7:30 A.M. – 4:00 P.M. CST.

In addition, Teletype Corporation provides Customer Technical Training at its headquarters at 5555 W. Touhy Avenue, Skokie, IL in the northwest suburban area of Chicago. The training covers the installation, maintenance and repair of all Teletype Corporation products. Arrangements can also be made for training to be conducted at customer-selected field sites.

For information about class schedules, enrollment, tuition, on-site training or any special training needs, please contact:

Customer Technical Training Center
Teletype Corporation
5555 W. Touhy Avenue
Skokie, Illinois 60077
Telephone (312) 982-2940
TLX 25-4051
TWX 901-223-9611

SERVICE CENTERS

ALABAMA	BIRMINGHAM	236 COMDOR CIRCLE, SUITE 1113, 35209-6302
ARIZONA	PHOENIX	2113 S. 48TH ST., SUITE 104, TEMPE, AZ 85282
	TUCSON	2500 E. BROADWAY BLVD., SUITE 220, TUCSON, AZ 85705
CALIFORNIA	LOS ANGELES	9480 SHELLA CITY OF INDUSTRY, 91748
	OAKLAND	7355 EDGEWATER, SUITE C, OAKLAND, CA 94621
	ORANGE COUNTY	11562 KNOTT AVE., SUITE A, LAGUNA BEACH, CA 92641
	SACRAMENTO	4221 NORTHGATE BLVD, SACRAMENTO, CA 95834
	SAN DIEGO	9245 SKY PARK COURT, SUITE 100, SAN DIEGO, CA 92123
	SAN JOSE	3288 KIFER RD., SANTA CLARA, CA 95051
	VENTURA COUNTY	2995 LAVERY COURT, SUITE 1, NEWBURY PARK, CA 91320
COLORADO	DENVER	5995 GREENWOOD PLAZA BLVD., GREENWOOD VILLAGE, COLORADO SPRINGS, CO 80907
	● DENVER	1999 BROADWAY, SUITE 2105, DENVER, CO 80202
CONNECTICUT	HARTFORD	RT. 66 & 167, MIDDLEFIELD, CT 06455
DIST. OF COLUMBIA	LORTON, VA	9999 SEVEN VA INDUSTRIAL AVENUE, SUITE 900-J, LORTON, VA 22079
FLORIDA	FT. LAUDERDALE	6850 N. W. 20TH AVE., FT. LAUDERDALE, FL 33309
	JACKSONVILLE	7620 ROUTH 4TH STREET, SUITE 100, JACKSONVILLE, FL 32211
	MIAMI	7215 NW 19TH ST., SUITE 5, MIAMI, FL 33126
	ORLANDO	102 LIVE OAKS BLVD, CASSELBERRY, FL 32707
	TAMPA	5302 W. LAUREL ST., SUITE 100, TAMPA, FL 33607
GEORGIA	● ATLANTA	2970 PEACHTREE ROAD, NW, SUITE 780, ATLANTA, GA 30305
ILLINOIS	● CHICAGO NORTH	2330 EASTERN AVE, ELK GROVE VILLAGE, IL 60007
	● CHICAGO SOUTH	2800 21ST AVE., BROADVIEW, IL 60153
INDIANA	INDIANAPOLIS	6240 LAS PAS TRAIL, INDIANAPOLIS, IN 46268
IOWA	DES MOINES	6200 SOUTHVIEW DRIVE, WEST DES MOINES, IA 50266
KANSAS	KANSAS CITY	9393 W. 110TH ST., OVERLAND PARK, KS 66211
LOUISIANA	NEW ORLEANS	9036 JEFFERSON HWY., NEW ORLEANS, LA 70123
MARYLAND	BALTIMORE	7240 PARKWAY DRIVE, SUITE 110, HANOVER, MARYLAND, MARYLAND 21076
MASSACHUSETTS	BOSTON	121 FLANDERS RD., E. BOX 366, WESTBORO, MA 01581
MICHIGAN	DETROIT	12616 FARMINGTON RD., LIVONIA, MI 48150
	GRAND RAPIDS	3981 LEE HILLDR. NE, KALAMAZOO, MI 49001
	LANSING	5800 S. PENNSYLVANIA AVE., LANSING, MI 48911
MINNESOTA	● MINNEAPOLIS	2905 CORPORATE PLACE, CHANHASSEN, MN 55317
	MINNEAPOLIS	8820 SEVENTH AVE., SOUTH BLOOMINGTON, MN 55427
MISSISSIPPI	JACKSON	137 TURNPOINT PLACE, PEARL, MS 39208
MISSOURI	● ST. LOUIS	1800 PARK 270 DRIVE, SUITE 140, ST. LOUIS, MO 63146
	ST. LOUIS	1034 W. LINE INDUSTRIAL DR., ST. LOUIS, MO 63141
NEBRASKA	OMAHA	13455 "B" STREET, OMAHA, NE 68144
NEW HAMPSHIRE	MANCHESTER	
NEW JERSEY	● FAIRFIELD	80-21 OTIS PLACE, FAIRFIELD, NJ 07004
	EDISON	1240 ROUTE 1, EDISON, NJ 08837
NEW MEXICO	ALBUQUERQUE	2400 RODEO PARK DR. NE., ALBUQUERQUE, NM 87107
NEW YORK	ALBANY	4 NORMANSKILL BLVD., CLIMERE, NY 12054
	BUFFALO	3 FLINT ROAD, KENMORE, NEW YORK 14217
	LONG ISLAND	1981 PARK AVENUE, AUBURN, NY 13021
	MANHATTAN	42 BROADWAY, SUITE 6, 1632, NEW YORK, NY 10004
	ROCHESTER	1225 JEFFERSON ROAD, ROCHESTER, NY
	SYRACUSE	5 CLEAR DR., EAST SYRACUSE, NY 13057
NORTH CAROLINA	CHARLOTTE	8800 YORK ROAD, CHARLOTTE, NC 28273
	DURHAM	2637 PICKETT ROAD, DURHAM, NC 27705
	GREENSBORO	127 S. MOUNTAIN VIEW, HENDERSONVILLE, NC 27284
OHIO	CINCINNATI	9060 C SPRINGFIELD PIKE, CINCINNATI, OH 45215
	CLEVELAND	6200 SHANNON PARKWAY, SUITE F, SOLON OH 44139
	COLUMBUS	6969 WORTHINGTON, GALENA RD., WORTHINGTON, OH 43085
	DAYTON	4433 INTERPLEX DR., TROY, OHIO 45373-4033
OKLAHOMA	OKLAHOMA CITY	10000 CORNELL, PARK, OKLAHOMA CITY, OK 73108
	TULSA	2602 S. 114TH EAST AVE., TULSA, OK 74129
OREGON	PORTLAND	9705 SW GEMINI DRIVE, BEAVERTON, OR 97005
PENNSYLVANIA	● PHILADELPHIA	260 MARKET ST., CAMP HILL, PA 17011
	PITTSBURGH	103 ROCK ROAD, HORSHAM, PA 19044
TENNESSEE	MEMPHIS	6148 SOUTHWIND ROAD, MEMPHIS, TN 38141
	NASHVILLE	2005 KONDONNAH BLVD., SUITE 8, MEMPHIS, TN 38138
TEXAS	DALLAS	222 N. STORY RD., SUITE 126, IRVING, TX 75061
	HOUSTON	4400 S. WAYSIDE, SUITE 105, HOUSTON, TX 77087
	SAN ANTONIO	8500 BANDERA ROAD, SUITE 110,
UTAH	SALT LAKE CITY	3650 W. 2100 SOUTH, SALT LAKE CITY, UT 84120
VIRGINIA	LORTON (DC AREA)	NORTHERN VA INDUSTRIAL PARK, 9922 TELEGRAPH RD., LORTON, VA 22079
	RICHMOND	8401 GLADEBROOK AVE., RICHMOND, VA 23228
WASHINGTON	SEATTLE	835 STRANDER BLVD, #10, COMMERCE CENTER, SEATTLE, WA 98188
WISCONSIN	● MILWAUKEE	2300 S. 170TH STREET, NEW BERLIN, WI 53151
	CALUMERE	1906 MARDEN ST., CALUMERE, WI 54101
	MADISON	3902 KINSMAN BLVD., MADISON, WI 53704
	MILWAUKEE	2300 S. 170TH STREET, NEW BERLIN, WI 53151
	WAUSAU	120 E. STEWART AVE., WAUSAU, WI 54401
CANADA	● TORONTO	34 KLONDIKE DR., WESTON, ONTARIO, CANADA M9L 1S1

(205) 942-2674	
(602) 894-9881	
(602) 622-6446	
(213) 724-5353	
(415) 569-9410	
(714) 581-3626	
(916) 924-1023	
(619) 268-1201	
(408) 727-7575	
(805) 498-9555	
(719) 260-0668	
(303) 629-8822	
(203) 349-1320	
(703) 550-1900	
(305) 974-4900	
(904) 743-1122	
(305) 444-1929	
(813) 630-3610	
(404) 351-3900	
(404) 981-1900	
(312) 758-2585	
(312) 345-7005	
(317) 297-1440	
(515) 224-4900	
(913) 498-4455	
(504) 733-4823	
(410) 712-0900	
(617) 366-8991	
(313) 326-5356	
(616) 957-1951	
(517) 394-0030	
(612) 996-6000	
(612) 548-5956	
(601) 932-1213	
(314) 878-4455	
(314) 567-9966	
(402) 330-3668	
(603) 668-8186	
(201) 575-6940	
(201) 440-8300	
(505) 345-1814	
(518) 438-7620	
(716) 854-7181	
(716) 852-3503	
(315) 364-3527	
(212) 344-2580	
(716) 427-2950	
(315) 463-4660	
(704) 588-3201	
(919) 544-5752	
(919) 668-4824	
(513) 772-8696	
(216) 349-0999	
(614) 436-2995	
(937) 435-5417	
(405) 840-5900	
(918) 437-2010	
(503) 626-4416	
(717) 730-9405	
(215) 674-3181	
(412) 795-8114	
(901) 346-8940	
(615) 399-0900	
(214) 254-4188	
(713) 641-3295	
(210) 561-7900	
(801) 972-6222	
(703) 550-7927	
(804) 285-8000	
(206) 575-4420	
(414) 781-1494	
(715) 532-7401	
(608) 249-5999	
(414) 781-1494	
(715) 845-9888	
(416) 745-9414	

● REGIONAL OFFICES

MODEL 40/3 SETS AND STATIONS

INSTALLATION

CONTENTS

		PAGE
1.	GENERAL	3
2.	IDENTIFICATION	4
	A. GENERAL	4
	B. TYPICAL STATION ARRANGEMENTS	4
	1. KD (Keyboard Display)	4
	2. KDP (Keyboard Display with Printer)	5
	3. ROP (Receive Only Printer)	11
	4. KD-ROP (Keyboard Display with Receive Only Printer)	12
	5. KD & ROP (Keyboard Display and Receive Only Printer)	14
	6. KDP & ROP (Keyboard Display Printer and Receive Only Printer)	16
	7. KD+ROP (Keyboard Display or Receive Only Printer)	19
	8. KDP+ROP (Keyboard Display with Printer or Receive Only Printer)	21
	9. KD-ROP+ROP† (Keyboard Display with Receive Only Printer or Receive Only Printer)	23
	C. CIRCUIT CARD ARRANGEMENTS	25
	1. DISPLAY LOGIC	25
	2. CONTROLLER LOGIC (KD or KDP)	26
	3. CONTROLLER LOGIC (ROP)	26
	4. 9140 CONTROLLER LOGIC	27
	D. OPCON KEYTOP ARRANGEMENTS	30
	1. ROP OPCON — 40K001/AAA	30
	2. KEYBOARD OPCON — 40K101/CAH	30
	3. KEYBOARD OPCON — 40K101/CAG	31
	4. KEYBOARD OPCON — 40K101/CAN	31
	5. KEYBOARD OPCON — 40K101/CAL	32
3.	INSTALLATION	
	A. INSTALLATION OUTLINE	33
	B. UNPACKING INSTRUCTIONS	33
	C. STATION ASSEMBLY	34
	1. PEDESTAL ASSEMBLY	34
	2. ELECTRONICS PACKAGE ASSEMBLY (Electronics Under Monitor or Adjacent for KD and KDPs)	34
	3. ELECTRONICS PACKAGE ASSEMBLY (Electronics in Pedestal for KDPs)	41
	4. ELECTRONICS PACKAGE — ROP WITH 40C103 CONTROLLER	45
	5. OPCON ASSEMBLY	46
	6. MONITOR ASSEMBLY	46
	7. FRICTION FEED PRINTER ASSEMBLY	48
	8. TRACTOR FEED PRINTER ASSEMBLY	50
	9. PORTA-ACCESS PRINTER ASSEMBLY	51
	10. 9140 STATION CONTROLLER ASSEMBLY	55
	11. CABLING	57
	12. DATA SETS	69
	13. MODIFICATION KITS	70

MODEL 40/3 SETS AND STATIONS

INSTALLATION (Contd)

CONTENTS

		PAGE
4.	OPTIONS	73
	A. GENERAL	73
	B. ACTIVATING SET OR STATION OPTIONS	77
	C. 40/3 OPTION LOCATION CHART	79
	D. 9140 CONTROLLER OPTION LOCATION CHART	80
	E. 40C202 CONTROLLER OPTIONS	81
	F. 40C103 CONTROLLER OPTIONS	86
	G. PRINTERS OPTIONS	88
	H. 9140 CONTROLLER OPTIONS	98
	I. INDIVIDUAL RECEIVER SELECTION (IRS) MODIFICATION KIT OPTIONS	110
	J. 40/3 STATION FEATURES AND OPTIONS RECORD	114
5.	TESTING AND TROUBLESHOOTING	123
	A. GENERAL	123
	B. PRELIMINARY CHECK	124
	C. BRIEF OFF-LINE CHECKOUT	124
	D. OFF-LINE CHECKOUT TABLE A — BRIEF OFF-LINE CHECKOUT — KD AND KDP TERMINALS** TABLE B — COMPLETE OFF-LINE CHECKOUT — KD AND KDP TERMINALS TABLE C — OFF-LINE CHECKOUT — ROP TERMINALS	124 125 129 143
	E. TROUBLESHOOTING TABLE D — TERMINAL ANALYSIS TABLE E — DISPLAY LOGIC TABLE F — KD OR KDP CONTROLLER TABLE G — 40C103 ROP CONTROLLER	146 147 154 157 160
6.	WIRING DIAGRAMS	163
	A. GENERAL	163
	B. WIRING DIAGRAMS	164
7.	ADJUSTMENTS	201
8.	TOOLS AND SUPPLIES	201

PART 1 — GENERAL

This manual provides the procedures for installation and checkout of Model 40/3 Sets and Stations with 9140 Station Controllers, hereafter referred to as 40/3.

Supplemental information can be found in the following Service Manuals:

352 Model 40 Shop Manual
355 Model 40 Printer Shop Manual
360 Integrated Model 40 EOP Stations
399 Model 40 Printers — Service
400 Model 40 Operator Consoles — Service
401 Model 40 Display Monitor — Service
402 Model 40 Power Supply — Service
403 Model 40 Cabinets, Paper Winder and Facilities — Service
426 Model 40 Printers — Installation

When ordering replaceable parts or components, unless otherwise specified, prefix each part number with the letters "TP" (ie, TP4100555).

The following Danger and Warning notices are to be observed as safety measures for the craftsperson and the apparatus.

Danger: Safety glasses must be worn whenever monitor cover is removed or whenever monitor is replaced.

Warning 1: Turn off all power and signal sources before removing or replacing any component.

Warning 2: To avoid possible internal damage to circuitry, wear a 346392 static discharge strap connected to ground to allow static discharge before handling circuit cards for removal or replacement. Avoid touching circuit lards or components as much as possible.

Attach static ground strap tightly to wrist.

Attach clip end of static discharge strap to frame ground.

Warning 3: Place each circuit card, except monitor circuit cards in a 406260 static bag immediately after removal from unit. Do not place any printer paper in the bag with the card. Keep the card in the static bag at all times. Never handle the card outside the bag without wearing a properly grounded 346392 static ground strap.



PART 2 – IDENTIFICATION
A. GENERAL

Identification of the 40/3 terminal and its features is important to the shop or field craftsperson. Knowing what features are provided and how those features are programmed to operate provide the basic understanding necessary for installation, operational checkout, or "in the field" service call routines. Several methods are presented in the following paragraphs for determining terminal features and optioning.

Features included in a terminal can be identified by observing if certain keytops are provided on the operator console, or if a certain type or quantity of printed circuit cards are present in the display controller and display logic circuitry.

Optioning on the 40/3 terminal should be recorded in J. 40/3 STATION FEATURES AND OPTIONS RECORD (Pages 112 through 122). Features and options must be recorded by checking ☒ on the variable number in the appropriate square. Features and modification on the terminal that are not listed in J. 40/3 STATION FEATURES AND OPTIONS RECORD should be written in, using the available space.

B. TYPICAL STATION ARRANGEMENTS

Note 1: The 40MN101 display monitor is used with a 60 Hz power source. Substitute the 40MN201 display monitor for 50/60 Hz power source.

Note 2: Specific opcon codes and keytop arrangements are detailed on Pages 30, 31, 32.

Note 3: Data sets used in 40/3 applications are listed on Page 69.

1. KD (Keyboard Display)

KD Stations consist of a keyboard (opcon), display monitor, logic package, 9140 Station Controller and a data set assembled in either of the arrangements shown following. The free standing arrangement requires the 408890 modification kit for remote operation of the opcon and display monitor.



KD Station, Pedestal Mounted



KD Station, Free Standing

2. KDP (Keyboard Display with Printer)

KDP stations resemble KD stations, with a printer added to provide copy of transmitted and received data. In the arrangements detailed below and on succeeding pages, printers shown on separate pedestals may be mounted on user supplied tables having, if tractor feed printers, the proper paper feed slot. The free standing arrangements require the 408890 modification kit for remote operation of the opcon and display monitor.



KDP Station, Single Pedestal, Friction Feed Printer Under Monitor

B. TYPICAL STATION ARRANGEMENTS (Contd)

2. KDP (Keyboard Display with Printer) (Contd)



*Noise reduced cabinet.

KDP Station, Single Pedestal, Friction Feed Printer Adjacent to Logic Cabinet



KDP Station, Single Pedestal, 80-Column Tractor Feed Printer Adjacent to Logic Cabinet



KDP Station, Single Pedestal, Separate Forms Access Printer and Cabinet



*Noise reduced cabinet.

KDP Station, Friction Feed Printer on Separate Pedestal

B. TYPICAL STATION ARRANGEMENTS (Contd)

2. KDP (Keyboard Display with Printer) (Contd)



Note 1: If 132 column printer, use 40CAB353/ZZ printer cabinet.

Note 2: If 132 column printer, use either 40P201/ZZ or 40P202/ZZ printer.

Note 3: If 132 column printer, use 401913 table top (27 inch slotted).

Note 4: If 132 column printer, use 40CAB904/AA pedestal.

KDP Station, Tractor Feed Printer (80- or 132-Column) on Separate Pedestal



KDP Station, Free Standing Opcon and Monitor, Friction Feed Printer on Separate Pedestal

KDP Station, Free Standing Opcon and Monitor, Tractor Feed Printer (80-Column) on Separate Pedestal

B. TYPICAL STATION ARRANGEMENTS (Contd)

2. KDP (Keyboard Display with Printer) (Contd)



KDP Station, Free Standing Opcon and Monitor, Tractor Feed Printer (132 Column) on Separate Pedestal



KDP Station, Free Standing Opcon and Monitor, Separate Forms Access Printer and Cabinet

3. ROP (Receive Only Printer)

These ROP arrangements have pedestal mounted 40C103AD Controllers that include a 1,000 character buffer. ROP friction, tractor or forms access stations having printer cabinet mounted 40C303 Integrated Controllers and described in Manual 360 may be substituted for the ROP arrangements shown here.



*Noise reduced cabinet.

ROP Station, Friction Feed Printer



Note 1: If 132 column printer, use 40CAB353/ZZ printer cabinet.

Note 2: If 132 column printer, use either 40P201/ZZ or 40P202/ZZ printer.

Note 3: If 132 column printer, use 401915 table top (39 inch slotted).

ROP Station, Tractor Feed Printer (80 or 132 Column)

B. TYPICAL STATION ARRANGEMENTS (Contd)

4. KD-ROP (Keyboard Display with Receive Only Printer)

With these KD-ROP arrangements the operator may direct received data to the KD, ROP, or both. The 40C103/AD controller associated with the ROP includes a 1,000 character buffer that eliminates printer data stacking when successive short lines of data are received. The operator may also direct transmitted data to the ROP when local copy is desired. ROP friction, tractor or forms access sets having printer cabinet mounted 40C303 Integrated Controllers and described in Manual 360 may be substituted for the ROP portion of the arrangements shown.



*Noise reduced cabinet.

KD-ROP Station, Friction Feed Printer



Note 1: If 132 column printer, use 40CAB353/ZZ printer cabinet.

Note 2: If 132 column printer, use either 40P201/ZZ or 40P202/ZZ printer.

Note 3: If 132 column printer, use 401913 table top (27.6 inch slotted).

KD-ROP Station, Tractor Feed Printer (80 or 132 Column)

B. TYPICAL STATION ARRANGEMENTS (Contd)

5. KD & ROP (Keyboard Display and Receive Only Printer)

KD & ROP arrangements provide simultaneous send and receive capability. Received data is directed only to the ROP and transmitted data emanates from the KD. There is no provision for using the ROP for local copy or on line copy of transmitted data. ROP friction, tractor or forms access sets having printer cabinet mounted 40C303 Integrated Controllers and described in Manual 360 may be substituted for the ROP portion of the arrangements shown.



*Noise reduced cabinet.

KD & ROP Station, Friction Feed Printer



Note 1: If 132 column printer, use 40CAB353/ZZ printer cabinet.

Note 2: If 132 column printer, use 40P201/ZZ or 40P202/ZZ printer.

Note 3: If 132 column printer, use 401913 table top (27.6 inch slotted).

KD & ROP Station, Tractor Feed Printer (80 or 132 Column)

B. TYPICAL STATION ARRANGEMENTS (Contd)

6. KDP & ROP (Keyboard Display Printer and Receive Only Printer)

KDP & ROP arrangements provide simultaneous send and receive capability. Received data is directed only to the ROP. Transmitted data emanates from the KDP with the associated printer providing on-line or local copy, as desired. ROP friction, tractor or forms access sets having printer cabinet mounted 40C303 Integrated Controllers and described in Manual 360 may be substituted for the ROP portion of the arrangements shown.



KDP & ROP Stations, Friction Feed Printers



KDP & ROP Stations, Friction Feed Printers (Contd)

B. TYPICAL STATION ARRANGEMENTS (Contd)

6. KDP & ROP (Keyboard Display Printer and Receive Only Printer) (Contd)



Note 1: If 132 column printer, use 40CAB353/ZZ printer cabinet.

Note 2: If 132 column printer, use 40P201/ZZ or 40P202/ZZ printer.

Note 3: If 132 column printer, use 401913 table top (27.6 inch slotted).

KDP & ROP Station, Tractor Feed Printers (80 or 132 Column)

7. KD+ROP (Keyboard Display or Receive Only Printer)

KD+ROP arrangements include the 344555 Individual Receiver Selection (IRS) modification kit and other components required for selectively directing incoming data to the KD or to the ROP. The primary receiver, usually the ROP, is selected to receive and print data addressed with the primary (CDC 1) or broadcast (CDC 2) call directing codes. The secondary receiver, usually the KD, receives and displays data addressed with the secondary (CDC 3) call directing code. An optional feature is to have the ROP print local copy of data transmitted from the KD in response to a Transmitter Start Code (TSC). ROP friction, tractor or form access sets having printer cabinet mounted 40C305 Integrated Controllers and described in Manual 360 may be substituted for the ROP portion of the arrangements shown provided a pedestal is included with the friction or tractor sets for housing the IRS logic and power supply package.



*Noise reduced cabinet.

KD+ROP Station, Friction Feed Printer

B. TYPICAL STATION ARRANGEMENTS (Contd)

7. KD+ROP (Keyboard Display or Receive Only Printer) (Contd)



KD+ROP Station, Tractor Feed Printer (80 Column)



KD+ROP Station, Tractor Feed Printer (132 Column)

8. KDP+ROP (Keyboard Display with Printer or Receive Only Printer)

KDP+ROP arrangements include the 344555 Individual Receiver Selection (IRS) modification kit and other components required for selectively directing incoming data to the KDP or to the ROP. These stations function similar to the KD+ROP stations described in 7. KD+ROP (Keyboard Display or Receive Only Printer), except that the KD associated printer provides copy of data transmitted from or directed to the KD. The ROP only serves as a primary receiver called in by CDC 1 or CDC 2. Any of the KDP stations described in 2. KDP (Keyboard Display With Printer) may be substituted for the KDP portion of the arrangements shown here. Similarly, ROP friction, tractor or forms access sets described in Manual 360 may be substituted for the ROP portion of the arrangements shown provided a pedestal is included with the friction and tractor sets for housing the IRS logic and power supply package.



KDP+ROP Station, Friction Feed Printers

B. TYPICAL STATION ARRANGEMENTS (Contd)

8. KDP+ROP (Keyboard Display with Printer or Receive Only Printer) (Contd)



KDP+ROP Station, Tractor Feed Printers (80 Column)



KDP+ROP Station, Tractor Feed Printers (132 Column)

9. KD-ROP+ROP† (Keyboard Display with Receive Only Printer or Receive Only Printer)

KD-ROP+ROP† arrangements include the 344555 Individual Receiver Selection (IRS) modification kit and other components required for selectively directing incoming data to the KD-ROP or to the ROP†. These stations function similar to the KDP+ROP stations described in 8. KDP+ROP (Keyboard Display Printer or Receive Only Printer), except that the ROP of the KD-ROP has a separate 40C103/AD controller with a 1,000 character buffer which eliminates printer data stacking when successive short lines of data are received. The ROP† serves as a primary receiver responding to CDC 1, CDC 2, and the KD-ROP serves as a secondary receiver responding to CDC 3. ROP friction, tractor or forms access sets having printer cabinet mounted 40C303 Integrated Controllers and described in Manual 360 may be substituted for either or both of the ROP, ROP† portion of the arrangements shown. Pedestals must however be provided for housing the IRS logic and power supply package(s) when friction or tractor sets are substituted.



KD-ROP+ROP† Station, Friction Feed Printers

B. TYPICAL STATION ARRANGEMENTS (Contd)

9. KD-ROP+ROP† (Keyboard Display with Receive Only Printer or Receive Only Printer) (Contd)



Note 1: For 132 column printer, use 40CAB353/ZZ printer cabinet.

Note 2: For 132 column printer, use 40P201/ZZ or 40P202/ZZ printer.

Note 3: For 132 column printer, use 401913 table top (27.6 inch slotted).

KD-ROP+ROP† Station, Tractor Feed Printers (80 or 132 Column)

C. CIRCUIT CARD ARRANGEMENTS

1. DISPLAY LOGIC



DISPLAY LOGIC MEMORY CIRCUIT CARD ARRANGEMENTS

DISPLAY LOGIC CODE	MEMORY SEGMENT	FULL EDIT MEMORY LINES	CIRCUIT CARD AND POSITION NO. 010	011	012
40DL29L/SI	No. 1	24	410015	None	None
40DL29L/BK	No. 1, 2	48	410015	410015	None
40DL29L/BL	No. 1, 2, 3	72	410015	410015	410015

Note: The 410005 circuit card (early design) is physically and functionally interchangeable with 400015 card.

C. CIRCUIT CARD ARRANGEMENTS (Contd)

2. CONTROLLER LOGIC (KD or KDF)



POSITION NUMBER		40C202BE	40C202BF	40C202BG (3)	CIRCUIT CARD DESCRIPTION
X01			410770		S/R and PTR Interface
X02		410771	410771		Modified EIA Interface
X03	Front	410672	410672	410672	Opcon Interface
	Rear	410676	410676	410676	Send Variations
X04		410675	410675	410675	Message Control
X05		410674	410674	410674	Data Bus and Decode
Frame No.		341909	341909	341909	

3. 40C103 CONTROLLER LOGIC (ROP)

Note 1: 40C103/AD ROP controller includes buffer (1,000 character storage).

Note 2: 40C103/AE ROP controller does not include a buffer.

CIRCUIT CARD LOCATION

40C103/AD	40C103/AE	POSITION
410582	410582	JA
410581 or 410583	410587	JB
410580	410580	JC
410583	410583	JD

410581 and 410585 are interchangeable.

4. 9140 CONTROLLER LOGIC

9140 Station Controllers consists of a plate on which are mounted seven circuit card connectors and a heat sink/regulator circuit card assembly. The controller mounts to a separately ordered 245600 mounting frame/power supply assembly, which in turn is mounted to a Model 40 pedestal door as illustrated below.



The circuit cards in the 9140 Station Controller are located in card connectors bearing the same letter designation as the initial letter designation on the circuit card. Card D1 is therefore located in the "D" card connector. A circuit card with a hyphen (-) in its designation is mounted piggyback on the card bearing the same letter designation. Card C2-2 is therefore mounted piggyback on card C2 in the "C" connector. The table following details the circuit card complement of the four coded controller arrangements.

CIRCUIT CARD / 9140 STATION CONTROLLER UNIT CODE	222910 "A" CDC DETECTOR	222685 "A3" CDC DETECTOR	222911 "B" R/T DISTRIBUTOR	222421 "B-1" PARITY ERROR DET.	222913 "C2" CONTROL LOGIC	222442 "C2-2" A,B AND MOTOR CONTROL	222914 "D1" DMA	222917 "D2" DMA INTERFACE	222917-"F1" 300H, ETX, EOT DET.	222917-"F2" 310H, ETB, DSN
9140/YH	X		X	X	X	X	X	X	X	X
9140/YJ	X		X	X	X	X	X	X		X
9140/YK		X	X	X	X	X	X	X	X	
9140/YL		X	X	X	X	X	X	X		X

CIRCUIT CARD / 9140 STATION CONTROLLER UNIT CODE	222912 "E" 8-BIT PARALLEL	222915 "F" 8-BIT PARALLEL	222916 "G" 8-BIT PARALLEL	222918 "H" 8-BIT PARALLEL	222919 "J" 8-BIT PARALLEL	222920 "K" 8-BIT PARALLEL	222921 "L" 8-BIT PARALLEL	222922 "M" 8-BIT PARALLEL	222923 "N" 8-BIT PARALLEL	222924 "P" 8-BIT PARALLEL	222925 "R" VOLTAGE REGULATOR
9140/YH	X	X	X	X	X	X	X	X	X	X	X
9140/YJ	X	X	X	X	X	X	X	X	X	X	X
9140/YK	X	X	X	X	X	X	X	X	X	X	X
9140/YL	X	X	X	X	X	X	X	X	X	X	X

X = indicates circuit card supplied with coded controller.

C. CIRCUIT CARD ARRANGEMENTS (Contd)

4. 9140 CONTROLLER LOGIC (Contd)

Signaling rate timer circuit cards are not supplied with coded 9140 Station Controllers but must be ordered separately to meet system requirements. Select the appropriate circuit card from the following table.

CARD	PART NO.	BAUD RATE
A-3C	303805	1050 Baud Timer ‡
A-3E	303839	1200 Baud Timer ‡
A-3F	303863	1800 Baud Timer §
A-3G	303864	2400 Baud Timer §

‡ For use with and mounted piggyback on the 322010 "A" circuit card.
§ For use with and mounted piggyback on the 322685 "A2" circuit card.

9140 Station Controllers operating at 600 baud or higher must have the following separately ordered circuit card installed in card connector "G".

CARD	PART NO.	FUNCTION
G3	322083	Channel Control Store and Forward

The following chart provides a list of circuit card designations, circuit card location within the 9140, part number of card and circuit card function. A circuit card with a hyphen (-) in its designation is mounted piggyback on the card bearing the same letter designation.

CIRCUIT CARDS	CIRCUIT CARD LOCATION	PART NO.	FUNCTION
A or A2	A	322010	CDC Detector
	A	322685	CDC Detector – 1800 and 2400 Baud Timer
¶ A-1	MTD on Card A or A2	322409	Third CDC Detector
A-3C or A-3E or A-3F or **A-3G	Mounted on Card A	303805 or 303839 or 303863 or 303864	1050 Baud Timer 1200 Baud Timer 1800 Baud Timer 2400 Baud Timer
B	B	322011	R/T Distributor
B-1	Mounted on Card B	322411	Parity Error Detection
C2	C	322013	REC Control Logic
C2-2	Mounted on Card C2	322442	A/B and Motor Control (Selected)
D1 or D2	D	322014 or 303734	Send/Receive Logic Receive Only Logic
E2	E	322451	EIA Interface
F1 or F2	F	322017 or 322018	Character Recognition Substitute Character
G3	G	323083	Channel Control Store and Forward
††MC641 or **MC642	Mounted on Card G3	322641 or 322642	Alarm/Parity Error Response 2400 Baud, Isochronous, Parity Detect and Alarm
R	Under Heat Sink	303808	Voltage Regulator

¶ 322409 third CDC circuit card assembly which is optional.
** 402326 modification kit updates a 9140 Station Controller to operate at 2400 baud isochronous operation with a parity detect and alarm feature.
†† Part of 345625 alarm modification kit which is optional. The other parts of 345625 modification kit are the 345626 alarm assembly and mounting hardware.

D. OPCON KEYTOP ARRANGEMENTS

40/3 stations generally use the coded opcon arrangements shown following. For opcon keytop arrangements such as fractions, weather symbols, refer to Manual 332, Part 3. In the arrangements pictured, certain keyswitches have repeat or latch-unlatched capability, or may be equipped with an indicator light. These features are indicated in the following manner:

1. ROP OPCON — 40K101/AAA

Note: Keytop marked TRANS START in lieu of TEST may be present on early model opcon units.

2. KEYBOARD OPCON — 40K101/CAH

For KD stations with 40DL291/Bd display logic.



3. KEYBOARD OPCON -- 40K101/CAG

For KD stations with 40DL291/BK or 40DL291/BL display logic.

4. KEYBOARD OPCON -- 40K101/CAN

For KDP stations with 40DL291/BJ display logic.

D. OPCON KEYTOP ARRANGEMENTS (Contd)

5. KEYBOARD OPCON – 40K101/CAL

For KDP stations with 40DL291/BK or 40DL291/BL display logic.



PART 3 — INSTALLATION
A. INSTALLATION OUTLINE

☐ Verify that equipment at hand matches service order material list.
☐ Unpack components per B. UNPACKING INSTRUCTIONS.
☐ Review service order option requirements. Refer to PART 4 — OPTIONS and option printer(s), controller(s), IRS modification kit (if used) and data set to match service order requirements.
☐ Record the component options on J. 40/2 STATION FEATURES AND OPTIONS CHART of PART 4 — OPTIONS.
☐ Assemble the components into station arrangement specified in service order.
☐ Perform operational checkout as detailed in PART 5 — TESTING AND TROUBLESHOOTING.
☐ Have customer try out station arrangement.
☐ Complete the installation:
(a) Give How to Operate Manual to customer.
(b) Clean up.
(c) Complete service order.

B. UNPACKING INSTRUCTIONS

Any special instructions necessary to open a box will be affixed to the top of the box. A sample instruction label is shown.



Follow these procedures when unpacking.

- Before unpacking the cartons, confirm customer's order with unit codes marked on the cartons.
- Select an assembly area to unpack the cartons so that damage to the components will not occur.
- When unpacking, be sure to wear approved safety glasses.
- Unpack each carton — refer to instructions on the container.

Note: Observe all "caution" notes printed on the carton.

- The pedestal should be unpacked first so that the printer and operator console can be placed on it.
- Cartons and containers can be saved and returned to a shop location for packing components for storage or movement.

C. STATION ASSEMBLY

1. PEDESTAL ASSEMBLY

Step 1. Mount pedestal top to pedestal (four screws with lockwasher.

Step 2. Install 408045 modification kit (ac distribution assembly and cable storage plate), if specified, following method detailed in 50802 Specification packed with the modification kit.



2. ELECTRONICS PACKAGE ASSEMBLY (Electronics Under Monitor or Adjacent for KD and KDFs)

If display logic and controller logic are already assembled in the electronics package, proceed with the power supply assembly, Step 19.

Step 1. Tilt up cabinet or place over edge of table and remove mounting hardware.

Step 2. Open lid.

Step 3. Insert fingers as shown and lift. Then pull module forward until it engages the stop.

Step 4. Insert screwdriver under latch and lift up on latch. Lift up on module and slide forward.





Step 5. Reach in and disconnect ac power cable. Slide module completely out of cabinet.

Step 6. Remove 408050 ventilation assembly by removing three screws and the flat washer, lockwasher, and nut.

Step 7. Check the display logic making sure the cards are seated and properly positioned.

Refer to 1. DISPLAY LOGIC (Page 25) to verify circuit type and position in the display logic wired frame.

Fan Assembly





Step 8. Remove muslin bag containing 341819 shoulder screw used to mount the display logic into the frame and retain for later assembly.

Step 9. Install display logic into frame.



Step 10. Position the display logic over the guide in the module frame and route power ribbon cable flat against bottom of module frame to the opposite side.



C. STATION ASSEMBLY (Contd)

2. ELECTRONICS PACKAGE ASSEMBLY (Electronics Under Monitor or Adjacent for KD and KDFx) (Contd)

Step 11. Remove muslin bag containing 341819 shoulder screw used to mount the controller logic into the frame and retain for later assembly.



Step 12. Install the controller logic into module frame.

Note: In terminals with adjacent logic, make sure unused opcon cable and connector are tied back under wired frame.

Step 13. Position controller bracket over guide in the frame. Route cables as shown (flat cable in center and opcon cable near front of cabinet). Slots in controller must fit over ribbon cable from the display logic.





Position controller bracket over guide in the frame. Route flat cable in center as shown. Slots in controller must fit over ribbon cable from the display logic.

Step 14. Install 341740 ribbon cable.



Step 15. Route opcon cable in the module so that the cable lies flat against front of the module in protective channel.

Omit Steps 15 and 16; continue with Step 17.

(Top View)

C. STATION ASSEMBLY (Contd)

2. ELECTRONICS PACKAGE ASSEMBLY (Electronics Under Monitor or Adjacent for KD and KDA) (Contd)

Step 16. Insert opcon connector (keys up) into frame. Use retainer plate and hardware (tied in muslin bag to the frame) to clamp opcon cable.





Step 17. Install ventilation assembly on the frame using the hardware removed in Step 6. Use notches on logic frame as a guide for alignment. Route ac cable along the inside of frame.

Step 18. Attach braided ground strap to the slip-on terminal on the ventilation assembly. Align the controllers and tighten screws retained in Steps 8 and 11.



Step 19. Mounting the 40PSU101 power supply into module frame:

①Loosen clamp screw and move clamp aside.
②Install power supply through slot and seat onto guide pins.
③Drop handle.
④Connect ac plug from ventilation assembly.
⑤Loosen rear insulator screw and swing insulator aside. Loosen terminal block screws.
⑥Place display logic cable on terminal strip (flat terminals) and then controller cable (formed terminals) on top. Tighten terminal screws.
⑦Replace insulator.
⑧Attach clamp in place over handle and tighten clamp screw.



Note: Frame grounding of circuit common is provided physically in the set power supply for display monitors with serial numbers 10,000 and up and in lower serial numbered monitors which have 403594 modification kit installed. Display monitors and 40PSU101 power supplies with serial numbers below 10,000 were originally manufactured to provide frame ground in the display monitor. The two grounding arrangements are not compatible and should not be mixed within a set. Refer to Service Manuals 401 and 402 if incompatibility exists.



Step 20. Cable routing and connections:

①Slide module back into the cabinet far enough to engage the latch on the right side of the cabinet.
②Reach in and connect the ac power cable to the base of ventilation assembly.

C. STATION ASSEMBLY (Contd)

2. ELECTRONICS PACKAGE ASSEMBLY (Electronics Under Monitor or Adjacent for KD and KDFx) (Contd)

Slide electronics package half way into the cabinet. Connect cable from display logic. Connect power cable at rear of the ventilation assembly.





① Loosen shoulder screw. Slip clip on monitor cable under screw and tighten screws.
② Connect monitor cable.

Step 21. Slide module back into position. Lift up slightly on module to seat in position.

3. ELECTRONICS PACKAGE ASSEMBLY (Electronics in Pedestal for KDPs)

If display logic and controller logic are already installed in the electronics package, proceed with the power supply assembly, Step 15.

Step 1. Slide tabs inward and open panel carefully. Remove two screws and slide module out.



Step 2. Loosen two captive screws and remove four rear screws.

Step 3. Remove guard from back of module by removing four screws, flat washers and lockwashers.





Step 4. Remove 408050 ventilation assembly by removing three screws, nut, lockwasher, and flat washer.

Step 5. Check the display logic making sure the cards are seated and properly positioned.

Refer to 1. DISPLAY LOGIC (Page 25) to verify circuit card type and position in the display logic wired frame.

C. STATION ASSEMBLY (Contd)

3. ELECTRONICS PACKAGE ASSEMBLY (Electronics in Pedestal for KDFs) (Contd)

Step 6. Remove the muslin bag containing the 341819 shoulder screw and 181204 flat washer used to mount the display logic into frame and retain for later assembly.





Step 7. Install display logic into frame.

Step 8. Route power ribbon cable flat against bottom of the module frame to the opposite side.

(Top View)

Step 9. Remove muslin bag containing 341819 shoulder screw and 181204 flat washer used to mount the controller logic into frame and retain for later assembly.



Step 10. Install controller logic into module frame.

Note: Make sure unused cable and connector at front of controller are tied back under frame.



Step 11. Route cables as shown. Slots in controller must fit over ribbon cable from display logic.



Step 12. Install 341740 ribbon cable.

C. STATION ASSEMBLY (Contd)

3. ELECTRONICS PACKAGE ASSEMBLY (Electronics in Pedestal for KDFs) (Contd)

Step 13. Install ventilation assembly on the frame using the hardware removed in Step 4. Use notches on logic frames as a guide for alignment. Route ac cable along the inside of frame.





Step 14. Attach the braided ground strap to the slip-on terminal on the ventilation assembly. Align controllers and tighten screws retained in Steps 6 and 9.

Step 15. Mounting the PSU101 power supply into module frame:

Ⓐ Install power supply through slot and seat onto guide pins.
Ⓑ Drop handle.
Ⓒ Connect plug from ventilation assembly.
Ⓓ Loosen rear insulator screw and swing insulator aside. Loosen terminal block screws.
Ⓔ Place display logic on terminal strip (flat terminals) and then controller cable (formed terminals) on top. Tighten terminal screws.
Ⓕ Replace insulator.



Note: Frame grounding of circuit common is provided physically in the set power supply for display monitors with serial numbers 10,000 and up and in lower serial numbered monitors which have 403594 modification kit installed. Display monitors and 40PSU101 power supplies with serial numbers below 10,000 were originally manufactured to provide frame ground in the display monitor. The two grounding arrangements are not compatible and should not be mixed within a set. Refer to Service Manuals 401 and 402 if incompatibility exists.

Step 16. Complete installation by reversing Steps 3, 2 and 1.

4. ELECTRONICS PACKAGE – ROP WITH 40C103 CONTROLLER

Step 1. Slide tabs inward and open panel carefully. Remove two screws and slide module out.



Step 2. Loosen 401676 screw, remove 401688 thumbscrew and swing bar aside out of the way.

Step 3. Install 401643 controller cable to bottom of module using two 119648 retaining rings. Install cable bracket to ventilation assembly with two 198670 screws. Route cables as shown.





Step 4. Locate the controller logic and power supply over their locator pins and seat. Connect ac plug from ventilation assembly.

C. STATION ASSEMBLY (Contd)

4. ELECTRONICS PACKAGE – ROP WITH 40C103 CONTROLLER (Contd)

Step 5. Loosen insulator screw and swing insulator aside. Mount ribbon cables and strap to terminal block. Replace insulator. Tighten screw.

Step 6. Complete installation by reversing Step 2 and then Step 1.



5. OPCON ASSEMBLY

Remove packing clips before assembly.

Step 1. Assembly procedures for RO, KD and KDP opcon are the same:

- Align connectors.
- Engage latches.
- Slide latches all the way up.
- Check that opcon is secure before releasing it.



KD, KDP Opcon

Step 2. Install CAPS LOCK or the blocking keytop (both provided in plastic bag) on KD or KDP opcon:

- If all caps are required, depress plunger and install blocking keytop.
- If upper and lower case are being used, install CAPS LOCK key.

Warning: The CAPS LOCK keytop must be in the fully extended, unlatched position before attempting to remove the keytop. Failure to observe this precaution will result in a damaged keyswitch.

6. MONITOR ASSEMBLY

Note: Frame grounding of circuit common is provided physically in the set power supply for display monitors with serial numbers 10,000 and up and in lower serial numbered monitors which have 403594 modification kit installed. Display monitors and 40PS(1)01 power supplies with serial numbers below 10,000 were originally manufactured to provide frame ground in the display monitor. The two grounding arrangements are not compatible and should not be mixed within a set. Refer to Service Manuals 401 and 402 if incompatibility exists.

Step 1.

Place monitor upside down. Remove packing clip. (Retain for possible future repacking.)

Monitors With . . .

Remove corrugated packing detail taped to tilt lever (if present). To disengage the tilt lever immobilization latch spring (if present), slide the spring toward the front of the unit until it clears the tilt lever, and move the tilt lever to the right and up into any detent position behind the first or second.

Wheel Type Tilt Mechanism

Lever Type Tilt Mechanism

Move latch spring forward, and move lever out of first two detent positions.

Push studs until they snap into place.

Step 2. Install bottom plate to underside of monitor.



Step 3. Grasp monitor securely from the rear and mount it onto both cabinet or separate monitor base posts, whichever is present.

- Monitor slides down on the posts freely — there is no locking device.
- Make sure connectors inside the posts are fully engaged.

C. STATION ASSEMBLY (Contd)

7. FRICTION FEED PRINTER ASSEMBLY

Step 1. Remove shipping latch and bar. Discard. If printer is to be shipped at later date, retain bar and latch.



Step 2. Slide printer into track:

- Make sure ac and SSI cables are not pinched.
- Make sure detents snap into place.



Step 3. Connect ac power cable and SSI cable.

Step 4. Connect interlock cable at right rear corner of cabinet.

Step 5. Install type carrier.

Step 6. Install ribbon. See instructions on printer top plate.

Caution: Wear a 346392 static discharge strap before proceeding further.

Attach static discharge strap tightly to wrist as shown.

Attach clip end of static discharge strap to frame ground.

Step 7. Option the printer circuit card per system requirements.

- Avoid touching components on the card as much as possible.
- Option 410640 or 410076 circuit card per information in PART 4, B. ACTIVATING SET OR STATION OPTIONS.
- Reinstall card after optioning.

Step 8. Lower Printer and install paper.

- Before inserting paper in paper chute, make a sharp crease on the paper as shown.

8. TRACTOR FEED PRINTER ASSEMBLY

Step 1. Loosen four immobilizing screws a minimum of four turns until base rides freely on the shock mounts.

Step 2. Install type carrier.

Step 3. Install ribbon. See instructions on printer top plate.



(Bottom View)

IMMOBILIZING SCREWS (4 Places)

C. STATION ASSEMBLY (Contd)

8. TRACTOR FEED PRINTER ASSEMBLY (Contd)

Caution: Wear a 346392 static discharge strap before proceeding further with an 80 column printer equipped with a 410640 or 410076 circuit card.

Attach static discharge strap tightly to wrist as shown.

Attach clip end of static discharge strap to frame ground.

Step 4. Option printer circuit card per system requirements:

80-Column

- Remove 410640 or 410076 circuit card and option it per information in PART 4, B. ACTIVATING SET OR STATION OPTIONS.
- Reinstall card.
- Option 410071 and by positioning appropriate switches at bottom of printer. (It is not necessary to remove 410071 card.)

132-Column

- Option 410729 or 410072 circuit card by positioning appropriate switches at bottom of printer per information in PART 4, B. ACTIVATING SET OR STATION OPTIONS. (It is not necessary to remove 410729 or 410072 card.).

Step 5. Slide printer in place:

- Make sure two latches on either side are fully engaged.
- Make sure three connectors at rear of printer are fully seated.



CONNECTORS

Step 6. Install paper forms:

- Open tractor lids.
- Feed forms up through pedestal and cabinet slots, continuing up into the throat of the printer paper chute.
- Make sure forms are loaded in front of mylar strips on both sides.
- Position forms in the tractor mechanism and close the tractor lids.
- Position printer form-out lever to match the length of installed forms.



Note: The dark blue 402572 form-out belt is supplied with the printer. Refer to the following table for selecting a different belt to match other form lengths.

Form Selector Setting				Color of Belt	Part No.
4	3	2	1		
Length of Form					
††3-1/3	3-1/2	5	10	Amber	402571
††3-2/3	†† 2-3/4	5-1/2	11	Dk Blue	402572
4	3	6	12	Yellow	402573
††4-1/3	†† 3-1/4	6-1/2	13	Brown	402574
††4-2/3	3-1/2	7	14	Red	402575
5	†† 3-3/4	7-1/2	15	Pink	402576
††5-1/3	4	8	16	Lt Green	402577
††5-2/3	†† 4-1/4	8-1/2	17	Green	402578
6	4-1/2	9	18	Lt Blue	402579
††7-1/3	5-1/2	11	22	White	402580

†† For six lines per inch
†† For eight lines per inch

9. FORMS ACCESS PRINTER ASSEMBLY

Step 1. Loosen four immobilizing screws far enough so that the base rides freely on the shock mounts.

Step 2. Install type carrier.

Step 3. Install ribbon. See instructions on printer top plate.

IMMOBILIZING SCREWS
(4 Places)

C. STATION ASSEMBLY (Contd)

9. FORMS ACCESS PRINTER ASSEMBLY (Contd)

Step 4. Option printer circuit card according to system requirements.

- Option 410071 circuit card according to information in PART 4, B. ACTIVATING SET OR STATION OPTIONS by setting appropriate option switches. It is not necessary to remove the 410071 card as the option switches protrude through slots in the printer bottom plate.





Step 5. Lower printer into cabinet and onto the rail assemblies. Slide the printer rearward making sure two latches (one on each side) are fully engaged. Connect cabinet connector bracket (left rear) to the printer.

Step 6. With the printer positioned and latched in its rearmost location on the rail assembly frame, make the following printer to cabinet positioning adjustments.

- Loosen and back off the four rail assembly frame mounting screws to where they are friction tight.

(Right Side View)

- Move the printer rail assembly frame forward or rearward so that the printer forms exit gap is located half to three-fourths of the way back in the forms chute opening (as gauged by eye).
- Tighten the four rail assembly frame mounting screws.
- With a scale resting on the printer tear bar top surface and against the front edge of the forms chute opening, the tear bar should be located 3/32 inch to 5/32 inch below the form of the cabinet forms chute opening.



- To adjust, loosen the six intermediate rail bracket mounting screws friction tight. Place the blade of a screwdriver between the frame and the intermediate rail. Pry intermediate rail assembly up at alternate left and right front corners until requirement is met. Tighten the forward most screws.
- After making adjustment, tighten remaining screws.



Step 7. Install paper forms:

- Open left and right tractor lids.
- If multiple forms separate, fold one form down and insert paper.
- Insert paper up through the paper guide chute, behind the ribbon shield and out the slot between the tear bar and top cover before engaging feed holes.



Paper Routing

C. STATION ASSEMBLY (Contd)

9. FORMS ACCESS PRINTER ASSEMBLY (Contd)

• Unlock and set the right tractor for paper width as follows:

(a) Lift clamp on the right tractor assembly.

(b) Position the right tractor to align tractor pins in paper feed holes.

(c) Close right tractor lid and close clamp lever.



Right Tractor Positioning

Thumbscrew Clamp

• To align forms to desired first column printing, loosen blue thumbscrew clamp and position forms drive assembly to align first position on paper with first printing character position. Tighten thumbscrew clamp.

• Pull out paper advance knob (blue) and turn to position form tearline perforation directly behind the edge of the printer tear bar.

Note 1: The dark blue 402572 form-out belt is supplied with the printer. Refer to the following table for selecting a different belt to match other form lengths.

Form Selector Setting				Color of Belt	Part No.
4	3	2	1		
Length of Form					
‡‡3-1/3	2-1/2	5	10	Amber	402571
‡‡3-2/3	‡‡3-3/4	5-1/2	11	Dk Blue	402572
4	3	6	12	Yellow	402573
‡‡4-1/3	‡‡3-1/4	6-1/2	13	Brown	402574
‡‡4-2/3	3-1/2	7	14	Red	402575
5	‡‡3-3/4	7-1/2	15	Pink	402576
‡‡5-1/3	4	8	16	Lt Green	402577
‡‡5-2/3	‡‡4-1/4	8-1/2	17	Green	402578
6	4-1/2	9	18	Lt Blue	402579
‡‡7-1/3	5-1/2	11	22	White	402580

‡‡ For six lines per inch

‡‡ For eight lines per inch

Note 2: The forms access printer is factory adjusted to accept 0.005 to 0.010 inch form stock. If other form stock thickness is being used in the particular installation, paper jams may be experienced or print quality may not be satisfactory due to ink smudge. If necessary, refer to Manual 426, Model 40 Printers -- Installation (packed with printer) and check and/or refine the following adjustments.

40P254 and 40P255 Printer (Ribbonless)
TEAR BAR (Preliminary)
TOP COVER (Preliminary)

40P252 and 40P253 Printer
TOP COVER (Preliminary)
TEAR BAR AND TOP COVER (Final)

10. 9140 STATION CONTROLLER ASSEMBLY

Step 1. Assembly 345605 mounting frame and power supply, and the 9140 Station Controller.



Step 2. Route the cables along mounting support, and plug "N" connector into "JN" connector on power supply.

Step 3. Install 322083 G3 circuit card in position G.

Step 4. Remove circuit card in position A. Mount specified timer circuit card piggy-back on removed card and reinstall in position A. Refer to PART 2, C., 4. 9140 CONTROLLER LOGIC for description and part number chart of available timer circuit cards.



C. STATION ASSEMBLY (Contd)

10. 9140 STATION CONTROLLER ASSEMBLY (Contd)

Perform Steps 5 through 7 only if 345625 alarm/parity response modification kit is used.

Step 5. Install 345626 alarm assembly to 345601 mounting frame with two 198870 screws with lockwashers.

Step 6. Install 322641 answer-back and alarm circuit card on 322083 circuit card in position G.

Step 7. Route the cable of 345626 alarm assembly between mounting posts and 345601 mounting frame. Slip the terminal of the red wire on pin B35 of card connector in position E. Slip the terminal of the black wire on pin B33 of card connector in position G.





Step 8. Remove cable clamp, if present, from right side of pedestal door.

Step 9. Install entire 9140 Station Controller assembly with 345605 mounting frame and power supply on pedestal door. Slide the slot at rear of 345601 mounting frame under the mounting tab on the door. Secure the frame with two 185871 screws with lockwashers. (Circuit cards in positions G and F may have to be removed to gain access to one of the holes.)

Step 10. Connect ac power cord to the unswitched receptacle of a 401665 ac distribution assembly or to any receptacle of a 407285 ac distribution assembly, whichever has been installed in the pedestal.

11. CABLING

Refer to the Index of Cabling Figures to find the interunit cabling layout for a particular 40/3 Station Arrangement. Refer to Manual 360 for additional cabling information when ROP sets having 40C303 Integrated Controllers are substituted for the printers and ROP controllers shown in the cable layout diagrams. It should be noted that information exchange between a Model 40 printer and an associated 40C103 (ROP) or 40C202 controller will always require an SSI type cable.

INDEX OF CABLING FIGURES

Note: +ROP indicates an ROP equipped with the 344555 Individual Receiver Selection (IRS) modification kit.

FIGURE	CONTENT	PAGE
1	ROP Station	58
2	KD Station	58
3	KD-ROP Station	59
4	KD-ROP+ROP Station	60
5	KD+ROP Station	61
6	KD & ROP Station	61
7	KDP Station, Friction Feed Printer Under Monitor	62
8	KDP Station, Tractor or Friction Feed Printer Adjacent	62
9	KDP Station, Tractor or Friction Feed Printer on Separate Pedestal	63
10	KDP+ROP Station, KDP Friction Feed Printer Under Monitor	63
11	KDP+ROP Station, KDP Tractor or Friction Feed Printer Adjacent	64
12	KDP+ROP Station, KDP Tractor or Friction Feed Printer on Separate Pedestal	65
13	KDP & ROP Station, KDP Friction Feed Printer Under Monitor	66
14	KDP & ROP Station, KDP Tractor or Friction Feed Printer Adjacent	66
15	KDP & ROP Station, KDP Tractor or Friction Feed Printer on Separate Pedestal	67
16	Free-Standing Monitor Base and Opcon Cabling to Logic Assembly for KD, KDP Stations	68

C. STATION ASSEMBLY (Contd)

11. CABLING (Contd)



Fig. 1—ROP Station



Fig. 2—KD Station



Note: 341896 or 408065 through 408068 EIA cable assembly, dependent on length required.

Fig. 3—KD-ROP Station

C. STATION ASSEMBLY (Contd)

11. CABLING (Contd)



Note: 341896 or 408065 through 408068 EIA cable assembly, dependent on length required.

Fig. 4—KD-ROP+ROP Station



Fig. 5—KD+ROP Station



Fig. 6—KD & ROP Station

C. STATION ASSEMBLY (Contd)

11. CABLING (Contd)



Fig. 7—KDP Station, Friction Feed Printer Under Monitor



Fig. 8—KDP Station, Tractor or Friction Feed Printer Adjacent



Fig. 9–KDP Station, Tractor or Friction Feed Printer on Separate Pedestal



Fig. 10–KDP+ROP Station, KDP Friction Feed Printer Under Monitor

C. STATION ASSEMBLY (Contd)

11. CABLING (Contd)



Fig. 11—KDP+ROP Station, KDP Tractor or Friction Feed Printer Adjacent



Fig. 12—KDP+ROP Station, KDP Tractor or Friction Feed Printer on Separate Pedestal

C. STATION ASSEMBLY (Contd)

11. CABLING (Contd)



Fig. 13—KDP & ROP Station, KDP Friction Feed Printer Under Monitor



Fig. 14—KDP & ROP Station, KDP Tractor or Friction Feed Printer Adjacent



Fig. 15—KDP & ROP Station, KDP Tractor or Friction Feed Printer on Separate Pedestal

C. STATION ASSEMBLY (Contd)

11. CABLING (Contd)



Fig. 16—Free-Standing Monitor Base and Opcon Cabling to Logic Assembly for KD, KDP Stations

12. DATA SETS

The following Bell System data sets or equivalent modems may be used with Model 40/3 sets and stations.

BELL SYSTEM DATA SET	MAXIMUM BAUD RATE
202C	1200
202D	1200
202R	1200
202T	1200
201C	2400

The following data set functional interface designations and connector pin assignments are used with Model 40/3 systems via the 9140 controller "T" cable.

CONNECTOR PIN NO.	INTERFACE DESIGNATION USING EIA RS-232-C NOMENCLATURE
1	Protective Ground (AA)
2	Transmitted Data (BA)
3	Received Data (BB)
4	Request-to-Send (CA)
5	Clear-to-Send (CB)
6	Data Set Ready (CC)
7	Signal Ground (AB)
8	Data Carrier Detector (CF)
12	Secondary Data Carrier Detector (SCF)
20	Data Terminal Ready (CD)

EIA RS-232-C specifies data and control signal levels as follows:

VOLTAGE	CONTROL SIGNAL	DATA SIGNAL	BINARY STATE
-5 V to -25 V	Off	Mark	1
+5 V to +25 V	On	Space	0

C. STATION ASSEMBLY (Contd)

13. MODIFICATION KITS

Audible Alarm and Answer-Back

The 345625 modification kit will supply an audible alarm and optional answer-back if the station is not ready to receive (DTR off) or a vertical parity error is detected in the message text. A ready to receive answer-back is sent if DTR is on and no errors are detected. The 9140TH controller must contain a 322083 (G3) card and its wiring must conform to Issue 8 or higher of 8523WD Wiring Diagram. Installation of the 345626 alarm assembly and 322641 circuit card are shown below with details given in Specification 50803S and the 2006SD Schematic Diagram.



Typical Audible Alarm and Answer-Back Modification Kit Installation

Individual Receive Selection

The 344555 modification kit provides interconnecting and control facilities in 40-type set combination KD/ROP (private line version). The ROP designated as the primary receiver must be equipped with a 345605 mounting frame and power supply. The KD secondary receiver must be equipped with a 345605 mounting frame with power supply, 9140 Station Controller, and 322409 circuit card (red code). The 344545 interface cable is used between the primary receiver, secondary receiver, individual receiver selection assembly, and the 9140 Station Controller. A typical KD+ROP arrangement equipped with an individual receiver selection modification kit is shown in Fig. 5, Page 61.

The Specification 50808S describes the use of the primary receiver and the ROP as the secondary receiver but this should not be used for full duplex operation and is not recommended for half-duplex because the "No-Traffic" replies "Ready/Not Ready" reflect the primary receiver status. Installation of the 344545 interface cable, the 344546 mounting plate and the 344545 interface cable is given in Specification 50808S. The actual wiring diagram for the 344546 mounting plate and connector assembly is 9311WD. The schematic wiring diagram for the 344553 logic circuit card is 1210SD.



Typical IRS Modification Kit Installation

2400 Baud Isochronous Operation With Private Detection and Alarm Feature.

The 402326 modification kit provides 2400 baud isochronous operation and requires a 201C or equivalent data set. The kit also supplies the alarm and vertical parity error features of the 345625 modification kit. The 9140 Station Controller must contain a 322083 card and this modification kit updates a 322010 "A" card into a 322685 "A3" card. The modification may be used with either a KD having a 410771 card or a ROP using a 410580 card. Installation procedures of the modification are given in Specification 50875S which accompanies the modification kit.

NOTES

PART 4 — OPTIONS
A. GENERAL

This part includes all options that are utilized in the 40/3 Station. It also covers handling of circuit cards, location of circuit card switch packs and information on how to activate or change switch positions.

The options enabled should be checked on 1. 40/3 STATION FEATURES AND OPTIONS CHART. (See Page 106.)

If any field options are to be changed, turn off power and remove cards using the following procedures. Check card to see that pins are not bent before reinserting card.

Warning: Wear the 346392 ground strap before removing or handling controller or printer circuit cards. See Part 1 of this manual.

Extracting Circuit Cards From the Controller

(a) Lift up on the extractor handles of the circuit card.

(b) Lift circuit card straight up.

Printer Circuit Card Removal

Only 410076 or 410640 printer circuit cards require removal to gain access to the option setting switches. Printers with other circuit card types do not require bottom plate and circuit card removal.

Remove 410076 or 410640 Circuit Card From 80-Column Friction Feed Printer

Remove two screws that secure circuit card cover to the bottom of the printer and allow cover to hang down.

Using finger hold and a firm grip of the card edge on opposite side as shown, apply an even pulling force and unplug card from the two rows of magnet assembly contacts.

Lift left (bottom) end of card up and out of channel (bypassing printer base shipping screws) first, then right side of card up and out. Remove card from connector.

A. GENERAL (Contd)

Note: During reassembly, make certain that the connector is plugged onto the card and that the card is located within the channel before plugging it into the two rows of magnet assembly contacts. Apply slight pressure at both ends and middle of card to fully seat it on magnet contacts.



Friction Feed Printer Circuit Card Removal

Remove 410076 or 410640 Circuit Card From 80-Column Tractor Feed Printer

Remove two top screws and loosen three bottom screws.

Slide bottom plate out.

Remove connector from card; using pull points, pull card down and out.



Tractor Feed Printer Bottom Plate

Optioning the 410076 or 410640 Circuit Card of 40P102 Friction Feed or 40P151, 40P152, 40P153 Tractor Feed Printers

Either circuit card may be optioned after removal from the printer by setting the option switches as detailed in B. ACTIVATING SET OR STATION OPTIONS.



Optioning the 410071 Circuit Card of 40P252 Through 40P255 80-Column Forms Access Tractor Feed Printers or 40P154 80-Column Tractor Feed Printer

It is not necessary to remove the 410071 circuit card from the printer to set the option switches. The option switches are accessible through openings in the printer bottom plate.





Forms Access Printer



40P154 Printer

A. GENERAL (Contd)

Optioning the 410072 or 410729 Circuit Card for 132-Column Tractor Feed Printer

It is not necessary to remove the 410072 or 410729 circuit card from the printer in order to option it. Option switches on the card are accessible through openings in the bottom plate of the printer.



Tractor Feed Printer – 132-Column



Option Switch Styles

Several styles of option selecting switches may be present on the printer and/or controller circuit cards. On toggle or slide type switches, options are activated by positioning the toggle or slide toware the ON designation. On rocker type switches, the dotted rocker end or the rocker end adjacent to a dot are positioned down (depressed) to activate an option. Conversely, to deactivate or switch OFF an option, position the toggle or slide away from ON or depress the blank end of the rocker switch.



Toggle Style Slide Style Rocker Styles

(Toggles and Slides Shown in OFF Position, Option Deactivated)

(Rockers Shown in ON Position, Option Activated)

The option selecting switches are of various sizes, having between 4 and 10 toggles, slides or rockers, numbered accordingly.

B. ACTIVATING SET OR STATION OPTIONS

To activate or change options on the circuit cards, perform the following procedures.

(a) Turn off all power to the station.

(b) Locate the circuit card that contains the option to be activated. (A complete list of options available can be found on Pages 79, 80.)

(c) Remove circuit card.

Warning: To avoid possible damage to MOS circuitry, attach 346392 static ground strap to wrist and frame ground before handling circuit cards.

B. ACTIVATING SET OR STATION OPTIONS (Contd)

(d) Locate the proper option switch or screw and activate as required.

(e) Return the circuit card to its proper location.

(f) Turn on station power.

(g) Perform a checkout of the station to verify proper operation of the option.



Legend:

● Indicates dot end of rocker switch depressed, toggle or slide positioned to ON.
○ Indicates blank end of rocker switch depressed, toggle or slide positioned to OFF.
* Factory optioned.
– Switch position does not affect option.

C. 40/3 OPTION LOCATION CHART

DATASPEED 40/3 OPTION NUMBER	LOCATION (Circuit Card or Printer)	PAGE NUMBER
4-1.	410770	82
4-3.	410580, 410771	81, 86
4-4.	410771	81
4-(5.-9.)	410674	85
4-(10.-12.)	410675	84
4-13.	410676	83
4-17.	410640, 410729, 410071, 410072, 410076	88, 90, 91, 93, 95
4-(18.-19.)	410640, 410729, 410071, 410072, 410076	89, 90, 92, 94, 96
4-20.	On Printer	88
4-(21.-23.)	410640, 410729, 410071, 410072, 410076	89, 90, 92, 94, 96
4-(24.-25.)	410580	86
4-27.	410675	84
4-(28.-29.)	410770	82
4-(30.-32.)	410771	81
4-(33.-34.)	410771	82
4-(35.-36.)	410580	86
4-37.	410771	82
4-38.	410582	87
4-39.	On Printer	88
4-40.	410674	85
4-48.	410729, 410071, 410072, 410076	90, 92, 94, 96
4-50.	410770	82
4-(51.-53.)	410770	83
4-(54.-55.)	410071, 410072, 410076	92, 94, 96
4-56.	410076	96
4-(57.-58.)	410071, 410072, 410076	92, 94, 96
4-(59.-60.)	410071, 410072	92, 94
4-61.	410151	97

D. 9140 CONTROLLER OPTION LOCATION CHART

9140 OPTION NUMBER	LOCATION	PAGE NUMBER
9-1. (a.-d.)	322442 C2-2	103
9-1. (e.-g.)	322014 D1	104
9-1. h.	322013 C2	102
9-1. (i.-j.)	322014 D1	104
9-1. (k.-n.)	322010 A	99
9-1. (o.-p.)	322409 A-1	100
9-1. q.	322018 F2	107
9-2.	322014 D1	104
9-3.	322011 B	101
9-4.	322010 A	99
9-5.	322011 B	101
9-6.	322014 D1 322451 E2	104 106
9-7.	322014 D1	105
9-8.	322011 B 322451 E2 322642 —	101 106 109
9-9.	322013 C2 322014 D1	102 105
9-10.	322014 D1	105
9-11.	322083 C3	108
9-12.	322442 C2-2	103
9-13.	322451 E2	106
9-14. — 9-15.	322010 A	99
9-16.	322409 A-1	100
9-17.	322013 C2	102
9-18.	322442 C2-2	103
9-19. (a.-d.)	322010 A	100
9-19. (e.-f.)	322409 A-1	100
9-20. — 9-21.	322442 C2-2	103
9-22. — 9-23.	322013 C2	102
9-24.	322451 E2	106
9-25.	322017 F1 322018 F2	107 107
9-26.	322451 E2	106
9-27.	322641 — 322642 —	108 109

E. 40C202 CONTROLLER OPTIONS

410771 — Full Duplex Interface Circuit Card — Card Position X02



Note: The straps to enable or disable the following options are on the component side (front) of the 410771 circuit card. Early cards have the lands on the rear. The cards are furnished without straps.

Sketch of present 410771 showing location of Straps (circuit lands) A through D.

4-3. EIA Send/Receive Data Baud Rate	A=1 1 2 3 4 5	
a 1050 Baud	– ● ● ● ● *	Choose 1
b 2100 Baud	– ○ ● ○ ○ *	
c 1400 Baud	– ○ ○ ● ○ *	
d 1800 Baud	– ● ○ ● ○ *	

4-4. EIA Reverse Channel	A=15 11 12 13 14 15	
a Reverse Channel Required to Send	●	Choose 1
b Reverse Channel Not Required to Send	○	*

4-31. Message Preparation	A=1 2 3 4 5	
a Automatic Cursor Home and Send Mode on Upcon Entry of Message Ending Character	– – – – ○	* Choose 1
b Manual Cursor Home and Send Mode on Upcon Entry of Message Ending Character	– – – – ●	

4-31. KD Forced to Receive Mode when Alarm Lead In On	Strap A	
a Independent of Printer Mode	○	* Choose 1
b Dependent on Printer Mode (Goes Receive Only if in Print On Line mode)	●	

4-32. Printer Access From Line (When PRINT ON LINE Lamp is On)	Strap B	
a KP KD is in Send, Receive, or Local Mode	○	* Choose 1
b KP KD is in Receive Mode or Local Mode	●	

See Legend for ○ , ● , – and * on Page 78.

E. 40C202 CONTROLLER OPTIONS (Contd)

410771 — Full Duplex Circuit Card — Card Position X02 (Contd)

		Strap C	
4-33. 9160 Controller Mode			
	a Full Duplex (FDX) -- CTS Controls RTS	●	Choose 1
	b Half-Duplex (HDX) -- CTS Does Not Control RTS	○	*
4-34. Control Signal Restrictions		Strap T	
	a RTS Can Turn On When STR is On	○	* Choose 1
	b RTS Cannot Turn On When STR is On	●	
4-37. Requirement for Sending		C-10 1 2 3 4 5	
	a CTS Signal Required for Sending	○●●●●	* Choose 1
	b CTS Signal Not Required for Sending	●○○○○	

410770 — Independent Printer Access Circuit Card — Card Position X01



		C-6 1 2 3 4 5	
4-1. Interface to Printer			
	a IFSS (Use for EO-KDP)	○●	* Choose 1
	b SST (Use for KDP)	●○	
4-28. Disconnect on Loss of Carrier		1 2 3 4 5	
	a Disconnect After 45 Seconds	○	* Choose 1
	b Loss Not Disconnect - Timer Disabled	●	
4-29. Printer Message Mode		C-6 1 2 3 4 5	
	a When in Print On Line Mode, Copies Display On Send, Copies Line to Receive or Local	●	* Choose 1
	b Not Used in 40C2-Type		
	c Not Used on 40/3-Type		
	d When in Print On Line, Copies Received Data in Receive or Local	○ ○	
4-30. Action Upon Printer Alt Loss		C-10 1 2 3 4 5	
	a NO SEND LOCK AND HOLD	○○○○○	* Choose 1
	b NO SEND LOCAL AND RELEASE	●○○○○	
	c No Mode Change In KB	○●●●●	

See Legend for ○ , ● ,– and * on Page 78.

Note: The switch pack in position C-6, was in position C-7 on Issue 2 and earlier circuit cards.

410770 — Independent Printer Access Circuit Card — Card Position X01

			C-I/O					
			1	2	3	4	5	6
4-51.	Remote Control							
	a 3210 Character Control		–	–	●	○	–	–
	b 3540 POL Control for Split Operation		–	–	●	○	–	–
	c Not Used on 4027-Type Stations		–	–	○	○	–	–
4-52.	Print On Line Control		1	2	3	4	5	6
	a Copy All Text Data		–	–	–	●		
	b Fm Option 4-29		–	–	–	○	*	
4-53.	Printer Motor Hold Timer		1	2	3	4	5	6
	a Disabled (See Note.)		–	–	–	●		
	b Enabled		–	–	–	○		

Choose 1

Choose 1

Choose 1

Note: If both Options 4-51.b. and 4-53.a. or both 4-52.a. and 4-53.a. are used, Strap A (land) must be cut.

410676 — Send Variations Circuit Card — Card Position X03

		Act							
4-13. Send Variations (All Without SetBinters Except as Modified by Option 4-9b)		1	2	3	4	5	6	7	8
a	Send All as Displayed	●	○	○	○	○	○	○	○
b	Send All as Displayed With Unprotected WF to Space	○	●	○	○	○	○	○	○
c	Send Protect as Space and Unprotected as Displayed	○	○	●	○	○	○	○	○
d	Send Protect as Space, Unprotected as Displayed and WF to Space	○	●	●	○	○	○	●	
e	Send Protect as Delete, Unprotected as Displayed	○	○	○	●	○	○	○	○
f	Send Unprotected Only as Displayed	○	●	○	●	○	○	○	○
g	Send Unprotected Only and WF at End of Field	○	○	●	●	○	○	○	○
h	Send Unprotected Only With Unprotected WF to Space	○	●	●	●	○	○	○	○

Choose 1

See Legend for ○ , ● , – and * on Page 78.

E. 40C202 CONTROLLER OPTIONS (Contd)

410675 — Message Control Circuit Card — Card Position X04



4-10. Line Ending Sequence	A-3							B-11				
	1	2	3	4	5	6		1	2	3	4	5
a.CR LF						○		●	●	○	○	○
b.CR CR LF						○		●	●	●	○	○
c.LF						●		○	○	○	○	○
4-11. Mode After Send	A-3											
	1	2	3	4	5	6						
a.Local	○	●	●				*					
b.Receive	●	○	●									
c.Not Used in 40/3-Type Stations	○	●	○									
4-12. Form Enter	A-3											
	1	2	3	4	5	6						
a.Disabled in Local	●						*					
b.Enabled in Local	○											
4-27. Message Start	A-3											
	1	2	3	4	5	6						
a.Move on Transmit						●	*					
b.Input From Cursor						○						

Choose 1

Choose 1

Choose 1

Choose 1

See Legend for ○ , ● , — and * on Page 78.

410674 — Data Bus and Decode Circuit Card — Card Position X05



	A-10	C-12	
4-5. I/O Response to Received Characters	1 2 3 4 5	1 2 3 4 5 6 7 8	
a Reject Null	● — — — —	— — — — — — — —	Choose 1
b Accept Null	○ — — — —	— — — — — — — —	
c Reject CR	● — — — —	— — — — — — — —	
d Accept CR	○ — — — —	— — — — — — — —	Choose 1
e Reject Delete	— — — — —	— — — — — — — ●	
f Accept Delete	— — — — —	— — — — — — — ○	
g Reject 3C (Issue 4b and Higher)	— — — — —	— — — — — — ● —	Choose 1
h Accept 3C (Issue 4b and Higher)	— — — — —	— — — — — — ○ —	
i Reject 3C (Issue 4b and Higher)	— — — — —	— — — — — — ● —	Choose 1
j Accept 3C (Issue 4b and Higher)	— — — — —	— — — — — — ○ —	

	A-10	
4-6. Functions on Receive	1 2 3 4 5	
a All Escape Sequences Displayed as Received	— — — — —	Choose 1
b All Escape Sequences Performed as Received But Not Displayed	— — ● — —	*

	A-10	
4-7. Errored Character on Receive	1 2 3 4 5	
a Not Displayed on Vertical Parity Error	— — — ● —	Choose 1
b Displayed on Vertical Parity Error	— — — ○ —	*

	C-11	C-12	
4-8. Message Ending Character	1 2 3 4 5	1 2 3 4 5 6 7 8	
a End on FF	— — — — —	— — ● — — — — —	*
b Do Not End on FF	— — — — —	— — ○ — — — — —	Choose 1
c End on ETX	○ — — — —	— — — — — — — —	*
d Do Not End on ETX	● — — — —	— — — — — — — —	Choose 1
e End on EOT	— — — — —	— — ● — — — — —	*
f Do Not End on EOT	— — — — —	— — ○ — — — — —	Choose 1
g End on CS	— — — — —	— — — — — — — ●	*
h Do Not End on CS	— — — — —	— — — — — — — ○	Choose 1

	C-12	
4-9. Highlight	1 2 3 4 5 6 7 8	
a Preliminary Not Sent (Except in Form Send Mode)	— — — — — — — ●	Choose 1
b Preliminary Sent (Modifies Option 4-11)	— — — — — — — ○	*

	C-12	
4-10. Go Receive on Sending CR (←) (Issue 4b and Higher)	1 2 3 4 5 6 7 8	
a Host is Half-Duplex Station	— — — — — — — —	Choose b
b Do Not Go Receive on Sending CR	— — — — — — — —	

See Legend for ○ , ● , — and * on Page 78.

F. 40C103 CONTROLLER OPTIONS

410580 — EIA Interface Circuit Card Options — Card Position 4C in 40C103 ROP Controller



4-7. EIA/Send/Receive Data Baud Rate	Insulator B Position	Insulator A Position	
a. 1200	1	1	Choose 1
b. 2400	2	2	*
c. 4800	3	3	

4-26. Odd/Even Character Parity Check	Strap Condition	
a. Even Vertical Parity	Strap A to B	* Choose 1
b. Odd Vertical Parity	Strap A to C	

4-25. Response to Receiving Parity Error	Insulator B Position	Strap A Condition	
a. Printer Receives Odd Parity Null Char. Operating Until Reading	2	-	Choose 1
b. Printer Operates Until Data From Host Is Not Parity Error	1	-	*
c. DATA ERROR Key Lights		Removed	* Choose 1
d. DATA ERROR Key Does Not Light		Installed	*

4-31. Printer Motor Control	Strap Condition	
a. "Data Set Ready" Controls Printer Motor	Strap B to 1	* Choose 1
b. "Carrier Detect" Controls Printer Motor	Strap B to 2	

4-30. Printer Paper Alarm	Insulators C Position	
a. Paper Alarm Affects "Data Terminal Ready" At End of Call. DTR Held Off Until Paper is Restored	2	* Choose 1
b. Paper Alarm Affects "Data Terminal Ready" Immediately. DTR Held Off Until Paper is Restored	1	

See Legend for ○ , ● , — and * on Page 78.

410582 — ROP Controller — Card Position JA in 40C103 ROP Controller

Note: Option 4-38b is shown enabled.

4-38.	Data Stacking	Insulator Position
a	Enable Data Stacking	Insulator Up
b	Disable Data Stacking	Insulator Down

Choose 1

Note: The following strapping is required on Issue 1 of the 410587 circuit card when using a 40C103/AE ROP controller (without a buffer) and Option 4-38a is to be enabled. Select Option 4-38b when using 40C103/AD (with buffer).

PC — PIN 20 to MLB1 PIN 1
MLB1 PIN 2 to MLB1 PIN 3
MLB1 PIN 4 to MLA1 PIN 2
(Connector PC-22)

410587 Circuit Card

Issue 2a of the 410587 circuit card has these straps incorporated in the board layout.

See Legend for ○ , ● , — and * on Page 78.

G. PRINTERS OPTIONS

Printer — Test, LF and Form Switches



For 40P151 and 153 Printers For 40P101 and 102 Printers

For 40P154, 201 and 202 Printers

Printer Option Switches Located on Top of Printer

4-30. Line Feed on Printer		
1	Single	* Choose 1
2	Double	
4-29. Forms Feed (Tractor Feed Printer Only)		
1	ON	* Choose 1
2	OFF	

See Legend for ○ , ● , — and * on Page 78.

410640 — Printer Logic Circuit Card (80-Column) — Card Located in Lower Portion of Printer



| | | |

G. PRINTERS OPTIONS (Contd)

410729 — Printer Logic Circuit Card (132-Column) — Access Through Printer Bottom Plate



| | | |

410071 — Printer Logic Circuit Card (80-Column) — Access Through Printer Bottom Plate





To obtain counts:

72 through 80 program as shown.
61 through 72 program as shown, then operate E8 position 8 to OFF.
49 through 60 program as shown, then operate E8 position 1 to OFF.
37 through 48 program as shown, then operate E5 position 7 to OFF.
25 through 36 program as shown, then operate E5 position 8 to OFF.

(X) Indicates desired column number.

See Legend for O , ● , — and * on Page 78.

G. PRINTERS OPTIONS (Contd)

410071 — Printer Logic Circuit Card (80-Column) — Access Through Printer Bottom Plate (Contd)

Note: Option 4-04.b. should not be used on a KDP set. The character after escape is already suppressed by the KD in SSI operation but not in EIA operation.

See Legend for ○ , ● , — and * on Page 78.

410072 — Printer Logic Circuit Card (132-Column) — Access Through Printer Bottom Plate



(Printer Circuit Card Viewed From Beneath Printer — Access to Switches is Through a Cutout in Bottom Pan of Printer.)

To obtain counts:

121 through 132 program as shown.
109 through 120 program as shown then operate D9 position 1 OFF.
97 through 108 program as shown, then operate D9 position 8 OFF.
85 through 96 program as shown, then operate D8 position 1 OFF.
73 through 84 program as shown, then operate D8 position 8 OFF.

(X) Indicates desired column number.

See Legend for ○ , ● , — and * on Page 78.

G. PRINTERS OPTIONS (Contd)

410072 — Printer Logic Circuit Card (132-Column) — Access Through Printer Bottom Plate (Contd)

Note: Option 4-54.b. should not be used on a KDP set. The character after escape is already suppressed by the KD in SSI operation but not in EIA operation.

See Legend for ○, ●, – and * on Page 78.

410076 — Printer Logic Circuit Card (80-Column) — Card Located in Lower Portion of Printer



| | | |

G. PRINTERS OPTIONS (Contd)

410076 — Printer Logic Circuit Card (80-Column) — Card Located in Lower Portion of Printer (Contd)

Note: Option 4-54.b. should not be used on a KDP set. The character after escape is already suppressed by the KD in SSI operation but not in EIA operation.

See Legend for ○, ●, — and * on Page 78.

410151 — Circuit Card — Located in Printer Power Module or Power Supply



4.61. Regulator Grounding (Circuit Ground to Frame Ground)	Screw A		Screw B		
	Component	Nonecomponent	Component	Nonecomponent	
a. NO (CKT & FR GND or PTE)	In	—	—	In	Choose 1
b. SECOND (CKT & FR GND or PTE, +15V)	In	—	In	—	
c. OEM (CKT GND KEY to FRM, +15V)	—	In	In	—	

H. 9140 CONTROLLER OPTIONS

The circuit cards in the 9140 Station Controller are located in card connectors bearing the same letter designation as the initial letter designation on the circuit card. Card D1 is therefore located in the "D" card connector. A circuit card with a dash (-) in its designation is mounted piggyback on the card bearing the same letter designation. Card C2-2 is therefore mounted piggyback on card C2 in the "C" connector.



H. 9140 CONTROLLER OPTIONS (Contd)

9140 circuit cards are optioned by cutting and removing or leaving intact specific wire straps, as indicated in the following legend:

● Strap in place.
○ Strap removed.
— Strap has no bearing on option.

The ASCII code chart provided here should be referred to when coding CDC, TSC or other variable characters as detailed in the 9140 Station Controller options.

ASCII CODE

(American National Standard Code for Information Interchange)



Note: Shaded boxes indicate characters with bit 8 "1" for even parity.

Example: Bits 1 through 7 of the bit permutation for the character M are 1011001, respectively.

1 = Mark 0 = Space

NUL	—	Null	DC1	—	Device Control 1
SOH	—	Start of Heading	DC2	—	Device Control 2
STX	—	Start of Text	DC3	—	Device Control 3
ETX	—	End of Text	DC4	—	Device Control 4
EOT	—	End of Transmission	NAK	—	Negative Acknowledge
ENQ	—	Enquiry	SYN	—	Synchronous
ACK	—	Acknowledge	ETB	—	End of Transmission Block
BEL	—	Bell	CAN	—	Cancel
BS	—	Back Space	EM	—	End of Media
HT	—	Horizontal Tab	SUB	—	Substitute
NL	—	New Line	ESC	—	Escape
VT	—	Vertical Tab	FS	—	Field Separator
FF	—	Form Feed	GS	—	Group Separator
CR	—	Carriage Return	RS	—	Record Separator
SO	—	Shift-Out	US	—	Unit Separator
SI	—	Shift-In	SP	—	Space
DLE	—	Data Link Escape	DEL	—	Delete

322010 — CDC Detector (A) — Card Position A


A
CHAN. OUT
CHAN. OUT
CHAN. OUT

H. 9140 CONTROLLER OPTIONS (Contd)

322010 — CDC Detector (A) — Card Position A (Cont)

			Straps 58	59	
9-19.	Answer-Back to CDC (Observe That, for Example, Option 9-17c Can Override Option 9-19a or 19b) (See Option 9-17, Card C2.)				
	a.	Answer-Back CDC1 Always	○	—	Choose 1
	b.	Answer-Back to CDC1 Only When Ready to Receive	●	—	
	c.	Answer-Back to CDC2 Always	—	○	Choose 1
	d.	Answer-Back to CDC2 Only When Ready to Receive	—	●	

322409 — 3rd CDC Detector A-1 — Card Position and Piggyback to A

Note: Card A-1 not present on all stations; it is USOC DJB.

		Coding Instructions
9-1.	Variable Characters (See Below)	
c.	Call Directing Code (CDC) 3, Character 1	
p.	Call Directing Code (CDC) 3, Character 2	

Cut strap labeled "M" for levels that are marking.
Cut strap labeled "S" for levels that are spacing.
Every level must have one strap cut.

			Straps 10	11	
9-16.	Number of Characters in CDC3 (Exclusive of Delete, if Used)				
	a.	One Character CDC	●	○	Choose 1
	b.	Two Character CDC	○	●	
	c.	No CDC3	Remove Card Pin		

			Strap 31	
9-19.	Answer-Back to CDC (See Option 9-19, Card A.)			
	a.		—	Choose 1
	b.		—	
	c.		—	Choose 1
	d.		—	
	e.	Answer - Back to CDC3 Always	○	Choose 1
	f.	Answer - Back to CDC3 When Ready to Receive	●	

See Legend for ○, ●, — and * on Page 98.

322685 — CDC Detector (A2) — Card Position A

Note: This card is required for 1800 or 2400 baud operation. Options are the same as A card (322010).

322011 — R/T Distributor (B) — Card Position B

9-3.	Unit Code of Answer-Back Characters Sent	Strap 13	
a.	10-Unit Code	O	Choose 1
b.	11-Unit Code	●	
9-5.	Code Level of Characters Sent	Strap 30	
a.	8-Unit Code	●	Choose 1
b.	7-Unit Code or Less	O	
9-8.	Regeneration of Sent Data (Requirements of Options 9-6c -- 9-6f Override Option 9-8.) (See Option 9-6, Card D1.)	Strap 26	
a.	No Regeneration	O	Choose 1
b.	Regeneration	●	

Note: ROP applications require Option 9-8.b.

See Legend for O , ● , — and * on Page 98.

H. 9140 CONTROLLER OPTIONS (Contd)

322013 — Receive Control Logic (C2) — Card Position C



322442 — A/B and Motor Control (C2-2) — Card Position, Piggyback to C2



H. 9140 CONTROLLER OPTIONS (Contd)

322014 — Send/Receive Logic (D1) (See Note 3) — Card Position D



	9-1. Variable Character (See Below)	Coding Instructions	
e.	Transmitter On (Recommend DC1)		Choose 1
f.	Transmitter Off (Recommend EOT)		
g.	Acknowledge (Recommend ACK)		
i.	Transmitter Start Code (TSC) Character 1		
j.	Transmitter Start Code (TSC) Character 2		
	Cut straps labeled "M" for levels that are marking. Cut straps labeled "S" for levels that are spacing. Every level must have one strap cut.		

9-2.	Number of Characters in TSC	Strap 52	
a.	Two Characters	○	Choose 1
b.	Two Characters Followed by Delete	●	

		Straps		
9-6.	HDX or FDX Stop Sending (See Note 2, Page 105.)	14	53	
a.	Stop on "SENT" Interrupt and EOT, Requires Option 9-8.b	○	○	Choose 1
b.	No Stopping of Sender	○	●	

See Legend for ○ , ● , and — on Page 98.

322014 — Send/Receive Logic (D1) (See Note 2) — Card Position D (Cont)

			Strap 15	
9-7.		Local Copy on ROP of KD Send Data (KD & ROP Arrangements)		
	a.	Local Copy (Can be Used for KD & ROP)	○	Choose 1
	b.	No Local Copy (May be Overridden by Options3) (Choose for Other Arrangements or KD & ROP, if Desired)	●	

			Strap 34	
9-9.		Interrupt Feature (See Note 2 below.)		
	a.	Stop on Interrupt Character and Blind Receive Data, Start on STX.	●	Choose 1
	b.	Does not Stop on Interrupt Character	○	
			Strap 51	
9-10.		Function of EOT Sent by Terminal		
	a.	EOT Deselects 9140 Sender	●	Choose 1
	b.	EOT Does Not Deselect Sender	○	

Note 1: If Option 9-10.a. is used, also use 9-8.b. and KD Option 4-8.e.

Note 2: If Option 9-1.a. is selected, Option 9-6.a. must also be used. Straps 53 and 34 must not both be closed with straps.

Note 3: The RO Logic Card (D2) 303734 has no options.

See Legend for ○ , ● , and — on Page 98.

H. 9140 CONTROLLER OPTIONS (Contd)

322451 — EIA Interface (E2) — Card Position E



322017 — Character Recognition (F1) — Card Position F1



9-25.	9140 Recognition of SOH and ETX	Straps 64 | 65 | 66
a.	SOH Only (See Note 1)	● ○ ○
b.	ETX Only (Action of ETX Requires Local Engineering)	○ ● ○
c.	Both SOH and ETX	○ ○ ○
d.	Neither SOH nor ETX (Recommended)	○ ○ ●

Choose 1

Note 1: If customer requires SOH to act like STX, strap XZF-B29 to XZF-B31.

Note 2: Option 9-25 choice has no effect on selection of ETX as INTERRUPT character.

322018 — Substitute Character — Card Position F2

9-1.	Variable Character	Coding Instructions
4.	Substitute Character	

Cut straps corresponding to marking levels
Close straps corresponding to spacing levels

9-25.	9140 Recognition of SOH and ETX	Straps 64 | 65 | 66
a.	SOH Only (See Note 1, Card F1)	● ○ ○
b.	ETX Only (Action of ETX Requires Local Engineering)	○ ● ○
c.	Both SOH and ETX	○ ○ ○
d.	Neither SOH and ETX	○ ○ ●

Choose 1

Note: This F2 card is ordered separately and is not required unless a substitute character other than Sp is desired for KD or other than font ID character for printer.

See Legend for ○ , ● , and — on Page 38.

H. 9140 CONTROLLER OPTIONS (Contd)

322083 — Channel Control (G3) — Card Position G



		Straps				
9-11.	Delay in Turning Off Carrier	69	70	71	72	
a.	Retain Until Last Character Is Sent	●	●	○	●	Choose 1
b.	Retain for One Character After Interrupt	●	○	●	○	
c.	Retain for Three Characters After Interrupt	○	○	●	○	

322641 — Answer-Back and Alarm — Card Position, Piggyback to G3 (Part of Alarm/Parity Error Response 345625 Modification Kit)



		Straps		
9-27.	Alarm Time and Reset on STX or EOT	X	Y	Z
a.	30-Second Alarm (See Note below.)	—	○	○
b.	60-Second Alarm (See Note below.)	—	●	○
c.	90-Second Alarm (See Note below.)	—	●	●
d.	Initialize Optional A/B Circuit on STX or EOT	●	—	—
e.	Initialize Optional A/B Circuit on EOT	○	—	—

Choose 1

Choose 1

Note: Audible Alarm on receipt of CDC is not ready to receive (DTR off).

See Legend for ○, ●, and — on Page 98.

322642 – 2400 Baud, Isochronous, Parity Detect and Alarm – Card Position, Piggyback to G3 (Part of 402236 Modification Kit)



		Straps	
9-8.	Regeneration of Sent Data (See Option 9-8, Cards B and E2.)	V	W
a.	No Regeneration	●	○
b.	Regeneration	○	●

Choose 1

		Straps		
9-27.	Alarm Time and Reset on STX or EOT	V	W	X
a.	30-Second Alarm (See Note below.)	–	○	○
b.	60-Second Alarm (See Note below.)	–	●	○
c.	90-Second Alarm (See Note below.)	–	○	●
d.	Initialize Optional A/B Circuit on STX or EOT	●	–	–
e.	Initialize Optional A/B Circuit on EOT	○	–	–

Choose 1

Choose 1

Note: Strap 74 on C2-2 card must be closed to use this modification kit.

See Legend for ○, ●, and – on Page 98.

I. INDIVIDUAL RECEIVER SELECTION (IRS) MODIFICATION KIT OPTIONS

344553 – Individual Receiver Selection – (Part of 344555 Modification Kit, 508008 Specification)



Basic Arrangements:

(a) KD+ROP† (ROP† = Primary Receiver); (KD = Secondary Receiver).

(b) KDP+ROP† (ROP† = Primary Receiver); (KDP = Secondary Receiver).

(c) KD-ROP+ROP† (ROP† = Primary Receiver); (KD-ROP = Secondary Receiver).

Optional Modifications:

(a) Six load interchanged in the IND REC connector of the 344545 cable; required to convert ROP† to Secondary and KD to Primary Receivers.

Color	From Pin	To Pin
White-Blue	10-Primary RD	16-Secondary RD
White-Red-Red	16-Secondary RD	10-Primary RD
White-Orange	24-Primary DTR	18-Secondary DTR
White-Red-Brown	18-Secondary DTR	24-Primary DTR
White-Red-Orange	14-Primary DSR	22-Secondary DSR
White-Black	22-Secondary DSR	14-Primary DSR

(b) "A" Strap: Controls Primary DSR "Off" when the station is in the (STS) Selected to Send mode — used for HDX operation only.

(c) Cut circuit land (component side) from MLC2-11 to MLA2-12 and MLA1-8. Remove Secondary DSR when the station is in the (STS) Selected to Send Mode. KD will not send with DSR "On" for HDX or FDX operation.

(d) Add wire strap (noncomponent side) between MLC2-11 and MLA1-2. Controls Primary DSR "Off" when Selected to Send is "On" — used for HDX operation only.

(e) X-TERM connector (to KD with Ptr/ROP) lead change: Remove pin 19 White-Red and tape back. Remove pin 6 White-Red-Orange and reposition lead to 19. This removes Secondary DSR when Primary Receiver is Selected. KD will not send with DSR "On". Selected to Receive controls Secondary DSR.

(f) Add wire strap (noncomponent side) between MLD1-1 and MLC2-11. This controls Secondary (RD) Received Data to monitor "Sent Data" when the station is in the (STS) Selected to Send mode. The ROP† is the Secondary receiver.

Application compatibility of modifications:

Note 1: It is not recommended to have ROP† a Secondary Receiver because "No-Traffic\" replies "Ready (Not Ready" reflect the Primary Receiver status and NOT to be used in FDX operation.

Note 2: This modification kit requires 3 character CDC codes having DELETE as the third character. Example: ALPHA ALPHA DELETE.

	ROP† — Primary			ROP† — Secondary	
	KD+ROP† ROP† Monitor's Sent Data	KD+ROP† KD-P/ROP+ROP† ROP† Does Not Monitor Sent Data		KD+ROP† ROP† Monitor's Sent Data	KD+ROP† KD-P/ROP+ROP† ROP† Does Not Monitor Sent Data
		HDX	FDX		
(a) IND REC Interchange	No	No	No	Yes	Yes
(b) "A" Strap	Open	Open	Open	Closed	Closed
(c) Cut Circuit Land	No	Yes	Yes	No	Yes
(d) Add DSR Wire Strap	No	Yes	No	No	Yes
(e) S/R X-TERM Change	No	Yes	Yes	No	Yes
(f) Add RD Wire Strap	No	No	No	Yes	No

J. 40/3 STATION FEATURES AND OPTIONS RECORD

The Station Features and Options Record provides a means by which the options and special features in the 40/3 can be recorded and kept with the station for later servicing or maintenance purposes.

☑ Check desired options.

KD, KDP, ROP Options

4-1. Interface to Printer
- ☐ a. EIA
- ☐ b. SSI*

} Choose 1

4-3. EIA Send/Receive Data Baud Rate
- ☐ a. 1050
- ☐ b. 1200*
- ☐ c. 2400 (See Note)

} Choose 1

Note: 402326 modification kit is required in 9140 for 2400 baud operation.

4-4. EIA Reverse Channel
- ☐ a. Reverse Channel Required to Send
- ☐ b. Reverse Channel Not Required to Send*

} Choose 1

4-5. Response to Received Characters
- ☐ a. Reject Null*
- ☐ b. Accept Null
- ☐ c. Reject CR*
- ☐ d. Accept CR
- ☐ e. Reject Delete*
- ☐ f. Accept Delete
- ☐ g. Reject DC1*
- ☐ h. Accept DC1
- ☐ i. Reject DC3*
- ☐ j. Accept DC3

} Choose 1

} Choose 1 — (Applies to Issues 4B and later of the 410674 circuit card only.)

} Choose 1

4-6. Functions Receive
- ☐ a. All ESC Seq Displayed as Received (Function Not Performed)
- ☐ b. All ESC Seq Are Performed as Received But Not Displayed*

} Choose 1

4-7. Errored Character on Receive
- ☐ a. Not Displayed on Vertical Parity Error
- ☐ b. Displayed on Vertical Parity Error*

} Choose 1

4-8. Page (Message) Ending Character Functions on Send
- ☐ a. End on FF
- ☐ b. Do Not End on FF*

} Choose 1

- ☐ c. End on ETX*
- ☐ d. Do Not End on ETX

} Choose 1

- ☐ e. End on EOT*
- ☐ f. Do Not End on EOT

} Choose 1

- ☐ g. End on GS*
- ☐ h. Do Not End on GS

} Choose 1

4-9. Highlight
- ☐ a. Delimiters Not Sent (Except in Form Send Mode)
- ☐ b. Delimiters Sent (Modifies Option 4-13)*

} Choose 1

*Indicates factory programmed option.

☑ Check desired options. (Contd)

KD, KDP, ROP Options (Contd)

4-10. Line Ending Sequence
- ☐ a. CF LF
- ☐ b. CR CR LF* } Choose 1
- ☐ c. LF*

4-11. Mode After Send
- ☐ a. Local* (See Note)
- ☐ b. Receive } Choose 1
- ☐ c. EXT Mode (Not Used on 40/3-Type Stations)

Note: If EOT is message-ending character, the mode after sending is always RECEIVE.

4-12. Form Enter
- ☐ a. Disable in Local
- ☐ b. Enabled in Local* } Choose 1

4-13. Send Variations (All Without Delimiters Except as Modified by Option 4-9.b.). In Form Send, Protect and Unprotect Sent as Displayed With Delimiters.
- ☐ a. Send All as Displayed
- ☐ b. Send All as Displayed with Unprotected HT to Space*
- ☐ c. Send Protect as Space and Unprotected as Displayed
- ☐ d. Send Protect as Space and Unprotected as Displayed, HT to Space
- ☐ e. Send Protect as Delete, Unprotected as Displayed
- ☐ f. Send Unprotected Only as Displayed
- ☐ g. Send Unprotected Only and HT at End of Field
- ☐ h. Send Unprotected Only With Unprotected HT to Space

} Choose 1

*Indicates factory programmed option.

J. 40/3 STATION FEATURES AND OPTIONS RECORD (Contd)

☑ Check desired options. (Contd)

KD, KDP, ROP Options (Contd)

4-17. Printer Left Margin and Form Width

- ☐ a. First Printed Column — Column 1*
- ☐ b.2. First Printed Column — Column 2
- ☐ b.3. First Printed Column — Column 3
- ☐ b.4. First Printed Column — Column 4
- ☐ b.5. First Printed Column — Column 5
- ☐ b.6. First Printed Column — Column 6
- ☐ b.7. First Printed Column — Column 7
- ☐ b.8. First Printed Column — Column 8
- ☐ b.9. First Printed Column — Column 9
- ☐ b.10. First Printed Column — Column 10
- ☐ b.11. First Printed Column — Column 11
- ☐ b.12. First Printed Column — Column 12
- ☐ b.13. First Printed Column — Column 13

Choose 1 — These options applicable only to printers equipped with 410071, 410072 and 410076 circuit cards.

Printer Right Margin and Form Width

- ☐ c. Last Character on Column 80*
- ☐ d.79. Last Character on Column 79
- ☐ d.78. Last Character on Column 78
- ☐ d.77. Last Character on Column 77
- ☐ d.76. Last Character on Column 76
- ☐ d.75. Last Character on Column 75
- ☐ d.74. Last Character on Column 74
- ☐ d.73. Last Character on Column 73
- ☐ d.___ Last Character on Column___
- ☐ e. Last Character on Column 132*
- ☐ f.131. Last Character on Column 131
- ☐ f.130. Last Character on Column 130
- ☐ f.129. Last Character on Column 129
- ☐ f.128. Last Character on Column 128
- ☐ f.127. Last Character on Column 127
- ☐ f.126. Last Character on Column 126
- ☐ f.125. Last Character on Column 125
- ☐ f.124. Last Character on Column 124
- ☐ f.123. Last Character on Column 123
- ☐ f.122. Last Character on Column 122
- ☐ f.121. Last Character on Column 121
- ☐ f.___ Last Character on Column___

Choose 1

Note: The number of right margin options available depends on the printer logic card accompanying the printer.

CARD NO.	RIGHT MARGIN OPTIONS
410071	c, d.25 through d.79
410072	e, f.73 through f.131
410076	c, d.25 through d.79
410640	c, d.73 through d.79
410729	e, f.121 through f.131

*Indicates factory programmed option.

☑ Check desired options. (Contd)

KD, KDP, ROP Options (Contd)

4-18. Printer Paper Feedout
- ☐ a. No Paper Feedout
- ☐ b. Paper Feedout on DCD or RM Loss — 16 Lines or One Form
- ☐ c. Paper Feedout on DCD or RM Loss or ETX — 16 Lines or One Form*

Choose 1

4-19. Printer Errored Character Symbol
- ☐ a. Printed on Even Parity Error*
- ☐ b. Printed on Odd Parity Error
- ☐ c. No Printed on Parity Error
- ☐ d. Printers With 96-Character Set
- ☐ e. Printers With 64-Character Set
- ☐ f. Printers With Extended ASCII Character Set
- ☐ g. Printers With Longest Character Set Having Less Than 64 Characters

Choose 1

Choose 1 (Must match type carrier ordered)

4-20. Line Feed on Printer
- ☐ a. Single*
- ☐ b. Double

Choose 1

4-21. Foldover on Up-Low Printer
- ☐ a. Lower Case and Upper Case Print*
- ☐ b. Lower Case Prints as Upper Case

4-22. Foldover on Monocase Printer
- ☐ a. Lower Case Prints as Error Symbol
- ☐ b. Lower Case Prints as Upper Case*

Choose 1 (Per type carrier ordered)

4-23. Extended ASCII on Printer
- ☐ a. Prints Extended ASCII Characters
- ☐ b. Does Not Print Extended ASCII*

For future use — do not change.

4-24. Controller Parity Detection (ROP)
- ☐ a. Even Vertical Parity*
- ☐ b. Odd Vertical Parity

Choose 1

4-25. Parity Error Response (ROP)
- ☐ a. Odd Parity Null Sent to Printer
- ☐ b. Received Character Sent to Printer*

Choose 1

- ☐ c. Data Error Lamp Turns on
- ☐ d. Data Error Lamp Dos Not Turn On*

Choose 1

4-27. Message Start
- ☐ a. Home on Transmit
- ☐ b. Send From Cursor*

Choose 1

4-28. Disconnect on Loss of Carrier
- ☐ a. Disconnect After 45 Seconds
- ☐ b. Does Not Disconnect — Timer Disabled*

Choose 1

4-29. Printer Message Mode
- ☐ a. Copies Display in Send, Copies in Receive or Local*
- ☐ b. Not Used on 40/3 Stations
- ☐ c. Not Used on 40/3 Stations
- ☐ d. When in Print On-Line, Copies Received Data in Receive or Local

Choose 1

*Indicates factory programmed option.

J. 40/3 STATION FEATURES AND OPTIONS RECORD (Contd)

☑ Check desired option., KD, KDP, ROP Options (Contd)

4-29. Printer Message Mode (Contd)

Note: Options 4-29.b. and 4-29.c. are not applicable for this arrangement. With Option 4-29.d. installed and PRINT ON LINE key lighted and if SEND is depressed, the printer motor will start. When polled the PRINT ON LINE light will go out but the motor stays on. At end of message when SEND light goes out, the PRINT ON LINE will light and motor stops. If the printer is optioned for Option 4-18.b. or 4-18.c., a 16-line feedout or form feed will occur in addition feed printer will feedout, but a tractor feedout or form feed — whichever is shorter). If this feedout is not desired, specify Option 4-18.a. and requirement that received messages include repeated NLs (with appropriate time fills) or form feeds (whichever applies). Option 4-18.a. does not affect the printer motor running when sending.

4-30. Message Preparation
- ☐ a. Automatic Home on Message-Ending Character* — Choose 1
- ☐ b. Manual Home on Message-Ending Character

4-31. KD Forced to Receive Mode (When ALARM Lead is On.)
- ☐ a. Independent of Printer Mode* — Choose 1
- ☐ b. Dependent on Printer Mode

4-32. Printer Access From Line (When PRINT ON LINE Lamp is On)
- ☐ a. If KD is in Send, Receive, or Local Mode* — Choose 1
- ☐ b. If KD is in Receive Mode or Local Mode

4-33. 9140 Station Controller Mode
- ☐ a. Full Duplex (FDX) — CTS Controls RTS — Choose 1
- ☐ b. Half-Duplex (HDX) — CTS Does Not Control RTS*

Note: If operation of system is such that the computer immediately receives an answer-back after the system sends a message and Option 4-33.b. is chosen, change to Option 4-33.a. Option 4-33.a. will not allow this answer-back to occur, but should not be selected unless the "automatic" answer-back is used.

4-34. Control Signal Restrictions
- ☐ a. RTS Signal Can Turn On When STR is On* — Choose 1
- ☐ b. RTS Cannot Turn On if STR is On

4-35. Printer Motor Control (ROP)
- ☐ a. "Data Set Ready" Controls Printer Motor* — Choose 1
- ☐ b. "Carrier Detect" Controls Printer Motor

4-36. Printer Paper Alarm (ROP)
- ☐ a. Paper Alarm Turns Off "Data Terminal Ready" at End of Call; DTR Held Off Until Paper is Restored.* — Choose 1
- ☐ b. Paper Alarm Turns Off "Data Terminal Ready" Immediately. DTR Off Until Paper is Restored.

4-37. Requirement for Sending
- ☐ a. Clear-To-Send (CTS) Required for Sending* — Choose 1
- ☐ b. CTS Not Required for Sending

*Indicates factory programmed option.

☑ Check desired options. (Contd)

KD, KDP, ROP Options (Contd)

4-38. Data Stacking (ROP)
☐ a. Enabled Data Stacking
☐ b. Disable Data Stacking* } Choose 1

Note: Must use Option 4-38.a. if 40C103/AE Controller is used.

4-39. Forms (Tractor Feed Only)
☐ a. On (See Note)
☐ b. Off* } Choose 1

Note: Form feed will not occur if printer is on first line of a form.

4-40. Go Receive on Sending CR (←)
☐ a. Not Used on 40/3-Type Stations
☐ b. Do Not Go Receive on Sending CR*

Note: Option on Issue 4B and later of the 410674 circuit card.

4-48. Incomplete Form Suppresses Paper Alarm
☐ a. No (Paper-Out Not Gated with Form Feed)
☐ b. Yes (Paper-Out Gated With Form-Out) (See Note.)* } Choose 1

Note: Option 4-48.b. delays paper alarm until end of form-out.

4-50. Action Upon Printer SSI Loss
☐ a. Go Local and Hold
☐ b. Go Local and Release
☐ c. No Mode Change* } Choose 1

Note 1: PRINT ON LINE is turned off in Options 4-50.a., 4-50.b., or 4-50.c.

Note 2: Card issues before 3A will not change mode if SSI fails, PRINT ON LINE also stays on with card Issue 1 and turns off with card Issue 2.

Note 3: Options 4-50. through 4-53. apply to Issue 3A or later 410770 card.

4-51. Remote Control
☐ a. 4210 character control*
☐ b. 9140 Print-on-Line Control For Split Operation
☐ c. Not Used on 40/3-Type Stations } Choose 1

Note 1: Card issues before 3A are permanently equipped with Option 4-51.a.

Note 2: If both options 4-51.b. and 4-53.a. are required, cut Strap A (land on component side between coordinates B1 and B2). Otherwise have Strap A intact.

4-52. Print On Line Control
☑ a. Copy All Sent Data
☐ b. Printer Copies as Option 4-29.* } Choose 1

Note: PRINT ON LINE is automatically turned on when SEND is lighted for Option 4-52.a. Card issues before 3A are permanently equipped with Option 4-52.b.

*Indicates factory programmed option.

J. 40/3 STATION FEATURES AND OPTIONS RECORD (Contd)

☑ Check desired options. (Contd)

KD, KDP, ROP Options (Contd)

4-53. Printer Motor Hold Timer
- ☐ a. Enabled
- ☐ b. Disabled* } Choose 1

Note: With Option 4-53.a., printer motor is held on for two minutes following end of message (useful for messages less than 2 minutes apart). Card issues before 3A are permanently equipped with Option 4-53.b.

4-54. Printing of Escape Sequences Suppressed
- ☐ a. Character After ESC Printed as Received* } Choose 1
- ☐ b. Printing of Character After ESC Suppressed

Note: Option 4-54.b. should not be used on a KDP set. The character after escape is already suppressed by the KD in SSI operation but not in EIA operation.

4-55. Shift-In/Shift/Out Detection
- ☐ a. SI/SO Detection Not Used* } Choose 1
- ☐ b. SI/SO Detection Enables Printing Additional Characters

Note: This option not present on 410640 and 410729 printer circuit cards.

4-56. Friction Feed/Tractor Feed Printer — 410076 Card Only
- ☐ a. Friction Feed Printer — Motor Held On After Paper Alarm* } Choose 1
- ☐ b. Tractor Feed Printer — Motor Turned Off After Paper Alarm

4-57. SSI/OEM Interface
- ☐ a. SSI*
- ☐ b. Not Used On 40/3-Type Station

Note: This option not present on 410640 and 410729 printer circuit cards.

4-58. Idle Line Motor Control
- ☐ a. Disabled — Motor Held On Indefinitely During Idle Line* } Choose 1
- ☐ b. Enabled — Motor Turned Off After 40-Second Idle Line

Note: This option not present on 410640 and 410729 printer circuit cards.

4-59. Speed Selection (Applies Only if Option 4-57.b. is selected, Therefore, Does Not Apply For 40/3 Stations.)
- ☐ a. 75 Baud
- ☐ b. 150 Baud
- ☐ c. 300 Baud
- ☐ d. 600 Baud
- ☐ e. 1200 Baud
- ☐ f. 2400 Baud*
- ☐ g. 4800 Baud
- ☐ h. 9600 Baud

4-60. Aux Alarm
- ☐ a. Enabled
- ☐ b. Disabled (Or Alarm Mechanism Not Present)* } Choose 1

Note: This option not present on 410640 and 410729 printer circuit cards.

*Indicates factory programmed option.

☑ Check desired options. (Contd)

KD, KDP, ROP Options (Contd)

4-61. Regulator Grounding (Circuit Ground to Frame Ground)
- ☐ a. SSI (CKT and FR GND at PTR)
- ☐ b. SSI/OEM (CKT and FR GD at PTR, +12 V)* } Choose 1
- ☐ c. OEM (CKT GND EXT to PTR, +12 V)

9140 Station Controller Options

9-1. Variable Characters (Enter Characters Chosen in the Boxes Provided)
- ☐ a. Answer-Back (A/B) Character 1
- ☐ b. A/B Character 2
- ☐ c. A/B Character 3
- ☐ d. A/B Character 4
- ☐ e. Transmitter On (X-ON) Character (DC1 Recommended)
- ☐ f. Transmitter Off (X-OFF) Character (DC3 Recommended)
- ☐ g. Acknowledge (ACK) Character (ACK Recommended)
- ☐ h. Interrupt Character (ETB Recommended)
- ☐ i. TSC (Transmitter Start Code) Character 1 (DC3 Recommended)
- ☐ j. TSC Character 2
- ☐ k. CDC (Call Directing Code) No. 1, Character 1
- ☐ l. CDC No. 1, Character 2
- ☐ m. CDC No. 2, Character 1 } See Note 1
- ☐ n. CDC No. 2, Character 2
- ☐ o. CDC No. 3, Character 1 } See Note 2
- ☐ p. CDC No. 3, Character 2
- ☐ q. Sub Character (Only When Substitute Character Other Than Sb is Required).

Note 1: If only one CDC is required, code CDC2 identical to CDC1.

Note 2: Applies only if circuit card A-1 is present. This card must be ordered separately if 3rd CDC is required.

9-2. Number of TSC Characters
- ☐ a. Two Characters } Choose 1
- ☐ b. Two Characters Followed by Delete

9-3. Unit Code of A/B Sent
- ☐ a. 10-Unit Code } Choose a.
- ☐ b. 11-Unit Code

9-4. Unit Code of Characters Sent
- ☐ a. 10-Unit Code } Choose a.
- ☐ b. 11-Unit Code

9-5. Code Level of Characters Sent
- ☐ a. 8-Level Code } Choose a.
- ☐ b. 7-Level Code or Less

*Indicates factory programmed option.

J. 40/3 STATION FEATURES AND OPTIONS RECORD (Contd)

☑ Check desired options. (Contd)

9140 Station Controller Options (Contd)

9-6. HDX or FDX Sending
- ☐ a. Stop on "SENT" Interrupt and EOT, Requires Option 9-8b.
- ☐ b. No Stopping of Sender

} Choose 1

9-7. Local Copy on ROP of KD Sent Data (KD & ROP Application)
- ☐ a. Local Copy
- ☐ b. No Local Copy

} Choose 1

Note: Option 9-13.a. overrides Option 9-7.b.

9-8. Regeneration of Sent Data
- ☐ a. No Regeneration
- ☐ b. Regeneration

} Choose 1

Note: Do not use Option 9-8.a. in ROP stations.

9-9. Interrupt Feature
- ☐ a. Stop on Interrupt Character, Blind Receive Data and Start on STX
- ☐ b. Does Not Stop on Interrupt Character

} Choose 1

Note: If Option 9-9.a. is selected, Option 9-6.a. must also be selected. Straps 53 and 54 must not both be closed with straps.

9-10. Function of EOT Sent by Terminal
- ☐ a. EOT Deselects 9140 Sender
- ☐ b. EOT Does Not Deselect Sender

} Choose 1

Note: If 9140 Station Controller Option 9-10.a. is selected, also use KD Option 4-8.b. and 4-8.e.

9-11. Delay in Turning Off Carrier
- ☐ a. Retain Until Last Character is Sent
- ☐ b. Retain for One Character After Interrupt
- ☐ c. Retain for Three Characters After Interrupt

} Choose 1

9-12. First or Second A/B Character Restarts Sender
- ☐ a. Second A/B Character Restarts Sender
- ☐ b. Should Not be Used in 40/3-Type Applications

9-13. Local Copy of Sent Data Provided/Not Provided by 9140 (Note 1)
- ☐ a. Copy All Sent Data and CPU Responses
- ☐ b. Copy Sent Data After STX is Sent

} Choose 1

Note 1: Option 9-13. has no effect on FDX operation. KD-ROP applications are affected by Option 9-13.

Note 2: If Option 9-13.a. is selected, local copy will be obtained regardless of status of Option 9-7., provided the PRINT ON LINE key on the opcon is lighted.

9-14. Number of Characters in CDC1
- ☐ a. One Character CDC
- ☐ b. Two Character CDC

} Choose 1

Note: Number of characters in the option is exclusive of Delete, if used (see Option 9-17.).

☑ Check desired options. (Contd)

9140 Station Controller Options (Contd)

9-15. Number of Characters in CDC2 (See Note After Option 9-14.)
- ☐ a. One Character CDC
- ☐ b. Two Character CDC
- ☐ c. No CDC2

} Choose 1

Note: If Option 9-15.c. is selected, code CDC2 identical to CDC1.

9-16. Number of Characters in CDC3 (See Note After Option 9-14.)
- ☐ a. One Character CDC
- ☐ b. Two Character CDC
- ☐ c. No CDC3

} Choose 1

Note: CDC3 requires A-1 circuit card.

9-17. Answer-Back Generated for CDCs (See Note 1.)
- ☐ a. A/B to CDC1
- ☐ b. A/B to CDC1 After Delete
- ☐ c. No A/B to CDC1
- ☐ d. A/B to CDC2
- ☐ e. A/B to CDC2 After Delete
- ☐ f. No A/B to CDC2
- ☐ g. A/B to CDC3
- ☐ h. A/B to CDC3 After Delete
- ☐ i. No A/B to CDC3

} Choose 1

} Choose 1

} Choose 1 (See Note 2)

Note 1: All items of Option 9-17. should be consistent. All CDCs either use Delete or do not use Delete.

Note 2: If circuit card A-1 is not used, Option 9-17.g., 9-17.h. and 9-17.i. are not functional.

9-18. Type of A/B to TSC
- ☐ a. Same as Ready to Receive A/B to CDC when DTR is On
- ☐ b. Same as Ready to Receive A/B to CDC Independent of DTR

} Choose 1

Note: Data Terminal Ready (DTR) signal from KD is affected by low paper only if the printer is available to copy on-line (PRINT ON LINE key light lighted). It is affected by the mode of the KD portion (LOCAL or RECEIVE key lighted) only if the printer is not available (PRINT ON LINE key not lighted).

9-19. Answer-Back to CDC (See Option 9-17)
- ☐ a. A/B to CDC1 Always
- ☐ b. A/B to CDC1 When Ready to Receive
- ☐ c. A/B to CDC2 Always
- ☐ d. A/B to CDC2 When Ready to Receive
- ☐ e. A/B to CDC3 Always
- ☐ f. A/B to CDC3 When Ready to Receive

} Choose 1

} Choose 1

} Choose 1 (See Note 1)

Note 1: If circuit card A-1 is not used, Options 9-19.e. and 9-19.f. need not be specified.

Note 2: Only one station in a group can be programmed to A/B to a group CDC.

Note 3: Options 9-19.a., 9-19.c. and 9-19.e. are recommended since Option 9-17. overrides Option 9-19.

J. 40/3 STATION FEATURES AND OPTIONS RECORD (Contd)

☑ Check desired options. (Contd)

9140 Station Controller Options (Contd)

9-20. Optional Answer-Back to CDC or TSC
- ☐ a. Optional Negative A/B
- ☐ b. Optional Positive A/B (CDC Only)
- ☐ c. No Optional A/B

} Choose 1

Note: If the 9140 Station Controller is equipped with a 345625 alarm/parity error modification kit that provides an audible alarm and the ability to initiate the optional A/B during post message recall use Option 9-20.b.

9-21. Response Delay for Motor Start-Up
- ☐ a. Nominal 2-Second Delay
- ☐ b. Nominal 200-Millisecond Delay

} Choose 1

9-22. Received Vertical Parity Error Response
- ☐ a. Odd Parity Causes Line Break
- ☐ b. Odd Parity Does Not Cause Line Break

} Choose 1

9-23. Loss of DTR Response
- ☐ a. Loss of DTR Causes Line Break
- ☐ b. Loss of DTR Does Not Cause Line Break

} Choose 1

9-24. Type of F Card Used
- ☐ a. F1 Circuit Card
- ☐ b. F2 Circuit Card

} Choose 1

9-25. 9140 Recognition of SOH and ETX
- ☐ a. SOH Only
- ☐ b. ETX Only
- ☐ c. Both SOH and ETX
- ☐ d. Neither SOH nor ETX

} Choose 1

9-26. Data Set Interface
- ☐ a. Gate Data Set Clear-To-Send (CTS) With 9140 Request-To-Send (RTS) to Produce M40 CTS.
- ☐ b. Do Not Gate CTS of Data Set With 9140 Signals.

} Choose 1
- ☐ c. Gate Data Set Data-Set-Ready (DSR) With 9140 Data-Terminal-Ready (DTR) to Produce Data Set RTS.
- ☐ d. Do Not Gate DSR of Data Set With 9140 Signals.

} Choose 1

Note: 202R Data Set furnishes CTS and DSR, and uses Request-To-Send (RTS), produced by Option 9-26.c.

9-27. Alarm Time and Reset on STX or EOT
- ☐ a. 30-Second Alarm
- ☐ b. 60-Second Alarm
- ☐ c. 90-Second Alarm
- ☐ d. Resets Optional A/B on STX or EOT
- ☐ e. Resets Optional A/B on EOT Only

} Choose 1

Note: Audible alarm sounds on receipt of CDC if not ready to receive (DTR off).

PART 5 -- TESTING AND TROUBLESHOOTING
A. GENERAL

This section provides the testing and troubleshooting procedures for the Model 40/3 Station arrangements. This section does not provide information on testing all associated modification kits. Refer to the appropriate 50,000 Specification for information on testing the modification kits.

When ordering or referring to replaceable parts or components, unless otherwise specified, prefix each part number with the letters "TP" (ie, TP410055).

An operational checkout should be performed after installation or on trouble calls. It may be a brief checkout to make sure the station is operable, or a complete checkout to exercise all features and options. Both types of checkout are provided. Since off-line checkout procedures do not check the interface or send and receive capabilities, an on-line test with the station interfaced to the customers system should be performed. Check all operational modes when sending to and receiving from the system, taking into account all option and feature variables.

Use the brief checkout upon installation, if a complete checkout has been performed prior to installation. Continue with a complete checkout, if needed, to check all features and options.

On maintenance or trouble calls at a location, confine the checkout to the specified trouble area. Use the brief checkout to isolate poorly defined trouble areas. Perform a complete checkout after an extensive repair.

The checkout routines are presented in tables. Each table is identified as to the type of station under test, and the nature of the checkout procedures.

If the indicated response is not obtained in any step of a checkout procedure, repeat the step to make sure that the procedure has been performed correctly. If the results are still unsatisfactory, perform the indicated trouble analysis. Always perform the checkout in the order given in the table. The trouble analysis steps are based on satisfactory results of all previous steps.

As a further aid to troubleshooting, refer to PART 6 -- WIRING DIAGRAMS of this manual. When detailed information regarding trouble analysis, disassembly/reassembly or piece parts is required for individual components such as the keyboard, printer, etc, refer to the appropriate publication listed in Part 1 of this manual.

In reference to options, a prefix 4 indicates the option pertains to the KD (or KDP) logic controller, the printer logic or the ROP logic controller. A prefix 9 indicates the option pertains to the 9140 Station Controller.

Example: Option 4-17.a.
Option 9-17.a.

B. PRELIMINARY CHECK

Before turning on any equipment, check the following:

(a) Is station connected to a properly grounded ac service?

(b) Are all circuit cards and cable connectors fully seated?

(c) Are all cabinet lids and pedestal doors closed?

(d) In KDP and ROP, are printer paper and ribbon properly installed?

In addition to the above, check J. 40/3 STATION FEATURES AND OPTIONS CHART to determine the options and features present in the station. In cases where the results are affected by options, alternate results for each option are provided in the tables.

C. BRIEF OFF-LINE CHECKOUT

The brief off-line checkout is provided in Table A. Use the brief checkout just to make sure that the station is operable. The brief checkout does not exercise all the features and options. If these should also be checked, perform Complete Off-Line Checkout in Table B or C.

D. OFF-LINE CHECKOUT

Off-line checkout provides a check of the operating condition of the 40/3-type terminal. Table A provides a brief off-line checkout for KD and KDP terminals. Table B provides a complete off-line checkout for KD and KDP terminals. Table C provides off-line checkout for ROP terminals. The off-line checkout should be performed before attempting any on-line procedures.

TABLE A

BRIEF OFF-LINE CHECKOUT – KD AND KDP TERMINALS*

STEP	PROCEDURE	RESULTS	TROUBLE ANALYSIS
1	Turn on power switches.	LOCAL indicator lights. Fans operate.	Terminal Analysis, Table D (Page 147)
2	Turn on power to monitor and set brightness to maximum.	Within 10 seconds, raster appears. *Note:* If random characters appear or if cursor is not at home position, depress HOME and CLEAR keys.	Terminal Analysis, Table D (Page 147) Manual 401, Model 40 Display Monitor
3	Adjust brightness and tube tilt to personal preference.	Cursor and segment marker clearly displayed, with raster barely visible. Glare from external light on screen should be minimal.	Manual 401, Model 40 Display Monitor
4	Lightly depress cursor right (→), down (↓), left (←), and up (↑), in that order.	Cursor moves one position in the direction indicated for each depression.	Terminal Analysis, Table D (Page 147)
5	Repeat Step 4, but depress cursor controls fully and hold depressed until cursor stops moving.	Cursor traces outer perimeter of display, stopping at each corner, and ends at home position.	Display Logic, Table E (Page 154)
6	If keyboard has CAPS LOCK key, depress CAPS LOCK key. Enter a line of Es at top and bottom of display, then HOME cursor.	Display appears as in Figs. 1 and 2 with all requirements as indicated.	Terminal Analysis Table D (Page 147) Refer to adjustments of monitor to meet requirements (Manual 401).
STEPS 7 THROUGH 14 APPLY TO KDP TERMINALS ONLY.			
7	Preliminary requirements of printer: a. Ribbon and paper loaded. b. Switches (top right of printer, cabinet cover raised) set as in Fig. 3 LF-1 Test-Off Forms (Tractor Feed Only) – On. c. Cabinet cover closed.		

*Includes KD or KDP portion of KD-ROP, KD & ROP, KD+ROP, KDP & ROP, KDP+ROP.

D. OFF-LINE CHECKOUT (Contd)



Requirements:

- Raster aligned vertically and horizontally.
- All Es sharply defined.
- Height and width of display as indicated.
- Es uniform across full width.
- Height of Es same at top and bottom lines.

Fig. 1—Display Monitor

Requirement:
The display (80 characters by 24 lines) shall be centered on the CRT face as gauged by eye.

Fig. 2—Display Monitor

Fig. 3—Printer Switches

Note: Figures 1, 2, and 3 refer to Procedures in Table A.

TABLE A (Contd)

BRIEF OFF-LINE CHECKOUT — KD AND KDF TERMINALS¶¶

STEP	PROCEDURE	RESULTS	TROUBLE ANALYSIS
8	Momentarily depress PAPER button (red) on cover of printer cabinet.	Paper feeds out as long as button is depressed.	Printer (Manual 399)
9	TRACTOR FEED PRINTER ONLY Depress and release FORMS ADVANCE button (black) on printer cabinet cover.	Paper feeds out until first line of next form is reached, then stops.	
10	Unlatch and raise printer cabinet cover.		
11	Raise cover interlock switch to maintenance position.		
12	Set test switch (Fig. 3) to ON, allow printer to print several lines, then turn test switch OFF.	Printer turns on and prints one of the font identification symbols such as [5] repeatedly until switch is turned off.	Printer (Manual 399)
13	FRICTION FEED PRINTER Lift paper roll to simulate a paper alarm. Lower paper roll, guide paper through window, and close cabinet cover. TRACTOR FEED PRINTER Tear off next form under pedestal top, then depress PAPER button on cabinet top until last form passes through printer. Reload forms, guide first form through window, and close cabinet cover.	LOW PAPER indicator lights. LOW PAPER indicator goes out. PAPER indicator lights. PAPER indicator goes out.	Printer (Manual 399)

¶¶ Includes KD or KDF portion of KD-ROF, KD & ROP, KD+ROF, KDF & ROP, KDF+ROP.

D. OFF-LINE CHECKOUT (Contd)

TABLE A (Contd)

BRIEF OFF-LINE CHECKOUT — KD AND KDP TERMINALS**

STEP	PROCEDURE	RESULTS	TROUBLE ANALYSIS
14***	Type an EOT in the lower right hand corner of the display and home cursor. Depress PRINT LOCAL key, and while cursor is moving through third or fourth line of display, depress LOCAL key.	LOCAL indicator goes out. PRINT LOCAL and SEND indicators light. Cursor moves through line of Es at top of display, returns to left, and moves through lines of spaces (blank lines). Printer prints line of Es. *Note:* Printing may occur in all 80 character positions or some Es may be carried over to next line, depending on Option 17. Printer line feeds but does not print for each line of spaces. When LOCAL key is depressed, SEND and PRINT LOCAL indicators go out and LOCAL indicator lights. Printer turns off. *Note:* Printer may or may not feed out 16 lines of paper before turning off, depending on Option 18. Tractor printer may form-out depending on Option 18 and Forms switch.	Terminal Analysis, Table D (Page 147) Printer (Manual 399)
THIS COMPLETES BRIEF OFF-LINE CHECKOUT — KD AND KDP TERMINALS.			

**Includes KD or KDP portion of KD-ROP, KD & ROP, KD+ROP, KDP & ROP, KDP+ROP.

***KD of KD & ROP, KD+ROP does not have PRINT LOCAL feature. KDP printer of KDP & ROP, KDP+ROP responds to PRINT LOCAL feature. Printer of ROP does not respond.

COMPLETE OFF-LINE CHECKOUT

The Complete Off-Line Checkout in Table B exercises all the features of the KD or KDP terminal off-line. These procedures do not check the interface or send and receive capabilities, therefore, an on-line checkout is also required to completely test the 40/3-type equipment. This includes KD (or KDP) portion of KD-ROP, KD & ROP, KDP & ROP, KD+ROP and KDP+ROP.

TABLE B

COMPLETE OFF-LINE CHECKOUT — KD AND KDP TERMINALS

STEP	PROCEDURE	RESULTS	TROUBLE ANALYSIS
1	Power on. Monitor brightness adjusted for desired viewing level. LOCAL key depressed. Depress HOME and CLEAR keys. Put CAPS LOCK key in down position.	Cursor goes to home position and all data is cleared from screen.	Terminal Analysis, Table D (Page 147) Display Logic, Table E (Page 154)
2	Starting with top row and moving from left to right, depress each unshaded key in Fig. 4. Depress RETURN and NEW LINE keys.	Characters displayed as in Fig. 7. Cursor goes to beginning of next line.	Terminal Analysis, Table D (Page 147)
3	If keyboard has CAPS LOCK keytop, depress and release CAPS LOCK key so it returns to upper position, then repeat Step 2.	Characters displayed as in Fig. 7. Cursor goes to beginning of next line.	
4	Hold left SHIFT key depressed. Starting with top row and moving from left to right, depress each unshaded key in Fig. 5. Hold right SHIFT key depressed and depress [?/] key. Depress NEW LINE key.	Characters displayed as in Fig. 7. Cursor moves to beginning of next line.	
5	Hold left CONTROL key depressed. Depress all unshaded keys of Fig. 6 in sequence shown by circled numbers. Hold right CONTROL key depressed and depress [FS] key. Depress NEW LINE key.	Characters displayed (Page 10). Cursor moves to beginning of next line. *Note:* With Option 4-30.a, installed, SEND key will automatically light and the cursor will go home when a valid message-ending character is entered. If this occurs, depress the LOCAL key and return cursor to the position after the message ending character using the cursor positioning controls.	

D. OFF-LINE CHECKOUT (Contd)

Fig. 4

Fig. 5

Fig. 6

TABLE B (Contd)

COMPLETE OFF-LINE CHECKOUT – KD AND KDP TERMINALS

STEP	PROCEDURE	RESULTS	TROUBLE ANALYSIS
6	Fully depress and hold [—] key until about half line of characters are displayed. Depress NEW LINE key.	Repeated . characters and = symbol displayed as in Fig. 7. Cursor moves to beginning of next line.	Terminal Analysis, Table D (Page 147) Operator Console (Keyboard) (Manual 400)
7	Repeat Step 6 using [^] key, and then again using Spacebar.	Repeated . characters followed by = symbol, and repeated spaces followed by = symbol, displayed as in Fig. 7. Cursor moves to beginning of next line.	Controller Logic, Table F (Page 158)
8	Depress cursor keys as necessary to position cursor over E_M character in line of control characters.		
9	Lightly depress CHAR INSRT key.	All characters to right of and including E_M move one position to right as in Fig. 7.	
10	Fully depress and hold CHAR INSRT key until characters stop moving.	All characters to right of and including E_M move right continuously until = symbol reaches right edge as in Fig. 7.	
11	Lightly depress CHAR DLETE key.	E_M and all subsequent characters move one position to left.	
12	Fully depress and hold CHAR DLETE key until characters stop moving.	E_M and subsequent characters move left continuously and are deleted from display as they reach cursor position as in Fig. 7.	
13	THIS STEP APPLIES ONLY TO KDP WITH TRACTOR FEED PRINTER Hold CONTROL key depressed and depress [FF ↓] key three times. *Note:* Make sure forms switch of printer is on.	Three F_F characters are entered in display to the right of the D4.	

D. OFF-LINE CHECKOUT (Contd)



Note 1: Step 3 applies only if keyboard has CAPS LOCK key.

Note 2: Figures shown are for opcons which have monocase and up-low ASCII.†††

†††American National Standard Code for Information Interchange.

Fig. 7

TABLE B (Contd)

COMPLETE OFF-LINE CHECKOUT — KD AND KDP TERMINALS

STEP	PROCEDURE	RESULTS	TROUBLE ANALYSIS
14	Depress HOME.	Cursor goes to home position.	
15	KDP, KDP & ROP or KDP+ROP, KD-ROP. Depress PRINT LOCAL key. When complete message on monitor has been sent to printer, depress LOCAL key.	LOCAL indicator goes out; PRINT LOCAL and SEND indicators light. Cursor moves through display and printer prints according to features and options as in Fig. 8. When LOCAL key is depressed, SEND and PRINT LOCAL indicators go out, printer turns off, and LOCAL indicator lights. TRACTOR PRINTER Form-out occurs when first F9 character is sent from display. Lines of - and . characters print on next form. (Only one form-out occurs — second and third F9 characters have no effect.) Spacing from first line of first form to line of - characters on next form equals form length selected by form belt and form selector setting.	Terminal Analysis, Table D (Page 147) Printer (Manual 399)

D. OFF-LINE CHECKOUT (Contd)

```
1234567890_+\QWERTYUIOP~\ASDFGHJKL:'{ZXCVBNM,./
1234567890_+"qwertyuiop~\asdfghjkl:'{zxcvbnm,./
!@#$%^&*()_>=[]:"}<>??
_____________
.....................
```

Up-Low Printer Without Foldover — Option 4-21.a.

```
1234567890_+@QWERTYUIOP~\ASDFGHJKL:'{ZXCVBNM,./
1234567890_+"QWERTYUIOP~\ASDFGHJKL:'{ZXCVBNM,./
!@#$%^&*()_>"[\]:"}<>??
_____________
.....................
```

Up-Low Printer With Foldover — Option 4-21.b.
or
Monocase Printer — Option 4-22.b.

```
1234567890_+!@QWERTYUIOP~\ASDFGHJKL:'|ZXCVBNM,./
1234567890_+{EEEEEEEEEE~\EEEEEEEEE:'EEEEEEEE,./
!@#$%^&*()_?|?[:"!<>??
_____________
.....................
```

Monocase Printer Without Foldover — Option 4-22.a.

Note 1: Line 2 in all three figures present only if opcon keyboard has CAPS LOCK key.

Note 2: Characters shown are for basic type carrier.

Note 3: For tractor feed printers with form-out mechanism, lines of - and . characters appear on next form.

Note 4: Figures shown are for monocase and up-low ASCII.

TABLE B (Contd)

COMPLETE OFF-LINE CHECKOUT — KD AND KDP TERMINALS

STEP	PROCEDURE	RESULTS	TROUBLE ANALYSIS
16	Depress HOME, then CLEAR key.	Cursor goes to home position and all information is cleared from display.	Terminal Analysis, Table D (Page 147)
17	Enter a line of 80 *s across top of display.	*s are displayed, and cursor remains at right of line.	
18	Depress LINE INSRT key, then enter a line of 80 Us across top of display.	Cursor returns to home position and *s move down one line. Us are displayed above *s.	Display Logic, Table E (Page 154)
STEPS 19 THROUGH 22 APPLY ONLY TO TERMINALS WITH ONE SEGMENT. IF TERMINAL IS EQUIPPED WITH TWO OR THREE SEGMENT DISPLAY, GO TO STEP 23.			
19	Repeatedly depress LINE INSRT key until *s move to to last line of display.	Cursor returns to home position and *s and Us both move down one line each time LINE INSRT key is depressed. Movement stops when *s reach bottom of display. Cursor stays at home position.	Terminal Analysis, Table D (Page 147) Display Logic, Table E (Page 154)
20	Depress cursor down (↓) and then cursor right (→) to move cursor to about the middle of the line of Us.		Terminal Analysis, Table D (Page 147)
21	Depress LINE DLETE key.	Cursor returns to left margin, and Us are removed. *s move up one line to replace Us.	
22	Depress LINE INSRT key several times.	*s move down one line to bottom of display and stop. Cursor does not move.	
STEPS 23 THROUGH 36 APPLY ONLY TO TERMINALS EQUIPPED WITH TWO OR THREE SEGMENT DISPLAY.			
23	Depress HOME.	Cursor goes to home position.	Terminal Analysis, Table D (Page 147)

D. OFF-LINE CHECKOUT (Contd)

TABLE B (Contd)

COMPLETE OFF-LINE CHECKOUT — KD AND KDP TERMINALS

STEP	PROCEDURE	RESULTS	TROUBLE ANALYSIS
24	Depress SEGMT ADV key twice for terminals with two segments, or three times for terminals with three segments.	Segment marker changes from segment 1 marker (-) to segment 2 (-), and on terminals with three segments to segment 3 marker (-), and back to segment 1 marker. *s and U's disappear as segment changes, and reappear at top of display when segment 1 marker reappears. Cursor does not move.	
25	Depress SCROL UP key one time.	Segment 1 marker and U's disappear from top of display. *'s move to top of display, and segment 2 marker appears at bottom left of display. Cursor does not move.	
26	Depress SCROL UP key fully. Note: Operation with 410009 or 410018 continuous scrolling circuit card. The 410009 circuit card is manufactur discontinued.	Segment 2 marker (then 3 marker if terminal has three segments) moves up the display. *'s disappear from top of display. Scrolling stops when segment marker of last segment reaches top line of display. Cursor does not move (see Note). Scrolling will not stop when segment marker of last segment reaches top line of display, but will continue while key is fully depressed.	

TABLE B (Contd)

COMPLETE OFF-LINE CHECKOUT — KD AND KDP TERMINALS

STEP	PROCEDURE	RESULTS	TROUBLE ANALYSIS
27	Depress SCROL DOWN key once, then fully. *Note:* Operation with 410009 or 410018 continuous scrolling circuit card.	Segment marker at upper left moves down one line, then moves down continuously and disappears as segment marker of previous segment appears at top left. When segment 1 marker appears at top left of display, scrolling stops. *s and Us reappear in original position at top of display when segment 1 returns to display. Cursor does not move (see Note). Scrolling will not stop when segment marker of last segment reaches top line of display, but will continue while key is fully depressed.	Terminal Analysis, Table D (Page 147) Display Logic, Table E (Page 154)
28	Repeatedly depress LINE INSRT key until *s move to last line of segment.	*s and Us both move down one line each time LINE INSRT key is depressed. Cursor does not move.	Terminal Analysis, Table D (Page 147) Display Logic, Table E (Page 154)
29	Depress cursor down (⇕), and then cursor right (→) to position cursor at about the middle of the line of Us.		
30	Depress LINE DLETE key.	Cursor returns to left margin and Us are removed. *s move up one line to replace Us.	
31	Depress LINE INSRT key several times.	*s move down one line to bottom of display on first depression, then disappear from display on second depression. Cursor does not move.	

D. OFF-LINE CHECKOUT (Contd)

TABLE B (Contd)

COMPLETE OFF-LINE CHECKOUT — KD AND KDP TERMINALS

STEP	PROCEDURE	RESULTS	TROUBLE ANALYSIS
32	Depress SEGMT ADV key.	Segment 2 marker appears at top left of display. *s appear a few lines down from top in segment 2. Cursor does not move.	
33	Depress HOME and CLEAR.	Cursor goes to home position. Segment 1 is displayed.	
34	Depress SEGMT ADV key to display last segment of page.	Segment marker of last segment appears at upper left of display. *s have been cleared from segment 2. Cursor remains in home position.	Terminal Analysis, Table D (Page 147)
35	Depress cursor down (↓) to position cursor at about next to last line of display, then enter a few Us in this line.		
36	Depress LINE INSRT key several times.	Cursor returns to left margin and Us move to bottom of display, then stop.	
IF TERMINAL IS EQUIPPED WITH FULL EDIT FEATURE, GO TO STEP 37. IF NOT, THIS COMPLETES OFF-LINE CHECKOUT.			
37	Depress HOME, then CLEAR.	Cursor goes to home position and display is cleared.	Terminal Analysis, Table D (Page 147)
38	Alternately depress TAB SET key and Spacebar until cursor reaches end of line.	Column of tab marks is displayed in every character position of page. Alarm sounds at 73rd and 80th character positions. (On terminals with more than one segment, depress SEGMT ADV key as necessary to view tab columns on other segment(s), then return to segment 1.)	Controller Logic, Table F (Page 158) Display Logic, Table E (Page 154) Operator Console (Keyboard) (Manual 400)

TABLE B (Contd)

COMPLETE OFF-LINE CHECKOUT — KD AND KDP TERMINALS

STEP	PROCEDURE	RESULTS	TROUBLE ANALYSIS
27	Depress SCROL DOWN key once, then fully. *Note:* Operation with 410009 or 410018 continuous scrolling circuit card.	Segment marker at upper left moves down one line, then moves down continuously and disappears as segment marker of previous segment appears at top left. When segment 1 marker appears at top left of display, scrolling stops. *s and Us reappear in original position at top of display when segment 1 returns to display. Cursor does not move (see Note). Scrolling will not stop when segment marker of last segment reaches top line of display, but will continue while key is fully depressed.	Terminal Analysis, Table D (Page 147) Display Logic, Table E (Page 154)
28	Repeatedly depress LINE INSERT key until *s move to last line of segment.	*s and Us both move down one line each time LINE INSERT key is depressed. Cursor does not move.	Terminal Analysis, Table D (Page 147) Display Logic, Table E (Page 154)
29	Depress cursor down (↓), and then cursor right (→) to position cursor at about the middle of the line of Us.		
30	Depress LINE DLETE key.	Cursor returns to left margin and Us are removed. *s move up one line to replace Us.	
31	Depress LINE INSRT key several times.	*s move down one line to bottom of display on first depression, then disappear from display on second depression. Cursor does not move.	

D. OFF-LINE CHECKOUT (Contd)

TABLE B (Contd)

COMPLETE OFF-LINE CHECKOUT — KD AND KDF TERMINALS

STEP	PROCEDURE	RESULTS	TROUBLE ANALYSIS
32	Depress SEGMT ADV key.	Segment 2 marker appears at top left of display. *s appear a few lines down from top in segment 2. Cursor does not move.	
33	Depress HOME and CLEAR.	Cursor goes to home position. Segment 1 is displayed.	
34	Depress SEGMT ADV key to display last segment of page.	Segment marker of last segment appears at upper left of display. *s have been cleared from segment 2. Cursor remains in home position.	Terminal Analysis, Table D (Page 147)
35	Depress cursor down (↓) to position cursor at about next to last line of display, then enter a few Us in this line.		
36	Depress LINE INSRT key several times.	Cursor returns to left margin and Us move to bottom of display, then stop.	
IF TERMINAL IS EQUIPPED WITH FULL EDIT FEATURE, GO TO STEP 37. IF NOT, THIS COMPLETES OFF-LINE CHECKOUT.			
37	Depress HOME, then CLEAR.	Cursor goes to home position and display is cleared.	Terminal Analysis, Table D (Page 147)
38	Alternately depress TAB SET key and Spacebar until cursor reaches end of line.	Column of tab marks is displayed in every character position of page. Alarm sounds at 73rd and 80th character positions. (On terminals with more than one segment, depress SEGMT ADV key as necessary to view tab columns on other segment(s), then return to segment 1.)	Controller Logic, Table F (Page 158) Display Logic, Table E (Page 154) Operator Console (Keyboard) (Manual 400)

TABLE B (Contd)

COMPLETE OFF-LINE CHECKOUT — KD AND KDP TERMINALS

STEP	PROCEDURE	RESULTS	TROUBLE ANALYSIS
39	Home cursor and depress TAB CLEAR.	All tab marks (on all segments) are cleared.	Terminal Analysis, Table D (Page 147)
40	Depress HIGH LIGHT key.	HIGH LIGHT indicator lights.	
41	Enter a full line of *s at top of display.	*s continuously flash between half- and full intensity. Alarm sounds at 73rd and 80th character positions. Cursor remains at right end of line.	
42	Depress HIGH LIGHT key again.	HIGH LIGHT indicator goes out.	
43	Depress LINE INSRT key.	Cursor moves to left margin, and highlighted *s move down one line.	Terminal Analysis, Table D (Page 147)
IF OPTION 4-12.a. IS ENABLED ON 410675 CARD (SEE STATION FEATURES AND OPTION RECORD), TEMPORARILY CHANGE TO OPTION 4-12.b. UNTIL CHECKOUT IS COMPLETE.			
44	Depress FORM ENTER key.	FORM ENTER indicator lights.	Controller Logic, Table F (Page 158)
45	Enter a full line of Us at top of display.	Us are displayed at half intensity (protected). Alarm sounds at 73rd and 80th character positions. Cursor remains at right end of line.	Terminal Analysis, Table D (Page 147) Display Logic, Table E (Page 154)
46	Depress LINE INSRT key.	Cursor moves to left margin and lines of *s and Us both move down one position. Cursor remains in home position.	
47	Depress CLEAR.	Screen is cleared.	
48	Depress FORM ENTER key.	FORM ENTER indicator goes out.	

D. OFF-LINE CHECKOUT (Contd)

TABLE B (Contd)

COMPLETE OFF-LINE CHECKOUT — KD AND KDF TERMINALS

STEP	PROCEDURE	RESULTS	TROUBLE ANALYSIS
49	Enter message of Fig. 9 in lines 1 through 9 of display.	Message appears as in Fig. 9. (To observe protected spaces, increase monitor brightness and note that all protected data has darker background than unprotected data.)	
50	Depress CHAR INSRT key fully and hold until movement stops.	Word QUICK in line 1 moves to tab column and stops. No other characters affected.	Terminal Analysis, Table D (Page 147)
51	Depress CHAR DLETE key twice.	Word QUICK in line 1 moves two positions left. No other characters affected.	
52	Depress TAB.	Cursor moves to tab column. Tab symbol (▶) appears at original position of cursor. All characters passed over by cursor are erased from display.	
53	Depress CHAR INSRT key fully and hold until movement stops.	Word UNPROTECTED moves three positions to right, stopping when it reaches word PROTECTED. No other characters affected.	
54	Depress CHAR DLETE key fully and hold until movement stops.	Word UNPROTECTED is moved left and completely erased. No other characters affected.	
55	Depress TAB.	Cursor moves to first character position after word PROTECTED. Tab symbol (▶) appears at original position of cursor.	
56	Depress SPACEBAR once, then depress it fully.	Alarm sounds once when Spacebar is depress first time. Cursor moves to character position preceding protected New Line symbol. Alarm sounds continuously, and cursor does not advance beyond this position.	

Note: Depress each key once unless number of depressions is indicated in parentheses.

LINE 1

Type QUICK
Depress Space (5)
Depress TAB SET
Type UNPROTECTED
Depress Space (2)
Depress FORM ENTER
Type PROTECTED
Depress FORM ENTER
Depress Space (8)
Depress FORM ENTER
Depress NEW LINE

LINE 2

Type QUICK
Depress FORM ENTER
Depress Space (5)
Type UNPROTECTED
Depress Space (3)
Depress FORM ENTER
Type PROTECTED
Depress FORM ENTER
Depress Space (8)
Depress FORM ENTER
Depress NEW LINE
Depress FORM ENTER

LINE 3

Type INSERT
Depress Space until
cursor is under
NEW LINE symbol.
Depress FORM ENTER
Depress NEW LINE

LINE 4 AND 5

Depress Cursor
Right (→) until
cursor is under
NEW LINE symbol.
Depress NEW LINE.

(Repeat for Line 5)

LINE 6

Depress Cursor
Right (→) until
cursor is at about
23rd character
position.
Depress NEW LINE.
Depress FORM ENTER.

LINE 7

Type MODEL
Depress Space
Type 40

LINE 8

Depress CURSR RTRN
Depress Cursor
down (↓) twice

LINE 9

Depress FORM ENTER
Type PROTECTED
Depress FORM ENTER
Depress HOME

Fig. 9

D. OFF-LINE CHECKOUT (Contd)

TABLE B (Cont)

COMPLETE OFF-LINE CHECKOUT — KD AND KDP TERMINALS

STEP	PROCEDURE	RESULTS	TROUBLE ANALYSIS
57	Depress TAB.	Cursor moves to end of protected word QUICK in line 2.	
58	Depress CURSOR TAB three times.	Cursor moves to tab mark on first depression. Cursor moves to space following word PROTECTED on second depression. Cursor moves to beginning of word INSERT in line 3 on third depression. No characters altered in any way.	Terminal Analysis, Table D (Page 147) Operator Console (Keyboard) (Manual 400) Display Logic, Table E (Page 154)
59	Depress LINE INSRT three times.	Word INSERT moves down two lines and stops. Rest of display does not change.	
60	Position cursor over M in word MODEL, then depress LINE INSRT twice.	Words MODEL 40 move down one position and stop.	
61	Move cursor over P at beginning of line 9, and type some miscellaneous characters.	Alarm sounds each time a key is depressed. (No characters can overwrite a protected character.)	
62	Depress HOME, CLEAR, then TAB CLEAR.	Cursor goes to home position. All unprotected characters and tab columns are cleared. Protected characters remain on display.	
63	Depress FORM ENTER.	FORM ENTER indicator lights.	
64	Depress CLEAR.	All characters are cleared from display.	
65	Depress FORM ENTER.	FORM ENTER indicator goes out.	
66	If Option 12.a. was originally present on 410675 card, restore this option (unless further checkout is to be performed).	With Option 12.a. selected, FORM ENTER indicator will no longer light when FORM ENTER is depressed in local mode.	

THIS COMPLETES OFF-LINE CHECK OF KD OR KDP.

This table checks the basic operation of 40-type ROP terminals with 40C103 controller.

Note: Checkout procedures for 40-type ROP terminals with 40C303 integrated controller are provided in Manual 360.

TABLE C

OFF-LINE CHECKOUT — ROP TERMINALS

STEP	PROCEDURE	RESULTS	TROUBLE ANALYSIS
1	Preliminary requirements: a. Ribbon and paper loaded. b. Switches (top right of printer cabinet, cover raised) set as follows: LP.1 Test-Off Forms (Tractor Feed Only)-On. c. Cabinet cover and pedestal door closed.		
2	Turn on power.	IN SERVICE indicator lights. Fans move air in pedestal. In tractor feed printer, fan in printer cabinet cover also turns on.	Terminal Analysis, Table D, (Page 147) 40C103 ROP Controller, Table G, (Page 160)
3	Momentarily depress PAPER button (red) on cover of printer cabinet.	Paper feeds out as long as button is depressed.	Opcon (Manual 400)
4	TRACTOR FEED PRINTER ONLY Depress and release FORMS ADVANCE button (black) on printer cabinet cover.	Paper feeds out until first line of next form is reached, then stops.	Printer (Manual 399)
5	Unlatch and raise printer cabinet cover.	IN SERVICE indicator goes out.	
6	Raise cover interlock to maintenance position.	IN SERVICE indicator lights.	Terminal Analysis, Table D (Page 147)
7	Momentarily set Test switch to ON position then return to OFF position.	Font identification symbol (▯▯ or ▯▯) prints repeatedly while switch is on.	40C103 ROP Controller, Table G (Page 160)
8	FRICTION FEED PRINTER Lift paper roll to simulate a paper alarm.	PAPER indicator lights; IN SERVICE indicator goes out.	Opcon (Manual 400) Printer (Manual 399)

D. OFF-LINE CHECKOUT (Contd)

TABLE C (Contd)

OFF-LINE CHECKOUT — ROP TERMINALS

STEP	PROCEDURE	RESULTS	TROUBLE ANALYSIS
8 (Contd)	Lower paper roll. Guide paper through window and close cabinet cover.	LOW PAPER indicator goes out; IN SERVICE indicator lights.	Printer (Manual 399)
	TRACTOR FEED PRINTER		
	Tear off next form under pedestal top, then depress PAPER button on cabinet top until last form passes through printer.	PAPER indicator lights; IN SERVICE indicator goes out.	
	Reload forms and close cabinet cover.	PAPER indicator goes out; IN SERVICE indicator lights.	
9	Depress TEST (early design designated TRANS START key (if present) on opcon, then after a few seconds depress again. *Note:* If key is not present on opcon, remove blocking key to left of IN SERVICE key. Depress switch once to turn on and second time to turn off.	TEST or TRANS START indicator lights and character set is printed repeatedly (Fig. 10). Indicator goes out and printing stops when depressed second time.	
10	Raise printer cabinet cover and set LF switch to position 2. Close cover and depress TRANS START key. While printer is printing, raise cover.	Repeated character set prints with double line spacing. When cover is raised, printer stops and IN SERVICE indicator goes out.	
11	Restore setting of LF switch (or leave in position 2 if double line spacing is desired). Depress (release) TEST or TRANS START key. If blocking key was removed in Step 9, restore key to opcon. Close cabinet cover.	 IN SERVICE indicator lights.	

THIS COMPLETES OFF-LINE CHECKOUT — ROP TERMINALS.

TABLE C (Contd)

OFF-LINE CHECKOUT — ROP TERMINALS

Option 19. a. Enabled

Line feed detected as printed character; printing continues to end of line.

Option 19. b. Enabled

Option 19. c. Enabled

The TEST (early design designated TRANS START) character set will print as above if Option 19.c. is enabled and the data stacking Option 38. is enabled in the 40C103/AE RO Controller (410580 circuit card). The locations of the line feeds may vary from the example shown.

Note: Printed characters shown for basic monocase type character (⌑ identification symbol). For other type carriers, substitute characters as necessary.

E. TROUBLESHOOTING

The troubleshooting information contained herein is divided into two parts:

(a) Terminal Analysis — A step-by-step procedure to determine which component of the Model 40/3 station or Set is failing.

(b) Component Analysis — A step-by-step procedure to determine which subcomponent or part (or related adjustment) of the component (display logic, controller logic, etc) is causing failure.

To use the troubleshooting information, always start with Analysis Question 1 of the Terminal Analysis, and follow the indicated procedure to the directive which specifies jumping into the Component Analysis section. Then follow the specific Component Analysis indicated (ie, display logic, controller logic, etc) starting with Analysis Question 1 to isolate and correct the trouble by replacing the indicated defective component.

To locate components, circuit cards, connectors, test switches, indicator lamps and other elements indicated in the troubleshooting information, refer to the appropriate Model 40 publication as listed in Part 1 of this manual.

For wire color codes, cable, connector, and other wiring information for continuity checks etc, in troubleshooting, refer to PART 6 – WIRING DIAGRAMS of this manual.

If replacement of the part or subcomponent indicated in the Component Analysis does not correct the trouble, replace the next higher order of component (ie, fuse, power distribution assembly, display monitor, or entire terminal).

When installing a replacement component, make certain that all options (if present) in this component are implemented for proper set operation.

Where more than one component is specified for replacement, they shall be substituted one at a time in the order specified. The original component shall be replaced if the trouble is not corrected before making the next indicated substitution.

Once the trouble has been corrected, the terminal should be checked out to be sure that it is performing properly. Refer to the appropriate checkout procedures.

The following warning procedures must be observed when troubleshooting Model 40 equipment:

Warning 1: Turn off all power or signal sources before removing or replacing any component.

Warning 2: To avoid possible internal damage to circuitry, wear a 346392 static discharge strap connected to ground to allow static discharge before handling circuit cards for removal or replacement. Avoid touching circuit lands or components as much as possible.

Note: Service personnel are never to be connected directly to ground but rather through a high resistance discharge path of at least one megohm to provide protection from accidental contact with 115 V ac.

TABLE D

TERMINAL ANALYSIS

Note 1: Always start with Step 1.

Note 2: Answer analysis questions, and follow appropriate response directive.

Note 3: Refer to Manual 360 for analysis of ROP sets equipped with 40C303 Integrated Controllers.

ANALYSIS QUESTION	"YES" RESPONSE DIRECTIVE	"NO" RESPONSE DIRECTIVE
1. Is the set an ROP?	Go to 20.	KD, KD-ROP, KD-ROP+ROP, KD+ROP, KD&ROP, KDP, KDP+ROP, KDP&ROP. If any of above, go to 2.
2. Do the fans turn when power is ON?	Go to 3.	Check ac to fan. Refer to PART 6 — WIRING DIAGRAMS, Manual 403 — Model 40 Cabinets, Paper Winder and Facilities. Fan cable connected. Power switch(es) ON. AC present at fan assembly connector.
3. Does the LOCAL lamp on the opcon turn ON when power is turned ON?	Go to 5.	Go to 4.
4. Are all three LED indicators in the power supply ON?	Go to Manual 400 — Operator Console (Keyboard) Go to Table F, KD or KDP Controller (Page 158).	Refer to Manual 402 — Model 40 Power Supply.
5. Is the red drive lamp 15 (in display monitor) ON?	Go to 6.	Go to Table E, Display Logic (Page 154). Go to Manual 401 — Display Monitor.

E. TROUBLESHOOTING (Contd)

TABLE D (Contd)

TERMINAL ANALYSIS

	ANALYSIS QUESTION	"YES" RESPONSE DIRECTIVE	"NO" RESPONSE DIRECTIVE
6.	Is the red pilot lamp IT (next to fuse on power distribution assembly in display monitor) IN?	Go to 7.	Go to Manual 401 — Model 40 Display Monitor.
7.	With the monitor OFF/ON control switch ON (CCW) and the operator brightness control to full intensity (CCW), is the raster visible?	Go to 9.	Go to 8.
8.	Is the 16 high voltage lamp in the display monitor ON?	Check DISPLAY MONITOR MASTER BRIGHTNESS adjustment in Manual 401 — Model 40 Display Monitor. Go to 9.	Go to Manual 401 — Model 40 Display Monitor.
9.	Is the cursor displayed on the monitor?	Go to 11.	Go to 10.
10.	Turn operator brightness to full intensity (CCW). Depress test switch number one (TS1) in display logic. Does a flashing vertical black bar pattern appear in the raster with no white pattern? 	Go to Manual 401 — Model 40 Display Monitor. Go to Table E, Display Logic (Page 154).	Go to Table E, Display Logic (Page 154).

TABLE D (Contd)

TERMINAL ANALYSIS

ANALYSIS QUESTION	"YES" RESPONSE DIRECTIVE	"NO" RESPONSE DIRECTIVE
11. In the local mode, can all data (including editing functions) be input from the opcon to the display monitor on all segments?	Go to 12.	Go to Manual 400 — Operator Console (Keyboard). Go to Table E, Display Logic (Page 154). Go to Table F, KD or KDP Controller (Page 158).
12. Are the characters displayed on the display monitor distorted?	Go to Manual 401 — Model 40 Display Monitor. Go to Table E, Display Logic (Page 154).	Go to 13.
13. Do characters displayed on the display monitor correspond to those generated from the opcon?	Go to 14.	Go to Table E, Display Logic (Page 154). Go to Table F, KD or KDP Controller (Page 158). Go to Manual 400 — Operator Console (Keyboard).
14. Is the station a KD?	Go to 19.	Go to 15.
15. Is the station a KD-ROP, KDP, KD-ROP+ROP, KDP&ROP, KDP+ROP?	Go to 16.	Go to 20.
16. Does printer respond properly to PRINT LOCAL key on opcon? (For KDP&ROP or KDP+ROP, this printer is KDP printer.)	KDP: Go to 19. KDP&ROP; KDP+ROP; KD-ROP: Go to 20.	All stations: Go to 17.
17. Does PRINT LOCAL key on opcon light?	Go to 18.	Go to KD or KDP Opcon Tests — Local Loopback Tests See Manual 400 — Operator Console (Keyboard). If PRINT LOCAL lamp fails test, replace opcon. If PRINT LOCAL lamp passes test, remove opcon from loopback mode (depress RETURN and P keys simultaneously beyond their normal stop) and go to 18.

E. TROUBLESHOOTING (Contd)

TABLE D (Contd)

TERMINAL ANALYSIS

ANALYSIS QUESTION	"YES" RESPONSE DIRECTIVE	"NO" RESPONSE DIRECTIVE
18. Does the type carrier symbol ($\frac{A}{B}$ or $\frac{C}{D}$) print in every column when the printer test switch TS9 is ON and the printer cover is closed or the interlock switch PS5 is in the maintenance up position?	Go to 19.	Go to Manual 399 — Model 40 Printer.
19. Does the station perform on-line tests properly?	Place in service.	Go to Table F, KD or KDP Controller (Page 158). Recheck 91...0 Station Controller options. Checkout 9140 Controller as indicated in Manual 352, Part 8.
20. Does the IN SERVICE lamp on the op-on in the ROP turn ON when power is turned ON?	Go to 21.	Go to 25.
21. In an off-line mode, does the TRANS START lamp turn ON when the key is depressed? (The key lights when depressed and stays ON until depressed again to stop the test.)	Go to 22.	Go to Manual 400 — Model 40 Operator Console (Keyboard). Go to Table G, 40C103 ROP Controller (Page 160).
22. In an off-line mode, is the test pattern printed properly with no errors when the TRANS START key is depressed?	Go to 27.	Go to 23.
23. Does the printer turn ON or run at all when the TRANS START key is depressed?	Go to Manual 399 — Model 40 Printer. Go to Table G, 40C103 ROP Controller (Page 160).	Go to 24.
24. Does paper advance when the red PAPER key is depressed?	Go to Table G, 40C103 ROP Controller (Page 160).	Check SSI cable and feed through for continuity at terminals A to B and C to D on J102 connector to printer circuit card, and terminals 1 to 2 and 3 to 6 on printer connector at rear of cabinet.

TABLE D (Contd)

TERMINAL ANALYSIS

ANALYSIS QUESTION	"YES" RESPONSE DIRECTIVE	"NO" RESPONSE DIRECTIVE
24. (Contd)		Go to Manual 402 — Model 40 Power Supply. If printer is tractor feed, check continuity of paper advance contact (P114 connector, terminals 3 to 4) when switch is depressed. Go to Manual 399 — Model 40 Printer. Go to Table G, 40C103 ROP Controller (Page 160).
25. Does paper advance when the red PAPER key is depressed?	Go to 26.	Check PSS interlock switch for continuity when switch activator is down and in maintenance up positions. Friction Feed: J106 connector, terminals 1 to 2. Tractor Feed: P114 connector, terminals 6 to 7 and 3 to 5. See PART E — WIRING DIAGRAMS. Check SSI cable and feed through for continuity at terminals A to B and C to D on J102 connector to printer circuit card, and terminals 1 to 2 and 3 to 6 on printer connector at rear of cabinet. If printer is tractor feed, check continuity of paper advance contact (P114 connector, terminals 3 to 4) when switch is depressed. Go to Manual 399 — Model 40 Printer. Go to Table G, 40C103 ROP Controller (Page 160).

E. TROUBLESHOOTING (Contd)

TABLE D (Contd)

TERMINAL ANALYSIS

ANALYSIS QUESTION	"YES" RESPONSE DIRECTIVE	"NO" RESPONSE DIRECTIVE
26. Does the type carrier symbol ($\frac{\Delta}{\Delta}$) or ($\frac{\Delta}{\Delta}$) print in every column when the TS9 printer test switch is ON and the printer cover is closed, or the PS5 interlock switch is in the maintenance up position?	Check S81 cable and feed through for continuity at terminals A to B and C to D on J102 connector to printer circuit card, wsd terminals 1 to 2 and 3 to 6 on printer connector at rear of cabinet. Go to Manual 400 — Model 40 Operator Console (Keyboard).	Go to Manual 399 — Model 40 Printer.
27. Does paper advance when the red PAPER key is depressed?	Go to 28.	If printer is tractor feed, check continuity of paper advance contact (P114 connector, terminals 3 to 4) when switch is depressed. Go to Manual 399 — Model 40 Printer.
28. Does the printer have tractor feed paper drive?	Go to 29.	Go to 30.
29. When the black FORM ADVANCE key is depressed, does the paper advance one form (printer form switch ON) or advance continuously (printer form switch OFF)?	Go to 30.	Check FORM ADVANCE switch for continuity when depressed (P114 connector, terminals 3 to 4 and 3 to 5). Go to Manual 399 — Model 40 Printer. Check Form Out Contact Gap.
30. Does the type carrier symbol ($\frac{\Delta}{\Delta}$) or ($\frac{\Delta}{\Delta}$) print in every column when the TS9 printer test switch is ON and the printer cover is closed, or the PS5 interlock switch is in the maintenance up position?	Go to 31.	Go to Manual 399 — Model 40 Printer.

TABLE D (Contd)

TERMINAL ANALYSIS

ANALYSIS QUESTION	"YES" RESPONSE DIRECTIVE	"NO" RESPONSE DIRECTIVE
31. Does the station perform on-line tests properly?	Place in service.	Go to 32.
32. Is the station a KD+ROP, KD-ROP+ROP, KDP+ROP or other arrangement that includes a +ROP having an IRS (Individual Receiver Selection) Modification Kit.	Checkout IRS Modification Kit according to Manual 352, Part 8.	Recheck 9140 Station Controller options. Checkout 9140 Controller Manual 352, Part 8. Go to Manual 399 — Model 40 Printer. Go to Table G, 40C103 ROP Controller (Page 160).

COMPONENT ANALYSIS

The following tables contain the Trouble Analysis for the logic in the 40/3 Station.

IF YOU ARE TROUBLESHOOTING THE	PROCEED TO	ON PAGE
Display Logic	Table E	154
KD or KDP Controller Logic	Table F	158
40C103 ROP Controller	Table G	160

Trouble Analysis for components other than those previously specified can be found in the following Manuals:

Manual 399 Model 40 — Printer
Manual 400 Model 40 — Operator Console (Keyboard)
Manual 401 Model 40 — Display Monitor
Manual 402 Model 40 — Power Supply

If data set problems are suspected, refer to the appropriate data set or modem literature.

E. TROUBLESHOOTING (Contd)

TABLE E

DISPLAY LOGIC



Display Logic Circuit Cards	
Pos.	
06	410002
07	410001, 410009 or 410018
08	410003
09	A/N
10	410015 (See Note 1.)
11	410015 (See Note 1.)
12	410015 (See Note 1.)
13	410687, 410020, 410021, 410022
14	410855
Wired Frame	341672 (See Note 2.)

Note 1: For 1 segment (24 lines), card is in position 10. For 2 segments (48 lines), cards are in position 10 and 11. For 3 segments (72 lines), cards are in positions 10, 11, and 12.

Note 2: If trouble is not cleared after replacing all components listed, check or replace wired frame.

ANALYSIS QUESTION	"YES" RESPONSE DIRECTIVE	"NO" RESPONSE DIRECTIVE
1. Depress TS1 test switch on 410855 circuit card. Is the following pattern generated on the display? Are all of the elements shown in enlarged view I and II present?	Go to 2.	Replace 410855 circuit card.

TABLE E (Contd)

DISPLAY LOGIC

ANALYSIS QUESTION	"YES" RESPONSE DIRECTIVE	"NO" RESPONSE DIRECTIVE
1. (Contd)  		
2. Depress TS2 test switch on 410657, 410020, 410021, or 410022 circuit card. Is the U* (or *U) pattern, with protected and high-lighted elements as indicated below, generated across all lines of the display? 	Go to 3.	Replace 410657, 410020, 410021, or 410022 circuit card.
3. Depress and hold down TS3 test switch on 410001, 410009, or 410018 circuit card. Is the * character generated across all lines of the display in all character positions? Also check segments 2 and 3 (if present) by scrolling.	If data appears on screen that is not sent from opcon: Replace 410015 circuit card for segment affected. Replace 410002 circuit card. Go to 8.	Go to 4.

E. TROUBLESHOOTING (Contd)

TABLE E (Contd)

DISPLAY LOGIC

ANALYSIS QUESTION	"YES" RESPONSE DIRECTIVE	"NO" RESPONSE DIRECTIVE
4. With TS3 depressed, is a black and white bar pattern generated on the display with bars that are 4 character positions wide as shown below? TS3 Test Pattern	Go to 5. *Note:* Pattern is not necessarily centered on the display as illustrated.	Go to 6.
5. Remove 341740 cable. Depress TS3. Is the test pattern from Question 4 still generated on the display?	Replace 410002 circuit card.	Trouble is in controller. Go to Table F, KD or KDP Controller (Page 158).
6. With TS3 depressed, is a black an white bar pattern generated on the display with white bars 4 character positions wide and black bars 12 characters positions wide as shown below? TS3 Test Pattern	Replace 410015 circuit card. for the segment indicated by the segment marker displayed in the test pattern. *Note:* Pattern is not necessarily centered on the display as illustrated.	Go to 7.

TABLE E (Contd)

DISPLAY LOGIC

ANALYSIS QUESTION	"YES" RESPONSE DIRECTIVE	"NO" RESPONSE DIRECTIVE
7. With TS3 depressed, is a black and white bar pattern generated on the display with bars that are 8 character positions wide as shown below? TS3 Test Pattern	Replace 410003 circuit card. *Note* Pattern is not necessarily centered on the display as illustrated.	Replace 410001, 410009, or 410018 circuit card.
8. With TS3 depressed, does the cursor and first segment marker come to rest in a stationary condition at the HOME position?	Display logic is good. Trouble is elsewhere.	Replace 410003 circuit card.

TABLE F

KD OR KDP CONTROLLER



Controller Circuit Cards		
Pos	KD	KDP
01	–	410720
02	410671	410721
03	410672	410673
04	410676	410676
05	410675	410675
06	410674	410674
Wired Frame	341909	341909

Note If trouble is not cleared after replacing all components listed, check or replace wired frame.

E. TROUBLESHOOTING (Contd)

TABLE F (Contd)

KD OR KDP CONTROLLER

Note: DL refers to Display Logic.

ANALYSIS QUESTION	"YES" RESPONSE DIRECTIVE	"NO" RESPONSE DIRECTIVE
1. Can anything be entered from opcon onto the display?	Go to 3.	Go to 2.
2. Depress TS4 test switch on 410771 circuit card. Is "?" (Option 4-7.a.) or "Sg" (Option 4-7.b.) displayed on the monitor?	Replace 410672 circuit card. Replace 410675 circuit card. Replace opcon.	Replace 410675 circuit card. Replace 410674 circuit card. Replace 410002 circuit card in DL. Replace 341740 cable to DL.
3. Can characters be entered from opcon (in local mode) and displayed properly?	Go to 4.	Replace 410672 circuit card. Replace 410674 circuit card. Replace 410002 circuit card in DL. Replace 341740 cable to DL.
4. Do edit and alarm features operate properly in local mode? *Note:* Refer to Complete Off-Line Checkout — Table B, KD and KDP Terminals.	Go to 5.	Replace 410675 circuit card. Replace 410672 circuit card. Replace 410674 circuit card. Replace 410002 circuit card in DL. Replace 341740 cable to DL. Replace opcon.
5. Can set send and receive properly on-line?	Go to 7.	Go to 6.

TABLE F (Contd)

KD OR KDP CONTROLLER

ANALYSIS QUESTION	"YES" RESPONSE DIRECTIVE	"NO" RESPONSE DIRECTIVE
6. Enter the sequence L*L/* across the first line. With cursor in home position and REC key lighted, depress TS6 test switch on 410771 circuit card. Does cursor move across line and *'s change to Us? (SEND and REC key lights flash on and off while TS6 test switch is depressed.)	Check 9140 Station Controller and the 9140 interconnect cable. Refer to Manual 352, Part 8.	Replace 410771 circuit card. Replace 410674 circuit card. Replace 410675 circuit card.
7. Does set respond properly to control characters and sequences? (Example: VT and EOT.)	Go to 8.	Replace 410674 circuit card. Replace 410675 circuit card. Replace 410710 circuit card (if so equipped).
8. Can proper escape sequence be sent on-line? (Example: ESC3 for highlight, ESC4 for no highlight.)	Go to 9.	Replace 410676 circuit card. Replace 410675 circuit card. Replace 410674 circuit card. Replace 410002 circuit card in DL.
9. With ☰ displayed on monitor, can proper line ending sequence (LF, CR LF, CR CR LF) be sent on-line? (The sequence is dependent on the Option 4-10.)	Go to 10.	Replace 410675 circuit card. Replace 410674 circuit card.
10. KDP, KD-ROP, KDP portion of "KDP&ROP" or "KDP+ROP" only: Do the PRINT ON LINE and PRINT LOCAL operations function properly? (Step 10 does not apply to KD&ROP or KD+ROP. Note of Step 4 applies.)	Controller is OK. Trouble is elsewhere.	Replace 410770 circuit card. Replace 410674 circuit card. KD-ROP only: Go to Table G, 40C103 ROP Controller (Page 160). KDP only: Replace printer.

E. TROUBLESHOOTING (Cont'd)

TABLE G

40C103 ROP CONTROLLER

Note 1: 40C103/AD ROP controller includes a buffer (character storage).

Note 2: 40C103/AE ROP controller does not include a buffer.



CIRCUIT CARD LOCATION

40C103/AD	40C103/AE	POSITION
410582	410582	JA
410581 or 410585	410587	JB
410580	410580	JC
410583	410583	JD

410581 and 410585 are interchangeable.

ANALYSIS QUESTION	"YES" RESPONSE DIRECTIVE	"NO" RESPONSE DIRECTIVE
1. Does IN SERVICE lamp on ROP opcon fail to light?	Replace 410580 circuit card.	Go to 2.
2. Is the correct test message printed when the TRANS START key on the ROP opcon is depressed, and does the TRANS START lamp turn ON? (See Page 161 for sample test message.)	Go to 3.	Replace 410583 circuit card. Replace 410582 circuit card. Replace 410580 circuit card.
3. Are messages received on-line?	Go to 4.	Check data set and transmission line facilities. Replace 410580 circuit card. Replace 410582 circuit card.

TABLE G (Contd)

40C103 ROP CONTROLLER

ANALYSIS QUESTION	"YES" RESPONSE DIRECTIVE	"NO" RESPONSE DIRECTIVE
4. Do messages received on-line contain errors? (Does the DATA ERROR lamp, if used, remain OFF when errors are received, or turn ON when errors are not received?)	Replace 410580 circuit card. Replace 410582 circuit card. Replace 410584 circuit card (interconnecting.	If controller code is 40C103/AK, go to 5. If controller code is 40C103/AD, go to 6.
5. Does data stacking feature operate properly — no loss of characters (40C103/AE)? *Note:* Data stacking prevents data loss by placing more char acters on printed lines (no buffer).	ROP controller is OK. Trouble is elsewhere.	Check to see that controller has a 410587 circuit card in position JB, Issue 2 or later. Check to see that Option 4-38.a. on 410582 is enabled. Replace 410582 circuit card.
6. Is the buffer (character storage) operating properly — no lost characters or blocks of characters, no erroneous message termination, etc?	ROP controller is OK. Trouble is elsewhere.	Replace 410581 or 410585 circuit card. *Note:* These two cards are interchangeable. Replace 410580 circuit card. Replace 410582 circuit card.

Option 4-19.c. only: (See Note below.)

☑:"#$%&'()*+,-./0123456789:;<=>?@ABCDEFGHIJKLMNOPQRSTUVWXYZ[\]^_

☑:"#$%&'()*+,-./0123456789:;<=>?@ABCDEFGHIJKLMNOPQRSTUVWXYZ[\]^_

└— Where ☑ represents the errored character symbol.

Two Lines of Test Pattern

Option 4-19.a. only: (See Note below.)

▯:"!▯▯▯'()▯+▯-▯/▯▯▯

NOTES

PART 6 — WIRING DIAGRAMS
A. GENERAL

This part provides wiring diagrams and cable components referred to in PART 2 – IDENTIFICATION and PART 3 – INSTALLATION of this manual.

The KD, and KDP drawings give the complete wiring between the various components. The components are shown as blocks and are labeled accordingly. If it becomes necessary to check the wiring of one of the above listed components, the page number for that drawing will be given in the appropriate block on the station drawing on which it appears. Drawings of the wired frames for the controller(s) and display logic are not given.

Where possible, small notes indicating voltage levels have been added to aid in trouble locating. The location of any cable can be attained by referring to the appropriate manual listed in Part 1 of this manual.

Danger: Whenever the monitor cover is removed, safety glasses should be worn. Also, the high voltage lead to the CRT should never be probed.

The wiring of the data set to the phone line (and to the telephone set, if applicable) is not given in this manual. Refer to the applicable data set or modem literature.

The wiring of ROP sets equipped with a 40C303 Integrated Controller is given in Manual 360.

If a more comprehensive presentation of the wiring information is required, the following wiring diagram packages are available from Teletype Corporation.

WDP0138	9140 Controller and Power Supply
WDP0383	40C202/– Controller
WDP0396	4025/ — KD & 4030/ — KDP With 40C202/ — Controller
WDP0400	40MN101 Display Monitor
WDP0401	ROP Set With 40C103
WDP0402	40C103 ROP Controller
WDP0403	40K101 Operator Console
WDP0404	40K001 ROP Opcon
WDP0405	40PSU101 Power Supply
WDP0423	40DL291 Display Logic
WDP0435	
WDP0436	40 Printers
WDP0441	40C303 Controller (TF Set)
WDP0462	Tractor Printer
WDP0463	40P201 Tractor Printer (132-Column)
WDP0481	Integrated Controller
WDP0487	40C303 Controller (FF Set)
1210SD	SSI Quiet Friction Printer Set
	Schematic Wiring Diagram of 344755 Individual Receiver Selection Modification Kit

When ordering replaceable components, unless otherwise specified, prefix each part number with the letters "TP" (ie, TP410055).

B. WIRING DIAGRAMS

The following list contains the figure and page numbers of all the wiring diagrams.

FIGURE	CONTENT	PAGE
1	ROP Cabinet with 40C103 Controller	165
2	KDP Set — Adjacent Printer	166
3	KDP Set — Printer Under Monitor	168
4	Printer Cabinets	170
5	40P101/ZZ Friction Feed Printer	171
6	40P102/ZZ Friction Feed Printer	172
7	40P151/ZZ 80-Column Tractor Feed Printer (Early Design)	173
8	40P151/ZZ 80-Column Tractor Feed Printer (Late Design)	174
9	40P153/ZZ 80-Column Tractor Feed Printer (Early Design)	175
10	40P153/ZZ 80-Column Tractor Feed Printer (Late Design)	176
11	40P184/ZZ 80-Column Tractor Feed Printer	178
12	40P201/ZZ and 40P202/ZZ 132-Column Tractor Feed Printer	180
13	40P253/ZZ Forms Access Tractor Feed Printer	182
14	40PSU101 Power Supply (Early Design)	184
15	40PSU101 Power Supply (Late Design)	185
16	40K101 Operator Console (Early Design)	186
17	40K101 Operator Console (Late Design)	186
18	40MN101/AA Display Monitor	187
19	341893 Monitor Extension Cable Assembly	188
20	341895 Printer Extension Cable Assembly	189
21	341896 Data Set Cable Assembly	190
22	344545 Individual Receiver Selection Cable Assembly	191
23	345603 Interface Cable Assembly (KD, KDF, KD-ROP)	192
24	345613 Interface Cable Assembly (KD & ROP or KDP & ROP)	193
25	346333 Opcon Bus Cable Assembly	194
26	401640 Printer Extension Cable Assembly	195
27	401641 Opcon Extension Cable Assembly	196
28	405306, 405307, 405308 or 405309 Printer Extension Cable Assembly	197
29	405373 Through 405378 Keyboard/Display Cable Assembly	198
30	408063 Through 408068 EIA Data Set Cable Assembly	199
31	408888 Adapter Cable Assembly	200


FAN SWITCH ON FRONT OF PRINTER
40C4B30
WIRE HARNESS
TO 40P10/J1
TO 40P10/J2
TO 40P10/J3
TO EPSON CONNECTOR ON REAR OF 40C4822 (PC)
40C4822 (PC)
TO EPSON CONNECTOR ON REAR OF 40C4822 (PC)
40C4822 (PC)
40C4822 (PC)

B. WIRING DIAGRAMS (Contd)



Fig. 2—KDP Set — Adjacent Printer



Fig. 2—KDP Set — Adjacent Printer (Contd)

B. WIRING DIAGRAMS (Contd)





Fig. 3—KDP Set — Printer Under Monitor (Contd)

B. WIRING DIAGRAMS (Contd)



LEGEND

O - FEMALE PIN
● - MALE PIN
\ - NO PIN PRESENT

Fig. 4—Printer Cabinets



Fig. 5—40P101/ZZ Friction Feed Printer

B. WIRING DIAGRAMS (Contd)



Fig. 6–40P102/ZZ Friction Feed Printer



Fig. 7—40P151/ZZ 80-Column Tractor Feed Printer (Early Design)

B. WIRING DIAGRAMS (Contd)



Fig. 8—40P151/ZZ 80-Column Tractor Feed Printer (Late Design)



Note 1: If printer contains a 410640 logic card of assembly Inner 15J or earlier, pins 1 and 42 of J1 and J2 are connected to the +24 V scanner supply line. If the printer contains a 410640 logic card of Inner 16A or later or a 410676 logic card, pins 1 and 42 of J1 and J2 are connected to circuit ground.

Note 2: Paper-low switch is optional (modification kit 402920).

Fig. 9—40P153/ZZ 80-Column Tractor Feed Printer (Early Design)

B. WIRING DIAGRAMS (Contd)



Note 1: If printer contains a 410640 logic card of assembly issue 15J or earlier pins 1 and 62 of J1 and J2 are connected to the -24 V support supply line. If the printer contains a 410640 logic card of issue 16A or later or a 410976 logic card pins 1 and 62 of J1 and J2 are unconnected to circuit ground.

Note 2: Paper ioss switch is optional (modification kit 4009910).

Fig. 10—40P153/ZZ 80-Column Tractor Feed Printer (Late Design)

NOTES

B. WIRING DIAGRAMS (Contd)

Note: Grounding Option — Inserting Option Screw A on component side of 4101/51 circuit card connects -24 V dc circuit common to chassis. Inserting Option Screw B on component side of 4101/51 circuit card connects -24 V dc circuit common to +5 V dc circuit common. Inserting Option Screw A or B into noncomponent side of card leaves connection open. Refer to Option 61.


COVER ASSEMBLY
POWER FOR CONTROL CONTROLLER
115 VAC
60 COMMON
5 VAC
115 VAC
TRANSFORMER
115 VAC
PAPER OUT LAMP TO LAMP
PAPER OUT SENSOR
PAPER OUT SENSOR ASSEMBLY
PAPER OUT LAMP
PAPER OUT SENSOR
PAPER OUT SENSOR ASSEMBLY



Fig. 11—40P154/ZZ 80-Column Tractor Feed Printer (Contd)

B. WIRING DIAGRAMS (Contd)

Note 1: Grounding Option — Inserting Option Screw A on component side of 410516 circuit card connects 24 V dc common to chassis. Inserting Option Screw B on component side of 410151 circuit card connects 24 V dc common to +12.2 V dc circuit common. Inserting either screw into noncomponent side of card leaves connection open.

Note 2: If the printer is equipped with a 410728 logic card, pins 1 and 68 of 410650 magnet bank assemblies will be connected to the -24 V magnet common. If the printer is equipped with a 410072 logic card, pins 1 and 68 of the 410650 magnet bank assemblies will be connected to magnet ground.


COVER ASSEMBLY
J600
P600
J601
P601
J602
P602
J603
P603
J604
P604
J605
P605
J606
P606
J607
P607
J608
P608
J609
P609
J610
P610
J611
P611
J612
P612
J613
P613
J614
P614
J615
P615
J616
P616
J617
P617
J618
P618
J619
P619
J620
P620
J621
P621
J622
P622
J623
P623
J624
P624
J625
P625
J626
P626
J627
P627
J628
P628
J629
P629
J630
P630
J631
P631
J632
P632
J633
P633
J634
P634
J635
P635
J636
P636
J637
P637
J638
P638
J639
P639
J640
P640
J641
P641
J642
P642
J643
P643
J644
P644
J645
P645
J646
P646
J647
P647
J648
P648
J649
P649
J650
P650
J651
P651
J652
P652
J653
P653
J654
P654
J655
P655
J656
P656
J657
P657
J658
P658
J659
P659
J660
P660
J661
P661
J662
P662
J663
P663
J664
P664
J665
P665
J666
P666
J667
P667
J668
P668
J669
P669
J670
P670
J671
P671
J672
P672
J673
P673
J674
P674
J675
P675
J676
P676
J677
P677
J678
P678
J679
P679
J680
P680
J681
P681
J682
P682
J683
P683
J684
P684
J685
P685
J686
P686
J687
P687
J688
P688
J689
P689
J690
P690
J691
P691
J692
P692
J693
P693
J694
P694
J695
P695
J696
P696
J697
P697
J698
P698
J699
P699
J700
P700
J701
P701
J702
P702
J703
P703
J704
P704
J705
P705
J706
P706
J707
P707
J708
P708
J709
P709
J710
P710
J711
P711
J712
P712
J713
P713
J714
P714
J715
P715
J716
P716
J717
P717
J718
P718
J719
P719
J720
P720
J721
P721
J722
P722
J723
P723
J724
P724
J725
P725
J726
P726
J727
P727
J728
P728
J729
P729
J730
P730
J731
P731
J732
P732
J733
P733
J734
P734
J735
P735
J736
P736
J737
P737
J738
P738
J739
P739
J740
P740
J741
P741
J742
P742
J743
P743
J744
P744
J745
P745
J746
P746
J747
P747
J748
P748
J749
P749
J750
P750
J751
P751
J752
P752
J753
P753
J754
P754
J755
P755
J756
P756
J757
P757
J758
P758
J759
P759
J760
P760
J761
P761
J762
P762
J763
P763
J764
P764
J765
P765
J766
P766
J767
P767
J768
P768
J769
P769
J770
P770
J771
P771
J772
P772
J773
P773
J774
P774
J775
P775
J776
P776
J777
P777
J778
P778
J779
P779
J780
P780
J781
P781
J782
P782
J783
P783
J784
P784
J785
P785
J786
P786
J787
P787
J788
P788
J789
P789
J790
P790
J791
P791
J792
P792
J793
P793
J794
P794
J795
P795
J796
P796
J797
P797
J798
P798
J799
P799
J800
P800
J801
P801
J802
P802
J803
P803
J804
P804
J805
P805
J806
P806
J807
P807
J808
P808
J809
P809
J810
P810
J811
P811
J812
P812
J813
P813
J814
P814
J815
P815
J816
P816
J817
P817
J818
P818
J819
P819
J820
P820
J821
P821
J822
P822
J823
P823
J824
P824
J825
P825
J826
P826
J827
P827
J828
P828
J829
P829
J830
P830
J831
P831
J832
P832
J833
P833
J834
P834
J835
P835
J836
P836
J837
P837
J838
P838
J839
P839
J840
P840
J841
P841
J842
P842
J843
P843
J844
P844
J845
P845
J846
P846
J847
P847
J848
P848
J849
P849
J850
P850
J851
P851
J852
P852
J853
P853
J854
P854
J855
P855
J856
P856
J857
P857
J858
P858
J859
P859
J860
P860
J861
P861
J862
P862
J863
P863
J864
P864
J865
P865
J866
P866
J867
P867
J868
P868
J869
P869
J870
P870
J871
P871
J872
P872
J873
P873
J874
P874
J875
P875
J876
P876
J877
P877
J878
P878
J879
P879
J880
P880
J881
P881
J882
P882
J883
P883
J884
P884
J885
P885
J886
P886
J887
P887
J888
P888
J889
P889
J890
P890
J891
P891
J892
P892
J893
P893
J894
P894
J895
P895
J896
P896
J897
P897
J898
P898
J899
P899
J900
P900
J901
P901
J902
P902
J903
P903
J904
P904
J905
P905
J906
P906
J907
P907
J908
P908
J909
P909
J910
P910
J911
P911
J912
P912
J913
P913
J914
P914
J915
P915
J916
P916
J917
P917
J918
P918
J919
P919
J920
P920
J921
P921
J922
P922
J923
P923
J924
P924
J925
P925
J926
P926
J927
P927
J928
P928
J929
P929
J930
P930
J931
P931
J932
P932
J933
P933
J934
P934
J935
P935
J936
P936
J937
P937
J938
P938
J939
P939
J940
P940
J941
P941
J942
P942
J943
P943
J944
P944
J945
P945
J946
P946
J947
P947
J948
P948
J949
P949
J950
P950
J951
P951
J952
P952
J953
P953
J954
P954
J955
P955
J956
P956
J957
P957
J958
P958
J959
P959
J960
P960
J961
P961
J962
P962
J963
P963
J964
P964
J965
P965
J966
P966
J967
P967
J968
P968
J969
P969
J970
P970
J971
P971
J972
P972
J973
P973
J974
P974
J975
P975
J976
P976
J977
P977
J978
P978
J979
P979
J980
P980
J981
P981
J982
P982
J983
P983
J984
P984
J985
P985
J986
P986
J987
P987
J988
P988
J989
P989
J990
P990
J991
P991
J992
P992
J993
P993
J994
P994
J995
P995
J996
P996
J997
P997
J998
P998
J999
P999
J1000
P1000
POWER FOR CONTROLLER
TO AC POWER CONTROLLER
LINE FEED MOTOR
PAPER OUT LAMP
PAPER OUT SENSOR
PAPER OUT LAMP TO LAMP
+5 VDC LOGIC
-24 VDC LOGIC
FORM OR PAPER ADVANCE
FORM OR PAPER ADVANCE MOTOR
ACTIVE/LOCKED LINE PRINTER
ACTIVE/LOCKED MOTOR OR FORM FROM CONTROLLER
NOT USED
TO 24 V CONTROLS
PAPER OUT SENSOR
PAPER OUT LAMP
LINE FEED MOTOR
PAPER OUT SENSOR
PAPER OUT LAMP
SEE NOTE 2
SEE NOTE 1
SEE NOTE 2
SEE NOTE 1
SEE NOTE 2
SEE NOTE 1



Fig. 12—40P201/ZZ and 40P202/ZZ 132-Column Tractor Feed Printer (Contd)

B. WIRING DIAGRAMS (Contd)



Note: Grounding Option — Inserting Option Screw A on component side of 410151 circuit card connects -24 V dc circuit common to chassis. Inserting Option Screw B on component side of 410151 circuit card connects -24 V dc circuit common to +11.3 V dc circuit common. Inserting Option Screw A or B into noncomponent side of card leaves connection open. Refer to Option 61.

Fig. 13—40P253/ZZ Forms Access Tractor Feed Printer



Fig. 13—40P253/ZZ Forms Access Tractor Feed Printer (Contd)

B. WIRING DIAGRAMS (Contd)



Note: The two black wires attached to the circuit card bus bar can be removed by taking out the nut and bolt which hold both wires to the bus bar.

Fig. 14—40PSU101 Power Supply (Early Design)



Transformer
Wiring Colors

1 - R
2 - G-Y
3 - R-Y
4 - BK
5 - BK

Fig. 15—40PSU101 Power Supply (Late Design)

B. WIRING DIAGRAMS (Contd)



Note: Interface to controller shown.

*PRESENT ONLY ON EARLY UNITS.

Fig. 16—40K101 Operator Console (Early Design)



Note: Interface to controller shown. Refer to Fig. 16 for additional detail.

Fig. 17—40K101 Operator Console (Late Design)



Fig. 18–40MN101/AA Display Monitor

B. WIRING DIAGRAMS (Contd)





Note: Used to connect display monitor in KDP arrangements having friction printer under monitor. Not for use with free standing monitor on separate 40BSE101 monitor base.

Fig. 19–341893 Monitor Extension Cable Assembly



Fig. 20—341895 Printer Extension Cable Assembly

B. WIRING DIAGRAMS (Contd)

	341977 CONNECTOR		341978 CONNECTOR
Data Set End	1	BK	1
	2	BR	2
	3	R	3
	4	O	4
	5	Y	5
	6	G	6
	7	BL	7
	8	P	8
	11	S	11
	12	W	12
	15	W-BK	15
	17	W-BR	17
	20	W-R	20
	22	W-O	22
	23	W-Y	23

ACTUAL WIRING

Note 1: 341896 cable is replaced by 408065 shielded cable assembly in 40/3 station arrangements.

Note 2: 341896 cable is also used in KD-ROP to connect KD to ROP.



Fig. 21—341896 Data Set Cable Assembly





Fig. 22–344545 Individual Receiver Selection Cable Assembly (Part of 344555 Modification Kit)

B. WIRING DIAGRAMS (Contd)

341977 CONNECTOR (X)		341978 CONNECTOR (D)
1	BK	1
2	BR	2
3	R	3
4	O	4
5	Y	5
7	BL	7
8	P	8
11	W-BK	11
12	W-BR	12
13	W-R	13
14	W-O	22
15	W-Y	15
19	W-S	6
20	W-BK-BK	20
21	W-BK-BR	21
23	W-BK-O	23
25	W-BK-BL	25

ACTUAL WIRING



Fig. 23—345603 Interface Cable Assembly (KD, KDP, KD-ROF)



Fig. 24–345613 Interface Cable Assembly (KD & ROP or KDF & ROP)

B. WIRING DIAGRAMS (Contd)





Fig. 25–346333 Opcon Base Cable Assembly





Note: Late design shielded cable shown. Early design cable does not have 181392 grounding terminals and had a bare single wire in lieu of shield.

Fig. 26–401640 Printer Extension Cable Assembly

B. WIRING DIAGRAMS (Contd)



Note: Late design shielded cable shown. Early design cable does not have 181393 grounding terminals and had a bare single wire in lieu of shield.

Fig. 27—401641 Opcon Extension Cable Assembly



CABLE	LENGTH
405306	6 FT
405307	12 FT
405308	25 FT
405309	50 FT

Fig. 28—405306, 405307, 405308 or 405309 Printer Extension Cable Assembly

B. WIRING DIAGRAMS (Contd)

KEYBD CONNECTOR		ADDRAY CONNECTOR
1	R	1
2	G	2
3	B	3
4	W-B	4
5	C	5
6	W-BL	7
7	W-BR	8
8	DRAIN WIRE	9

DISPAY CONNECTOR		MAIN CONNECTOR
1	BL	1
2	W	2
3	R	3
4	DRAIN WIRE	4
5	BR	5
6	W-P	6
8	W-Y	9
10	P	10
11	W-BR	11
12	W-G	12
13	BK	13
14	W-O	14
15	W-T	15

ACTUAL WIRING



Fig. 29—405373 Through 405378 Keyboard/Display Cable Assembly



CABLE	LENGTH
408065	7 FT
408066	12 FT
408067	25 FT
408068	50 FT

Note 2: Each 406043 screw retainer kit contains two screws and retainers.

Note 3: The 341896 cable assembly is replaced by the 408065 shielded cable assembly in the 40/3 KD, KDP, and KD-ROP.

Fig. 30—408065 Through 408068 EIA Data Set Cable Assembly

B. WIRING DIAGRAMS (Contd)





Fig. 31–408888 Adapter Cable Assembly

PART 7 — ADJUSTMENTS

The only adjustments in the station are in printer and monitor.

Monitor adjustments are given in Manual 401.

Printer adjustments are given in Manual 399.

PART 8 — TOOLS AND SUPPLIES

The following tools and supplies may be required for installation or servicing of 40/3-type apparatus. Except for items prefixed CP, the part numbers should be prefixed with the letters "TP" (ie, TP410055) and ordered from:

Teletype Corporation
5555 W. Touhy Avenue
Skokie, Illinois 60077

Items prefixed with the letters "CP" (ie, CP10.018.000) should be ordered from:

Teletype Corporation
Custom Systems Division
5555 W. Touhy Avenue
Skokie, Illinois 60077

Tools

Wrench	3/16" socket	125752
Wrench, open end	3/8"	125765
Wrench, open end	3/16" and 1/4"	129534
Wrench, open end	5/16" and 3/8"	152835
Wrench, open end	3/4"	129537
Nut driver	Handle	135676
Nut driver	1/4"	89954
Nut driver	5/16"	89955
Nut driver	1/4"	135677
Nut driver	5/16"	135678
Screwdriver	1/8", 2" blade	93368
Screwdriver	1/4", 6" blade	100982
Screwdriver	(blade less than 5/32")	94647
Allen wrench	0.062	124682
Tweezers		151392
Spring hook (pull)		142554
Spring hook (pull)		75675
Spring hook (push)		75503
Static ground strap		346392
Scales, spring (8)		110443
Ruler, 6"		95960
Cleaning brush (type face)		151394
Long-nose pliers		108285
Cutting pliers		108286
Terminal extractor		182697
Retaining ring pliers		160396
Terminal extractor		341983
Keyswitch extractor		346257

PART 8 — TOOLS AND SUPPLIES (Contd)

Tools (Contd)

Keytop extractor	346260
Gauge (80-column friction and tractor feed printers)	402617
Gauge (132-column tractor feed printer)	402716
Gauge (132-column tractor feed printer)	402717
Dynamic backup bar gauge	403868
Type carrier alignment gauge	402878
Terminal extractor	402840
Extender card for 9140 circuit cards	343980
Extender cable for Model 40 tractor feed printers	CP10.008.003.1
Extender cable for Model 40 friction feed printers	CP10.008.004.1
Extender card for Models 40/0, 1, 2 and 3 circuit cards	CP10.018.000

Supplies

Grease — Mobil No. 2 (1 lb can)	143484
Grease — Mobil No. 2 (4 oz tube)	145867
Grease — Beacon 325 (5 lb can)	195298
Oil — KS7470 (1 qt can)	88970
Ribbon	402444
Paper (friction feed) — standard 8-1/2" wide, 5" dia roll	
Paper (tractor feed)	
Freon TF degreaser (6 oz aerosol can)	337449
Thermal joint compound (obtained locally)	