

Bulletin No. 1094
Issue 1
February, 1942

TELETYPE

PRINTING TELEGRAPH SYSTEMS

PARTS
TYPE BAR PAGE PRINTER
(MODEL 15)







I
ALPHABETICAL INDEX


	<u>Page</u>
Armatures	26
Basket - Type Bar	13,14
Base (Assem.)	17,22
Bells	2,5
Bell Crank Levers (Assem.)	15
Cables.	9,12,17,22,26
Cam Sleeve (Assem.)	3,23
Carriage Return Spring Drum (Assem.).	5
Clamps - Cable.	17,21
Condensers.	20,29
Connecting Strip.	21
Contact (Assem.)	9,23
Code Bars	15,30
Connecting Block.	18
Control Relay (Assem.)	20
Cords (Assem.)	19
Cover	24
Cover Doors	24,25
Cover Front Plates.	25
Copyholder.	25
Crank Handle.	9
Cross Bar (Assem.)	4,5
Dashpot Parts	1
Felt Pads	17,24
Filter Units.	29
Frame Parts - Left Side	1
Frame Parts - Right Side.	2
Function Levers	6,7,8
Function Lever Bail (Assem.)	6,31
Function Push Bar and Cross Bar (Assem.).	4
Fusetrons and Fustats	19
Gears	3,5,15,23,26,27
Governor (Assem.)	28
Governor Brush and Speed Adjusting Bracket (Assem.)	28
Guards.	18,21
Handle.	9
Index - Numerical	34
Jack (Assem.)	18
Key (Test).	22
Key Levers.	22
Keyboard (Assem.)	22
Keyboard Shaft (Assem.)	23


	<u>Page</u>
Keyboard Track	21
Keytops.	7,16,22,30
Lamp	19
Line and Selector Jack (Assem.).	18
Lock Bar Latch and Carriage Return Lock Bar (Assem.)	5
Margin Adjusting Screws.	14
Margin Bell.	2
Main Shaft (Assem.).	3
Message Line Guide	25
Motor Units.	26,27
Motor Stop Contacts.	9
Motor Stop Locking (Assem.).	12
Name Plates.	25,26,27
Notes of Explanation	32
Numerical Index.	34
Pads - Felt.	17,24
Paper Roll Spindle	21
Pallets.	30
Pinions.	26,27
Platen (Assem.) - Friction Feed.	10
Printing Bail (Assem.).	4
Platen Roll - Rubber and Steel Jacketed.	9,11
Power Line Cords	19
Pull Bars.	13,30
Range Finder (Assem.).	12
Rear Cross Bar	4,5
Relay.	20
Relay Base	18
Relay Connecting Block	18
Reset Lever Downstop and Unshift on Space Cut-out Lever (Assem.)	9
Ribbon Feed Mechanism.	14,15
Ribbon Lockout Lever (Assem.).	13
Ribbon Reverse Mechanism	14,15
Resistors.	18,20,21,22,29
Resistance Mounting Block (Assem.).	17
Rotors (Assem.).	27
Selector Bars.	22
Selector Unit - Pulling Magnet (Assem.).	12
Selector Vane (Assem.).	6
Send-Receive Break Mechanism	18,31
Set of Keytops	7
Set of Paper Guide Parts	11
Set of Parts to Convert from Friction Feed to Sprocket Feed.	11
Set of Pallets	7



	<u>Page</u>
Set of Parts for Tabulator	16
Set of Parts to Convert 15 Printer Sets to Disseminate Weather Map Data.	7
Set of Parts (New Sixth Vane Extension).	4
Shaft - Keyboard	23
Shaft - Main	3
Sixth Vane Extension	4
Sixth Vane Detent Lever (Assem.)	6
Slip Connection Mounting (Assem.).	21
Spacing Cross Bar.	5
Spacing Gear	5
Spacing Rack	14
Spring Drum (Assem.)	5
Switches	17,19,26
Tabulator Parts.	16
Target Lamp (Assem.)	19,26
Terminal Block (Assem.).	17,20,22
Terminal Straps.	12,19
Test Key	22
Toggle Switches.	17,19,26
Tracks	13,21
Transmitter (Assem.)	23
Type Bars.	13,30
Type Bar Backstop (Assem.)	13
Type Bar Basket (Assem.)	13,14
Type Bars (With Pallets)	30
Unshift on Space Cutout.	9
Upper Case "H" Motor Stop Mechanism.	6,8,9,12,30,32
Upper Case "M" Motor Stop Mechanism.	6,8,9,12,30,32
Weather Map - Parts for Disseminating Data	7

















(A) (B) SEE PAGE 32 FOR EXPLANATION







90103 SET OF PARTS FOR CONVERTING MODEL 15 PRINTER SETS, EQUIPPED WITH SPRING CUSHION KEYTOPS, TO DISSEMINATE WEATHER MAP DATA.
INCLUDES 84061, 84927, 84928, 82750 & 90101.



84061 BLANK PRINTING- SPACING CUT-OUT LEVER (ASSEM)
(SUPPRESSES PRINTING & SPACING ON LOWER CASE BLANK)



84927 CARRIAGE RETURN
FUNCTION LEVER #2-B

FOR C.R. AND L.F. OPERATION IN LOWER CASE ONLY


84928 LINE FEED
FUNCTION LEVER #12-A

82750 SET OF TYPE PALLETS			
CAT. NO.	DESCRIP- TION	CAT. NO.	DESCRIP- TION
82147	A ↑	82154	L ↘
82148	D ↗	82420	B ⊕
82149	F →	82421	V ⊖
82150	G ↖	84069	N ⊙
82151	H ↓	82423	C ○
82152	J ↙	82751	Z +
82153	K ←	84025	-


90101 SET OF SPRING CUSHION KEYTOPS			
CAT. NO.	DESCRIP- TION	CAT. NO.	DESCRIP- TION
89413	-	89420	K ←
89414	A ↑	89421	L ↘
89415	D ↗	89422	Z +
89416	F →	89423	C ○
89417	G ↖	89424	V ⊖
89418	H ↓	89425	B ⊕
89419	J ↙	89426	N ⊙

FUNCTION LEVERS


CATALOG NUMBER	POSITION USED	FUNCTION PERFORMED	SPRING	CODE SELECTION	STAMPING
74040	1	LOCKS VANES	74962	ALL COMBINATIONS	1
74131	2	CARRIAGE RETURN	74961	--- 4 --	2
84927	2	CARRIAGE RETURN IN "LETTERS" POSITION ONLY.	74961	--- 4 --	2-B
74128	3	SHIFT TO "FIGURES" POSITION.	74962	1 2 - 4 5	3
74138	4	BELL ON "FIGURES" "5"	74961	1 - 3 --	4
74109	5	RESETS SEND-RECEIVE BREAK MECHANISM	86873	ANY PRINTED CHARACTER	5-A
84792	6	TABULATION ON "FIGURES" "Z"	74705	1 --- 5	6-A
86768	6	TABULATION ON "FIGURES" "G"	74705	- 2 - 4 5	6-B
74932	7	SUPPRESSES PRINTING & SPACING ON "BLANK"	87402	-----	7-A
84060	7	SUPPRESSES PRINTING & SPACING ON "BLANK", IN "LETTERS" POSITION ONLY	4708	-----	7-B
74130	9	SHIFT TO "LETTERS" POSITION ON SPACE	74962	-- 3 --	9
74039	10	OPERATES SEND-RECEIVE BREAK MECHANISM ON "BLANK" SIGNAL.	74705	-----	10
74129	11	SHIFT TO "LETTERS" POSITION	74962	1 2 3 4 5	11
74127	12	LINE FEED	74962	- 2 ---	12
84928	12	LINE FEED IN "LETTERS" POSITION ONLY.	74962	- 2 ---	12-A
(A) 74038	13	MOTOR STOP ON "FIGURES" "H"	82788	-- 3 4 5	13
(B) 82271	13	MOTOR STOP ON "FIGURES" "H"	82787	-- 3 -- 5	13-B
(A) (B) SEE PAGE 32 FOR EXPLANATION					







SEE WIRING DIAGRAM FOR CABLES




②② SEE PAGE 32 FOR EXPLANATION




Ⓐ SEE PAGE 32 FOR EXPLANATION








(A) (B) (C) SEE PAGE 32 FOR EXPLANATION

SEE WIRING DIAGRAM FOR CABLES











Ⓐ Ⓢ SEE PAGE 33 FOR EXPLANATION




(A) SEE PAGE 33 FOR EXPLANATION








(A) 82917 SEND - REC. BREAK MECHANISM(ASSEM.)







(A) SEE PAGE 31 FOR OLD STYLE


SEE WIRING DIAGRAM FOR CABLES




FUSETRONS	
CAT. NO.	AMPERES
103290	.6
103289	.8
103287	1.25
103288	1.4
103286	1.6
103284	3.2
103285	6.25













95050 CORD (ASSEM.) WITH PLUG - SHIELDED





95052 CORD (ASSEM.) WITH PLUG - SHIELDED












SEE WIRING DIAGRAM FOR CABLES




74690 TRANSMITTER (ASSEM.)
WITH 7381 CONTACT MOUNTING (ASSEM.)




7381 CONTACT MOUNTING (ASSEM.)




(A) SEE PAGE 33 FOR EXPLANATION



93183 COVER (ASSEM.) BLACK WRINKLE
82322 COVER (ASSEM.) BLACK GLOSS



(A) SEE PAGE 33 FOR EXPLANATION




GOVERNED MOTORS

77953 MOTOR - 1/25 H.P. - 110 V. - A.C. - 60 CYCLE (G.E. MODEL 32989 OR 5BA65AA29) (EXCLUDES PARTS MARKED ④)
 74839 MOTOR UNIT (ASSEM.) (77953 MOTOR) (EXCLUDES PARTS MARKED ④ & ④)


72586 MOTOR 1/17 H.P. - 110 V. - D.C. (G.E. MODEL 31531) (EXCLUDES PARTS MARKED ④)
 74840 MOTOR UNIT (ASSEM.) (72586 MOTOR) (EXCLUDES PARTS MARKED ④ & ④)

SEE WIRING DIAGRAM FOR CABLES




SYNCHRONOUS MOTORS




- 82283 SYNCHRONOUS MOTOR- 1/40 H.P.- 110V.- A.C.- 60 CYCLE (G.E. MODEL 5SH25ABII) (EXCLUDES PARTS MARKED (A))
 80439 SYNCHRONOUS MOTOR UNIT (ASSEM.) (EXCLUDES PARTS MARKED (B) & (D))
 82714 SYNCHRONOUS MOTOR- 1/40 H.P.- 110V.- A.C.- 50 CYCLE (G.E. MODEL 5SH25AB14) (EXCLUDES PARTS MARKED (A))
 84901 SYNCHRONOUS MOTOR UNIT (ASSEM.) (EXCLUDES PARTS MARKED (C) & (D))




80352 CENTER CONTACT GOVERNOR (ASSEM.)
EXCLUDES PARTS MARKED (A)



80341 GOVERNOR BRUSH & SPEED ADJUSTING BRACKET (ASSEM.)



CODE BARS	
NUMBER STAMPED ON BAR	CATALOG NUMBER
ID	74180
2D	74181
3D	74182
4D	74183
5D	74184



NOTE


CHECK CAREFULLY THE POSITION OF PULL BARS IN SEGMENT AND THE ARRANGEMENT OF THE TYPE PALLETS ON THE TYPE BARS. IF THESE DIFFER IN ANY WAY WITH THE ARRANGEMENT SHOWN ON THIS PAGE, THE FOLLOWING PARTS SHOULD BE ORDERED BY NAME. FOR EXAMPLE ORDER:-

TYPE PALLET.....(A --)
TYPE BAR 17 WITH PALLET.....(A --)
PNEUMATIC KEY TOP.....(A --)

NUMBER OF POSITION IN SEGMENT	PULL BARS		TYPE BARS WITHOUT PALLETS		TYPE BAR PALLETS		TYPE BARS WITH PALLETS		PULL BAR SPRING		SPRING CUSHION KEYTOP CATALOG NUMBER	KEYTOP DESCRIPTION
	CATALOG NUMBER	DESCRIPTION	CATALOG NUMBER	NUMBER ON BAR	CATALOG NUMBER	DESCRIPTION	CATALOG NUMBER	NUMBER ON BAR				
1												
2	74185	STANDARD	74202	2	74302	.	74642	2	7634		78979	*
2	74185	"	74202	2	84025	-	84734	2	7634		89413	-
3	74185	"	74203	3	74303	Z "	74643	3	7634		78970	Z *
3	74185	"	74203	3	82751	Z +	84735	3	7634		89422	Z +
4	74185	"	74204	4	74304	K (74644	4	7634		78956	K (
4	74185	"	74204	4	82153	K ←	84736	4	7634		89420	K ←
5	74185	"	74205	5	74305	B ?	74645	5	7634		78947	B ?
5	74185	"	74205	5	82420	B ⊕	84737	5	7634		89425	B ⊕
6	74185	"	74206	6	74306	P O	74646	6	7634		78961	P O
6	74185	"	74206	6	96559	P ⚡	102985	6	7634		99564	P ⚡
7	74185	"	74207	7	74307	Y 6	74647	7	7634		78969	Y 6
8	74185	"	74208	8	74308	M *	74648	8	7634		78958	M *
9	74185	"	74209	9	74309	U 7	74649	9	7634		78956	U 7
10	74185	"	74210	10	74310	L)	74650	10	7634		78957	L)
10	74185	"	74210	10	82154	L \	84738	10	7634		89421	L \
11	74185	"	74211	11	74311	H £	74651	11	7634		78953	H £
11	74185	"	74211	11	82151	H ↗	84740	11	7634		89418	H ↗
12	74185	"	74212	12	74312	O 9	74652	12	7634		78960	O 9
13	74185	"	74213	13	74313	I 8	74653	13	7634		78954	I 8
14	74185	"	74214	14	74314	N .	74654	14	7634		78959	N .
14	74185	"	74214	14	84069	N ⑩	84742	14	7634		89426	N ⑩
15	74185	"	74215	15	74315	E 3	74655	15	7634		78950	E 3
16	74185	"	74216	16	74316	T 5	74656	16	7634		78964	T 5
17	74185	"	74217	17	74317	A —	74657	17	7634		78946	A —
17	74185	"	74217	17	82147	A ↑	84743	17	7634		89414	A ↑
18	74185	"	74218	18	74318	J ' '	74658	18	7634		78955	J ' '
18	74185	"	74218	18	82152	J /	84745	18	7634		89419	J /
19	74185	"	74219	19	74319	R 4	74659	19	7634		78963	R 4
20	74185	"	74220	20	74320	D \$	74660	20	7634		78949	D \$
20	74185	"	74220	20	82148	D /	84746	20	7634		89415	D /
21	74185	"	74221	21	74321	C :	74661	21	7634		78948	C :
21	74185	"	74221	21	82423	C ○	84747	21	7634		89423	C ○
22	74185	"	74222	22	74322	F !	74662	22	7634		78951	F !
22	74185	"	74222	22	82149	F →	84749	22	7634		89416	F →
23	74185	"	74223	23	74323	W 2	74663	23	7634		78967	W 2
24	74185	"	74224	24	74324	G 8	74664	24	7634		78952	G 8
24	74185	"	74224	24	82150	G \	84750	24	7634		89417	G \
25	74185	"	74225	25	74325	V ;	74665	25	7634		78966	V ;
25	74185	"	74225	25	82421	V ①	84752	25	7634		89424	V ①
26	74185	"	74226	26	74326	Q I	74666	26	7634		78962	Q I
27	74185	"	74227	27	74327	X /	74667	27	7634		78968	X /
28	74185	"	74228	28	74328	S ▷	74668	28	7634		80551	S ▷
28	74185	"	74228	28	74328	S ▷	74668	28	7634		78980	S BELL
											80138	M STOP
											82607	H STOP
											84799	TAB Z
											86732	TAB G
											*	
											78972	FIGS.
											78973	LTRS.
											78976	CARRET /
											78978	LINE FEED
											78971	BLANK


OLD STYLE PARTS

74298 MARGIN BELL SHAFT



6746 SCREW
2191 LOCK WASHER
7002 WASHER

81956 BLOCKING PLATE



74404 OPERATING LEVER

33-38 SCREW
3599 NUT

74702 SPRING

74701 SPRING

33-38 SCREW
3599 NUT


84575 SPRING

74533 LATCH HANDLE

74411 SEND-REC. HANDLE

6745 SCREW
34432 WASHER
2669 LOCK WASHER

74805 BRACKET



NOTES OF EXPLANATION

Page 4

- (A) The 87509 spring post (threaded) has replaced the 8486 spring post (not threaded). The 74244 printing bail, which is now tapped, includes the 87509 spring post. Old style 74244 printing bails (not tapped) necessitate the use of the 8486 spring post for replacement purposes.
- (B) The original 3108 roller used on the function bail and the printing bail arm was replaced by a roller of new design consisting of one roller housing and nine rollers.

The 82986 pilot screw, which was redesigned and may be identified by the beveled end, must be used with the new style roller housing and rollers. It may also be used with the old style 3108 rollers.

The 2449 lock washer was retained for use with the new style roller housing and rollers.

An assembly number (91175) was assigned to the cam follower roller (Assem.) which consisted of one roller housing, nine rollers, and one pilot screw.

The 91175 cam follower roller (Assem.) has now been redesigned but retains the same number. This latest design of 91175 consists of one 82986 pilot screw, (which has not been changed) one roller housing, nine rollers, and two roller retaining washers.

Due to the fact that the rollers of both the later designs are tested as assemblies, it is recommended that whenever a roller housing or roller is to be replaced, the whole assembly 91175 be ordered.

Pages 6,8,9 and 12

- (A) The 74764 motor stop mechanism (operating on upper case "M"), required to convert printers from switch to remote control, consists of all the parts marked (A) on pages 6, 8, 9, and 12 and the 80138 spring cushion keytop on page 30.
- (B) The 82742 motor stop mechanism (operating on upper case "H"), required to convert printers from switch to remote control, consists of all the parts marked (B) on pages 6, 8, 9, and 12 and the 82607 spring cushion keytop on page 30.

Page 10

A paper chute with one centrally located hole for the pressure roller is available and may be ordered as 92745.

Page 12

- (A) All the parts marked (A) on pages 6, 8, 9, and 12, and the 80138 spring cushion keytop on page 30, comprise the 74764 motor stop mechanism (operating on upper case "M") required to convert printers from switch to remote control.
- (B) All the parts marked (B) on pages 6, 8, 9, and 12, and the 82607 spring cushion keytop on page 30, comprise the 82742 motor stop mechanism (operating on upper case "H" required to convert printers from switch to remote control).
- (C) The 94015 clutch lever bracket supersedes the 74189 clutch lever bracket and differs from 74189 in that a cutout has been added between the two outer mounting holes. The 94015 new style bracket now mounts by means of two screws instead of three. The original design of the 74189 old style bracket mounted by means of two screws, but was later redesigned and made wider and mounted by means of three screws. To accomodate this change a hole was added in the selector mounting plate.

The 94015 new style clutch lever bracket is interchangeable with the 74189 old style bracket of the later design, but is not interchangeable with the original 74189 bracket which mounted by means of two screws.

Page 13

- (A) The 74294 adapter plate formerly consisted of an adapter plate with two 2341 dowels. The new style 74294 adapter plate has two extruded projections instead of the dowels. The 2341 dowels, however, are available for maintenance on the old style adapter plates.
- (B) In order that the ribbon may be locked sufficiently below the printing line, when stencils are being cut, the 74365 lockout lever has been replaced by the 91657 ribbon lockout lever (assem.). The 74331 lockout spring is assembled under the new lockout lever so as to extend outward from the ribbon oscillator, instead of toward the ribbon oscillator as in the previous construction.

Page 14

- (A) The 33-41 shoulder screw and 81936 ribbon feed lever have replaced the 33-346 shoulder screw and 74382 ribbon feed lever, respectively. None of the foregoing parts are interchangeable. When either an old style lever or screw is replaced by a new style part, the other old style part must also be replaced.
- (B) The 84894 arm, 84895 detent spring and 84896 screw have replaced the 74748 arm, 74747 detent spring and 74736 screw respectively. New and old style parts are not interchangeable. When an old style part is replaced by a new style part, the other old style parts must also be replaced. The new style parts may be ordered as 83855 set of parts.

Page 15

- (A) The 74994 mounting plate has replaced the 74188 mounting plate, and the 74995 retainer has replaced the 74193 retainer in order to obtain more clearance between the lower end of the bell crank retainer and the keyboard lock loop.

The old and new style parts are not interchangeable, as the hole for the lower mounting screw in the 74995 retainer and the 74994 mounting plate is located .062" higher than in the 74193 retainer and the 74188 mounting plate. The distance between centers of the two retainer mounting screw holes in the 74193 retainer and the 74188 mounting plate is 3.011" as compared with 2.932" in the 74995 retainer and the 74994 mounting plate.

Page 23

- (A) In order to improve the keyboard touch, it is necessary that the clearance between the lockout lever and the lock loop be made adjustable. To accomplish this, the following changes have been made:

A slot has been provided in place of the hole in the 7377 lock loop, which retains the same number. The 7378 lock loop roller has been replaced by a 92511 roller, having a larger diameter in order to clear the head of the 6800 shoulder screw.

A 7002 washer, and a 2191 lock washer have been added under the 3598 nut which mounts the 6800 shoulder screw to the 7377 lock loop.

Note: The new style 92511 roller should not be used with the old style 7377 lock loop.

Page 25

- (A) The 87936 bracket and 87937 bracket (with rod) have replaced the 72592 bracket, 73640 bracket (with rod) and the 8515 filler block.

NUMERICAL INDEX

M-169	Magnet - 355 Ohms, 20	1245	Screw { 10-32 x 1}, 2,5,17	4812	Wick (3/8 Long), 4
M-177	Magnet - 105 Ohms per Coil, 12	1248	Screw { 6-40 x 1/2}, 5,9,22	4814	Lock Washer, 15,17
33-15	Screw { 2-56 x 1/8}, 20	1252	Screw { 4-40 x 1/4}, 10	4852	Lock Washer, 5
33-38	Screw { 4-40 Shoulder}, 9,18	1262	Screw { 6-32 x 5/16}, 22	4871	Bolt, 20
33-41	Screw { 6-40 Shoulder}, 5,14, 33	1266	Screw { 6-32 x 7/16}, 29	4881	Spring Backing, 23
33-43	Screw { 2-56 x 3/4}, 20	1269	Screw { 6-40 x 1/2}, 10,11,17	5061	Ball Bearing, 26
33-50	Screw { 4-40 Shoulder}, 24	1272	Screw { 6-40 x 11/16}, 26	5446	Screw { 6-40 x 9/16}, 5
33-86	Screw { 4-40 x 1/8}, 29	1275	Screw { 10-32 x 1-1/2}, 17	5599	Nut (8-32 Hex.), 17
33-111	Screw { 2-56 x 9/64}, 13	1291	Screw { 6-32 x 3/4}, 25	6314	Contact Spring (Assem.), 28
33-168	Screw { 6-40 Pilot}, 13	1293	Screw { 4-40 x 1/8}, 29	6318	Contact Spring Clamp, 28
33-170	Screw { 4-40 Shoulder}, 13	1294	Screw { 4-36 x 1/2}, 25	6319	Block, 28
33-179	Screw { 8-32 x 3/8}, 17	1297	Screw { 6-40 x 2-7/16}, 18, 21,22	6320	Screw (6-32 Contact), 28
33-227	Screw { 4-40 Shoulder}, 10, 24	2034	Washer, 12	6323	Spring, 28
33-270	Screw { 2-56 x 3/16}, 25	2191	Lock Washer, 1 to 6, 9 to 29, 33	6324	Adjusting Wheel, 28
33-344	Screw { 10-32 x 3/4}, 2	2199	Nut { 7/16-32 Hex.}, 23	6344	Screw { 6-32 x 11/32}, 28
33-346	Screw { 6-40 Shoulder}, 33	2201	Nut { 5/16-32 Hex.}, 15	6345	Nut (6-32 Hex.), 28
34-1	Nut (1/4-32 Hex.), 5,12, 13,14	2247	Washer, 29	6346	Screw { 6-32 x 3/4}, 28
34-4	Nut (10-32 Hex.), 1,2,4,5, 6,9,10,12,13,14,16,17,18, 26,27,28	2248	Pin, 10	6347	Screw { 6-32 x 3/8}, 28
34-10	Nut { 8-40 Hex.}, 14	2291	Contact Spring-Lower, 17	6348	Screw (4-36 x 3/4), 28
34-11	Nut { 2-56 Hex.}, 12,25	2322	Lock Washer, 1,5,13,14	6685	Sword, 12
34-48	Nut { 6-32 Hex.}, 22	2341	Dowel, 32	6689	Separator Plate, 12
34-51	Nut { 6-40 Hex.}, 5	2378	Spacer Key Lever, 22	6706	Magnet Bracket, 12
34-56	Nut { 4-40 Hex.}, 4,10,12, 23,24,29	2382	Lock Washer, 1	6745	Screw (10-32 x 1/2), 1,2, 4,13,14,15,17,18,26,27
34-59	Nut { 10-30 Hex.}, 26	2407	Lock Washer, 23	6746	Screw { 6-40 x 5/16}, 1,2, 4,5,6,10 to 15,17,19,20, 22,23,26 to 28.
34-66	Nut { 4-36 Hex.}, 25	2438	Washer, 12,20	6760	Shim, 6
35-70	Spring, 18	2449	Lock Washer, 1,4,5,14,16, 17,20,26,27,32	6799	Screw { 6-40 x 27/32}, 12
35-89	Spring, 22	2451	Ball, 13,14	6800	Screw { 6-40 Shoulder}, 1,2,4,10,14,16,23,33
36-150	Dowel, 1,2,4,6	2502	Mounting Strip, 23	6801	Screw { 4-40 Pilot}, 12
43-10	Plunger Stop, 20	2503	Plate, 23	6805	Screw { 6-40 Shoulder}, 14,23
61-24	Insulator, 29	2504	Insulator Strip, 23	6810	Screw (10-32 x 3/8), 1,2, 5,9,17,18,21
103-27	Washer, 10,13,14,18,25	2525	Key Lever Guide - Front, 22	6811	Screw { 6-40 x 5/8}, 1 to 4, 10,12,17,21,23,26 to 28
122-26	Washer, 12	2526	Spacing Collar, 23	6814	Screw { 6-40 Pilot}, 12,23
122-29	Dowel, 1,2	2528	Spring Plate, 22	6827	Connecting Block, 18
122-67	Post, 10	2529	Bushing, 23	6830	Trip Latch, 12
123-244	Washer, 1,10,17	2539	Nut { 3/8-32 Hex.}, 1,2	6836	Magnet Yoke, 12
126-123	Outlet Bushing, 26	2565	Key Lever Spring, 22	6850	Bell Crank, 12
200-1348	Washer 18	2574	Upstop, 22	6859	Spacer Collar, 15 —
1010	Screw { 6-40 Shoulder}, 14	2623	Spring, 23	6861	Washer - Felt, 3
1020	Screw { 6-40 x 1/4}, 3	2663	Buffer - Rubber, 22	6863	Cam Sleeve Disc, 3
1026	Screw { 6-40 x 3/8}, 5,6, 10,14,17,20	2666	Nut { 3/16-40 Hex.}, 14	6884	Bracket, 12
1028	Screw { 4-40 x 1/4}, 12, 17,20	2719	Lock Washer, 1 to 6, 9,10, 13 to 18,20,21,26 to 28	6909	Stop Lever, 12
1030	Screw (6-40 Shoulder), 12, 16,24	2846	Washer, 9	6940	Spring Post, 4,5,6,14
1035	Screw { 4-40 x 3/8}, 9	2924	Washer, 17,26,27	6942	Screw (4-40 Eccentric), 12,23
1038	Screw { 6-40 x 9/32}, 22	3094	Contact Spring - Upper, 17	6950	Eccentric Stop, 12
1051	Screw { 4-40 x 1/2}, 18	3106	Insulator, 20	6970	Nut { 3/8-32 Hex.}, 10
1064	Screw { 6-32 x 1/4}, 28	3108	Turnbuckle, 1	6971	Clutch Throw-out Lever, 12
1072	Screw { 6-40 Thumb}, 24	3110	Roller, 32	6979	Hub, 28
1073	Screw { 6-40 Thumb}, 12	3131	Nut { 10-32 L.H. -Hex.}, 1	6987	Spacer, 15
1097	Screw { 4-40 x 15/32}, 9	3288	Link End - Short, 1	6990	Screw { 1/4-32 Pilot}, 12
1100	Screw { 1/4-32 Pilot}, 26	3298	Washer, 15	6993	Clutch Spring, 3
1159	Screw { 4-40 x 3/8}, 16	3329	Eccentric Stop, 4,12	6998	Post, 12
1160	Screw { 6-40 x 5/16}, 4,6, 12,15,16,17	3340	Nut { 9/16-32 Hex.}, 9	7001	Washer, 12,15
1161	Screw { 6-40 x 1/4}, 1,9, 10,13,15	3598	Lock Washer, 9	7002	Washer, 2,4,5,6,9 to 17, 20 to 24,26 to 29,33
1162	Screw { 4-40 x 1/4}, 10, 12,13,14	3599	Washer, 1,4,5, 9 to 14, 16,17,18,21 to 24, 29,33	7007	Trip Plunger, 12
1163	Screw { 4-40 x 3/16}, 11	3603	Nut { 4-40 Hex.}, 9,10,13,14, 16,18,22	7022	Reverse Lever - Left, 14
1166	Screw { 4-36 x 1/4}, 17	3606	Nut { 1/4-32 Hex.}, 1,4	7023	Reverse Lever - Right, 14
1168	Screw { 4-40 x 5/16}, 2,	3617	Nut { 6-40 Hex.}, 14,15,22	7024	Reverse Pawl - Left, 14
1169	13,14,18,28	3618	Washer, 20	7025	Reverse Pawl - Right, 14
1174	Screw { 6-40 x 7/16}, 22	3621	Insulator, 9,20	7032	Pawl, 23
1176	Screw { 4-40 Shoulder}, 14	3640	Terminal, 22	7036	Collar, 10,11
1176	Screw { 6-40 x 3/16}, 10, 11,18,21	3646	Lock Washer, 2,4,9,10,12,13, 14,16,18,20,22,23,25,28,29	7044	Link, 14
1179	Screw { 6-40 x 5/8}, 27	3647	Lock Washer, 9,18,22	7049	Roller, 6
1193	Screw { 10-32 x 7/8}, 17	3649	Insulator, 9,20	7050	Sleeve, 6
1196	Screw { 6-40 Shoulder}, 1,5, 10,13	3650	Washer, 5	7081	Post, 23
1206	Screw { 4-40 x 9/16}, 29	3897	Washer, 17,20	7093	Terminal Block, 21
1208	Screw { 10-32 x 5/8}, 4,5, 21	3899	Bushing, 21	7094	Connection Spring, 17,21
1222	Screw { 2-56 x 1/2}, 9	4293	Collar, 20	7095	Spring Plate, 17,21
1224	Screw { 6-40 Special}, 17	4323	Insulator, 17,21	7096	Bushing, 17,21
1226	Screw { 6-40 x 3/4}, 4,17	4703	Ball, 3	7105	Target { 10 Spot}, 26
		4708	Spring, 14	7318	Contact Lever, 23
		4810	Spring, 7,8	7334	Post, 22
			Wick, 23	7372	Bearing Bracket, 23
				7373	Bearing Bushing, 23
				7377	Lock Loop, 23,33
				7378	Lock Loop Roller, 33

NUMERICAL INDEX

7381	Contact Mounting (Assem.), 23	70707	Bracket, 20	73640	Bracket, 33
7382	Front Bracket, 23	70724	Insulation Strip, 20	73641	Message Line Guide, 25
7383	Oiler, 23	70771	Oiler, 26	73670	Terminal Block (Assem.), 17, 20
7385	Rear Bracket (with Posts), 23	70793	Washer, 15		Terminal Block, 17, 20
7386	Post, 23	70803	Spool Cup, 15	73705	Keyboard Shaft, 23
7387	Brace, 23	70834	Screw (6-40 Pivot), 12	74001	Selector Mounting Plate (with Posts), 12
7389	Driving Clutch, 23	70872	Copy Holder - 6" - Black Gloss, 25	74003	Shaft, 6
7391	Driven Clutch, 23	70872	Brush Holder (with Insulator), 26	74005	Bushing, 13
7396	Bracket - Left, 22	70873	Brush Holder Cap, 26	74006	Roller, 13
7397	Bracket - Right, 22	70886	Washer, 5, 16	74008	Pawl Latch, 12
7398	Spring Plate, 17, 21	70887	Nut (3/16-24 Hex.), 20	74009	Roller, 13
7399	Spring Stiffener, 17, 21	70892	Nut (1/8-27 Hex.), 19	74010	Screw (6-40 Shoulder), 1, 10
7400	Clutch Lever, 23	70893	Nipple, 19	74011	Printing Bail Blade, 4
7602	Spring, 12	71045	Nut (6-40 Hex. - Stop), 12	74013	Screw (10-32 x 3/4), 6, 17, 18, 21, 29
7603	Spring, 12	71046	Screw (6-40 Special), 12	74014	Spring, 4
7607	Collar, 12	71073	Washer, 12	74015	Post, 1, 2
7612	Spring, 12	71161	Bushing, 23	74016	Screw (6-40 Shoulder), 4, 5
7614	Spring, 12	71189	Copper Bearing Retainer, 26	74017	Piston Rod, 1
7615	Spring, 12	71443	Terminal, 22	74020	Spring Plate, 6
7634	Spring, 13, 14, 30	71445	Link, 12		Screw (6-40 Eccentric Shoulder), 10
7654	Shim, 23	71659	Screw (6-40 Shoulder), 2	74018	Bell Crank #1, 15
7661	Adjusting Lever, 26	71670	Mounting Block, 17	74019	Bell Crank #2, 15
7678	Screw (4-40 Pilot), 10	71671	Jack Spring - Left, 17	74020	Bell Crank #3, 15
7679	Roller, 10	71672	Cable Clamp, 17		Bell Crank #4, 15
7835	Ribbon - Black, 15	71675	Jack Spring - Right, 17	74021	Bell Crank #5, 15
7959	Magnet Bracket, 20	71681	Ribbon Spool, 15	74022	Collar, 4, 5
7965	Spring, 16	71696	Range Scale (with Bell Crank Mounting), 12	74023	Screw (1/4-32 Special), 1
8094	Brush (with Spring), 26	71999	Clamping Plate, 12	74024	Dashpot Cylinder, 1
8097	Cam Sleeve, 23	72021	Stop Lever Plate, 12	74025	Piston Head, 1
8157	Selector Lever - Right, 12	71697	Brush Holder Ring (with 80706 Screw), 26	74026	Platen Bracket - Right, 10
8158	Selector Lever - Left, 12	71976	End Play Spring, 26	74028	Washer, 1
8165	Washer, 28	71998	Resistance Mounting Block (Assem.), 17	74031	Washer - Leather, 1
8184	Washer, 10		Shim, 22	74032	Nut (10-32 Hex.), 13, 14
8222	Wearing Strip, 26		Bearing - Upper, 28	74033	Motor Stop Lever, 12
8254	Cable Clamp, 21		Bearing - Lower, 28	74036	Function Lever, 8
8330	Washer, 13, 14, 26		Plug (Polarized), 19	74037	Function Lever #10, 8
8470	Post, 12	72472	Control Relay (Assem.) with Mounting Screws, 20	74038	Type Basket, 14
8472	Locking Wedge, 12	72474	Shaft, 22	74040	Selector Vane #1, 6
8486	Spring Post, 32	72475	Screw (6-40 x 3/4), 17	74041	Selector Vane #2, 6
8507	Cam Sleeve, 3	72481	Lock Washer, 5, 10	74042	Selector Vane #3, 6
8508	Armature, 12	72484	Driving Disc, 3	74043	Selector Vane #4, 6
8511	Locking Lever, 12		Spring, 3	74044	Selector Vane #5, 6
8513	Message Line Guide (Assem.), 25	72501	Nut (5/16-32 Hex.), 3	74045	Selector Vane #6, 6
8514	Stop Plate, 25	72508	Retaining Disc, 3	74046	Screw (4-40 Shoulder), 12
8515	Filler Block, 33	72509	Wick - Felt, 3	74049	Margin Bell Cam, 2
8539	Screw (6-40 x 1/2), 3, 4, 10, 12 to 15, 17, 20 to 23	72513	Post, 22	74050	Lever, 2
8543	Screw (6-40 x 1/4), 10	72514	Clutch - Driving, 3	74051	Keyboard Track, 21
8671	Screw (6-40 Shoulder), 12	72515	Washer - Felt, 3	74052	Slip Connection Mounting Plate (Assem.), 21
8686	Wooden Filler Block, 25	72521	Resistance Unit (100-100 Ohms), 21	74053	Plate (Assem.), 21
8783	Locking Lever, 22	72545	Motor - 1/17 H.P. - 110 V. - D.C., 26	74055	Roller, 1
8884	Terminal Block, 4, 26, 27	72562	Armature, 26	74056	Retaining Plate, 1, 2
8896	Shim, 4, 15, 23	72563	Bracket, 33	74058	Detent Lever, 1
8990	Retainer, 24	72566	Stud, 22	74059	Screw (6-40 x 7/32), 6, 10, 17, 18, 29
9177	Contact Stop, 23	72586	Ball Bearing, 3	74061	Clutch, 3
9178	Contact Spring, 23		Contact Point, 28	74062	Track - Lower, 13
9182	Contact Lever Shaft, 23	72587	Lock Washer, 1, 2, 19	74066	Shift Link Bracket, 4
9203	Bracket (with Rollers), 22	72592	Resistor, 21	74068	Latch Bar, 5
9209	Key Lever - Center, 22	72643	Resistor, 21	74069	Reset Bar, 5
9210	Key Lever - Upper, 22	72644	Steel Bearing Retainer, 26	74071	Clutch Fork, 5
9695	Plunger, 20	72835	Washer - Felt, 26	74072	Operating Lever, 5
34432	Washer, 1, 2, 4, 5, 9, 12 to 15, 18, 21	73175	Field Frame (with Oiler), 26	74076	Screw (1/4-32 Shoulder), 1
35503	Foot - Rubber, 17	73196	End Shield (with Oiler), 26	74077	Screw (10-32 Shoulder), 1, 4
35826	Washer, 1	73197	Field Core, 26	74078	Latch Link, 5
35858	Margin Bell, 2		Field Coil, 26	74079	Line Feed Sail, 1
36273	Washer, 14, 22	73231	Insulation (for One Field Coil), 26	74080	Shift Link, 4
41341	Crank Handle, 9	73232	Locking Wedge, 26	74081	Line Feed Push Bar, 1
41342	Screw (8-40 x 1-1/4), 9	73236	Screw (10/32 x 7/8), 26	74082	Shift Lever, 1
41543	Ball Bearing, 5	73237	Screw (6-40 Shoulder), 5	74083	Vertical Link, 1
41675	Washer, 10, 14, 15	73240	Terminal End (Assem.), 20	74085	Washer - Felt, 3
41732	Clamp Plate, 18, 28	73241	Plug - Red, 19	74089	Printing Bail Arm, 4
41733	Insulator, 18, 28	73242	Contact Spring, 9, 20	74091	Plate, 17, 26, 27
41830	Contact Spring, 18		Spring Plate, 20	74095	Spacing Collar, 4
43954	Bell, 5	73243	Contact Spring, 9, 20	74096	Space Pawl - Front, 4
45104	Spring, 10	73244	Clamping Rod, 26	74097	Space Pawl - Rear, 4, 16
46092	Nut (10-32 Hex.), 1	73276		74098	Shaft, 4
55063	Spring, 10	73357		74100	Washer - Leather, 3
55083	Spring, 4, 5	73497			
70177	Screw (4-40 Pilot), 22	73588			
70324	Bearing, 22	73592			
70529	Stiffener, 18	73593			
70593	Screw (6-40 Thumb), 2	73595			

NUMERICAL INDEX

74101	Oil Plug, 3	74208	Type Bar (without Pallets) #8, 30	74311	Type Bar Pallet (H \$), 30
74107	Bearing, 4	74209	Type Bar (without Pallets) #9, 30	74312	Type Bar Pallet (O \$), 30
74109	Function Lever #5, 8	74210	Type Bar (without Pallets) #10, 30	74313	Type Bar Pallet (I \$), 30
74110	Post, 5	74211	Type Bar (without Pallets) #11, 30	74314	Type Bar Pallet (N \$), 30
74111	Shaft, 1	74212	Type Bar (without Pallets) #12, 30	74315	Type Bar Pallet (E \$), 30
74112	Screw (10-32 Pilot), 4	74213	Type Bar (without Pallets) #13, 30	74316	Type Bar Pallet (T \$), 30
74119	Bail Shaft Bearing, 1	74214	Type Bar (without Pallets) #14, 30	74317	Type Bar Pallet (A \$), 30
74121	Latch Bell Crank, 5	74215	Type Bar (without Pallets) #15, 30	74318	Type Bar Pallet (J \$), 30
74122	Screw (6-40 x 3/4), 4	74216	Type Bar (without Pallets) #16, 30	74319	Type Bar Pallet (R \$), 30
74124	Spacing Cross Bar (Assem.), 5	74217	Type Bar (without Pallets) #17, 30	74320	Type Bar Pallet (D \$), 30
74126	Support, 13	74218	Type Bar (without Pallets) #18, 30	74321	Type Bar Pallet (C \$), 30
74127	Function Lever #12, 8	74219	Type Bar (without Pallets) #19, 30	74322	Type Bar Pallet (F \$), 30
74128	Function Lever #3, 8	74220	Type Bar (without Pallets) #20, 30	74323	Type Bar Pallet (W \$), 30
74129	Function Lever #11, 8	74221	Type Bar (without Pallets) #21, 30	74324	Type Bar Pallet (G & \$), 30
74130	Function Lever #9, 8	74222	Type Bar (without Pallets) #22, 30	74325	Type Bar Pallet (V \$), 30
74131	Function Lever #2, 8	74223	Type Bar (without Pallets) #23, 30	74326	Type Bar Pallet (Q \$), 30
74132	Spacing Gear, 3	74224	Type Bar (without Pallets) #24, 30	74327	Type Bar Pallet (X \$), 30
74133	"T" Lever #1, 12	74225	Type Bar (without Pallets) #25, 30	74328	Type Bar Pallet (S \$), 30
74134	"T" Lever #2, 12	74226	Type Bar (without Pallets) #26, 30	74329	Reverse Shaft, 15
74135	"T" Lever #3, 12	74227	Type Bar (without Pallets) #27, 30	74330	Spring, 13
74136	"T" Lever #4, 12	74228	Type Bar (without Pallets) #28, 30	74331	Lockout Spring, 13, 32
74137	"T" Lever #5, 12	74230	Driving Clutch, 5	74332	Roller - Flanged, 14
74138	Function Lever #4, 8	74239	Clutch Bushing, 3	74334	Washer, 13
74140	Printing and Function Cam, 3	74240	Roller, 14	74335	Shift Lever, 13
74142	Cylinder Head, 1	74241	Driven Clutch, 5	74337	Roller - Upper, 14
74143	Ball Bearing Retainer, 5	74243	Basket Guide Roller (Assem.), 14	74338	Release Crank, 10
74144	Spacing Pawl Arm, 4	74244	Printing Bail, 4, 32	74339	Platen Cross Bar, 10
74148	Bell Hammer, 4	74246	Motor Stop Pawl - Inner, 12	74342	Eccentric Stud, 14
74150	Bell Operating Lever, 4	74247	Shift Stop Post, 10	74343	Stud, 14
74151	Gear (35T) - 368 O.P.M., 26	74248	Roller Stud, 10	74344	Reverse Arm - Right, 15
74152	Spring, 3	74249	Screw (1/4-32 Pilot), 1	74345	Reverse Arm - Left, 15
74153	Bearing, 3	74251	Dashpot Lever, 1	74358	Bracket, 13
74154	Lower Spacing Gear, 5	74252	Screw (3/8-32 Pilot), 1, 2	74361	Draw Strap, 5
74156	Screw (10-32 x 9/16), 4	74253	Stud, 14	74362	Screw (6-40 Shoulder), 10
74158	Function Bail Blade, 4	74254	Rear Cross Bar, 4	74363	Bail, 13, 14
74160	Carriage Return Lock Bar, 5	74255	Function Lever Comb, 6	74365	Lockout Lever, 32
74161	Lock Bar Latch, 1	74259	Detent, 10	74366	Spacing Rack, 14
74162	Adjusting Link, 5	74264	Platen Shaft, 9	74367	Screw (10-32 x 1-7/16), 14, 25
74163	Shift Push Bar, 4	74269	Washer, 5	74368	Operating Bail Roller (Assem.), 14
74164	Spacing Shaft, 5	74271	Washer, 5	74371	Ribbon Carrier, 13
74166	Driving Disc, 3	74272	Spring, 5	74372	Link, 14
74169	Pivot Clamp, 6	74275	Shaft, 5	74373	Segment, 13
74170	Screw (10-32 Pivot), 6	74276	Ball Bearing, 5	74374	Pull Bar Bail Plunger, 14
74171	Screw (10-40 Eccentric), 1	74278	Escapement Lever, 5	74376	Bracket, 14
74172	Screw (10-32 Eccentric Shoulder), 1	74279	Leather Strip, 13	74378	Margin Bell Pawl, 13
74173	Bell Latch Bar, 4	74281	Type Bar Backstop (Assem.), 13	74379	Bracket, 13
74174	Bell Push Bar, 4	74283	Washer - Spring, 1, 2, 9	74380	Shaft (with Detent and Gears), 14
74175	Bracket, 12	74286	Bail Guide, 15	74381	Feed Pawl, 14
74178	Bracket, 2	74289	Back Stop, 12	74382	Ribbon Feed Lever, 33
74179	Vertical Feed Shaft, 15	74291	Spring Bracket, 12	74383	Bearing - Right, 14
74180	Code Bar "1D", 30	74292	Screw (10-32 Shoulder), 14	74384	Spool Gear, 15
74181	Code Bar "2D", 30	74294	Adapter Plate, 13, 32	74385	Spur Gear, 15
74182	Code Bar "3D", 30	74296	Screw (6-40 Pilot), 13	74390	Reverse Bail, 14
74183	Code Bar "4D", 30	74297	Latch Plate, 5	74392	Spool Bracket, 15
74184	Code Bar "5D", 30	74298	Type Bar Backstop (Assem.), 13	74394	Spool Shaft, 15
74185	Standard Pull and Function Bar, 30	74300	Washer - Spring, 1, 2, 9	74395	Relay Guard, 18
74186	Disc, 10	74302	Bail Guide, 15	74397	Draw Strap Post, 13
74187	Pull Bar Guide, 14, 15	74303	Back Stop, 12	74398	Ratchet Shaft, 14
74188	Mounting Plate, 33	74304	Spring Bracket, 12	74399	Screw (6-40 Pilot), 12
74189	Clutch Lever Bracket, 32	74305	Screw (10-32 Shoulder), 14	74401	Ribbon Oscillator, 13
74190	Spacing Clutch, 5	74306	Adapter Plate, 13, 32	74407	Sending - Receiving Reset Lever, 9
74191	Latch, 6	74296	Screw (6-40 Pilot), 13	74408	Post, 9
74192	Upper Spacing Gear, 5	74297	Latch Plate, 5	74409	Contact Lever, 6
74193	Retainer, 33	74300	Type Bar Pallet (Assem.), 5	74410	Frame - Left, 1
74194	Stud, 13	74302	Type Bar Pallet (.), 30	74412	Bushing, 5
74195	Roller, 13	74303	Type Bar Pallet (Z), 30	74413	Back Stop, 4
74196	Stud, 14	74304	Type Bar Pallet (K C), 30	74414	Type Bar Guide, 13
74197	Roller, 14	74305	Type Bar Pallet (B ?), 30	74416	Sending - Receiving Intermediate Lever, 9
74198	Ball Race, 14	74306	Type Bar Pallet (P O), 30	74417	Send - Receiving "T" Lever, 9
74199	Eccentric Bushing, 15	74297	Spring Drum (Assem.), 5	74420	Bracket, 17
74200	Track - Upper, 13	74300	Type Bar Pallet (.), 30	74421	Bracket, 19
74202	Type Bar (without Pallets) #2, 30	74302	Type Bar Pallet (Z), 30	74422	Bracket, 17, 18
74203	Type Bar (without Pallets) #3, 30	74303	Type Bar Pallet (K C), 30	74425	Receptacle, 17
74204	Type Bar (without Pallets) #4, 30	74304	Type Bar Pallet (B ?), 30	74430	Strap, 20
74205	Type Bar (without Pallets) #5, 30	74305	Type Bar Pallet (P O), 30	74432	Mounting Strip, 21
74206	Type Bar (without Pallets) #6, 30	74306	Type Bar Pallet (Y 6), 30	74433	Cover, 21
74207	Type Bar (without Pallets) #7, 30	74308	Type Bar Pallet (M), 30	74435	Platen Bracket - Left, 10
		74309	Type Bar Pallet (U 7), 30		
		74310	Type Bar Pallet (L), 30		

NUMERICAL INDEX

74437	Slide Bar, 10	74583	Selector Bar #3, 22	74687	Screw (6-40 x 5/8), 14
74438	Platen - Rubber, 9	74584	Selector Bar #4, 22	74688	Unshift on Space Cut-out
74446	Line Feed Ratchet (33T), 9	74585	Selector Bar #5 - Front, 22		Lever - Short, 9
74447	Detent Ratchet (33T), 9	74587	Pad - Felt, 17	74689	Guide Post, 15
74448	Bushing, 10	74588	Terminal Block (Assem.), 17	74690	Transmitter (Assem.), 23
74449	Bushing, 10	74589	Terminal Block (Assem.), 22	74691	Resistance (800-800 Ohms), 22
74451	Release Lever Shaft, 10	74590	Plate, 22		Spring Post, 1, 4, 16
74452	Release Shaft, 10	74592	Retaining Rod, 17	74692	Post, 10
74454	Release Cam, 10	74594	Retaining Ring, 22	74693	Friction Arm, 9
74455	Paper Chute, 10	74595	Gear - 24T, 23	74694	Friction Sleeve, 9
74457	Guide Lever, 10	74596	Driving Gear - 21T, 3	74695	Spring, 13
74460	Shaft, 10	74599	Eccentric, 12	74700	Spring, 16
74463	Adjusting Lever, 10	74601	Universal Bar, 22	74701	Spring, 12
74465	Line Feed Lever, 10	74604	Repeat Space Rod, 22	74703	Spring, 1
74467	Line Feed Pawl, 10	74605	Bracket, 22	74704	Spring, 6, 7, 16
74469	Paper Finger - Right, 10	74609	Spacer Bar Shaft, 22	74705	Spring, 10
74470	Paper Finger - Left, 10	74610	Key Lever Shaft, 22	74706	Spring, 1, 16
74473	Straightener Rod Stop, 10	74613	Screw (4-40 x 1/4), 10	74707	Spring, 10
74476	Straightener Rod, 10	74614	Resistance (2600 Ohms), 18, 29	74708	Spring, 10
74478	Single - Double Line Feed Lever, 10	74618	Base Plate, 17	74709	Spring, 10
74479	Bushing, 10	74620	Control Switch, 17	74710	Spring, 1
74480	Retaining Spring, 10	74621	Cover Locating Stud (Assem.), 17	74712	Relay Base, 33
74481	Detent Roller, 10	74625	Cable, 12	74720	Screw (1/4-20 Thumb), 17
74490	Roller - Rubber - Front, 10	74627	Connection Strip (Assem.), 21	74721	Spring, 14
74491	Roller - Rubber - Rear, 10	74628	Fuse Block, 17	74722	Washer, 12, 15
74493	Spacer - Short, 10	74642	Type Bar (with Pallets) #2, 30	74724	Screw (10-32 Thumb), 12
74494	Spacer - Long, 10		Type Bar (with Pallets) #3, 30	74725	Screw (6-40 Shoulder), 4
74499	Bearing Cap - Right, 14	74643	Type Bar (with Pallets) #4, 30	74726	Extension, 13
74500	Bearing - Left, 14		Type Bar (with Pallets) #5, 30	74727	Terminal, 18
74501	Bearing Cap - Left, 14	74644	Type Bar (with Pallets) #6, 30	74729	Screw (6-40 Shoulder), 13
74502	Clutch - Driven, 3		Type Bar (with Pallets) #7, 30	74730	Nut (6-40 Hex.), 13
74503	Function Bail (with Spring Post), 4	74645	Type Bar (with Pallets) #8, 30	74731	Stud, 10
74504	Base, 17	74646	Type Bar (with Pallets) #9, 30	74732	Shoulder Stud, 5, 10
74505	Pinion (7T) - 368 O.P.M., 26		Type Bar (with Pallets) #10, 30	74733	Stop Lever Bracket, 5
74508	Spring Drum, 5	74647	Type Bar (with Pallets) #11, 30	74736	Spading Stop Lever, 5
74511	Friction Spring, 14		Type Bar (with Pallets) #12, 30	74737	Screw (10-32 Shoulder), 33
74512	Basket Support Roller (Assem.), 13	74648	Type Bar (with Pallets) #13, 30	74738	Screw (6-40 Special), 14
74513	Fulcrum Rod, 13	74649	Type Bar (with Pallets) #14, 30	74739	Guard, 18
74514	Screw (4-40 x 55/64), 18		Type Bar (with Pallets) #15, 30	74744	Detent Spring, 33
74517	Screw (6-40 x 1/2), 9	74650	Type Bar (with Pallets) #16, 30	74747	Arm, 33
74519	Paper Finger Shaft, 10		Type Bar (with Pallets) #17, 30	74748	Stop Plate, 22
74520	Screw (6-40 Eccentric), 9	74651	Type Bar (with Pallets) #18, 30	74750	Trip-off Pawl, 22
74521	Bevel Gear, 15		Type Bar (with Pallets) #19, 30	74751	Detent Spring, 14
74523	Spacer Bar, 22	74652	Type Bar (with Pallets) #20, 30	74754	Wick - Felt, 3
74525	Screw (1/4-32 Thumb), 22		Type Bar (with Pallets) #21, 30	74755	Guard, 21
74526	Collar, 15	74653	Type Bar (with Pallets) #22, 30	74756	Strip - Felt, 24
74528	Spacer Bar Loop, 22		Type Bar (with Pallets) #23, 30	74757	Spring, 4
74529	Bracket, 22	74654	Type Bar (with Pallets) #24, 30	74759	Key Lever - Lower, 22
74530	Separator, 17		Type Bar (with Pallets) #25, 30	74760	Motor Stop Mechanism (Upper Case M), 32
74531	Switch Cover, 17	74655	Type Bar (with Pallets) #26, 30	74776	Insulator, 17
74532	Base, 22		Type Bar (with Pallets) #27, 30	74779	Rivet, 6
74534	Bearing Bracket (with Spring Post and Oiler), 5	74656	Type Bar (with Pallets) #17, 30	74783	Sixth Vane Detent Lever (Assem.), 6
74536	Screw (6-40 x 5/32), 9, 10, 15	74657	Type Bar (with Pallets) #18, 30	74789	Cable, 9
74538	Bracket, 9		Type Bar (with Pallets) #19, 30	74798	Screw (6-40 x 31/64), 5
74539	Plate, 9	74658	Type Bar (with Pallets) #20, 30	74799	Retaining Plate, 5
74545	Release Lever, 12		Type Bar (with Pallets) #21, 30	74800	Washer - Felt, 3
74546	Cable Clamp, 21	74659	Type Bar (with Pallets) #22, 30	74801	Friction Disc Sleeve, 3
74548	Spring, 5		Type Bar (with Pallets) #23, 30	74802	Spring, 3
74551	Cover, 17	74660	Type Bar (with Pallets) #24, 30	74804	Post, 14
74552	Vane Frame (with Post), 6		Type Bar (with Pallets) #25, 30	74805	Screw (10-32 x 3/4), 3, 14, 15
74554	Spring Post, 1, 10, 12	74661	Type Bar (with Pallets) #26, 30	74806	Guide Post Mounting Strip, 14
74556	Motor Stop Pawl - Outer, 12		Type Bar (with Pallets) #27, 30	74807	Nut (10-32 Hex.), 14
74557	Lamp, 19	74662	Type Bar (with Pallets) #28, 30	74808	Bushing, 22
74558	Socket, 19		Type Bar (with Pallets) #29, 30	74820	Platen - Hard Rubber, 9
74559	Shaft, 10	74663	Type Bar (with Pallets) #30, 30	74821	Resistance (2810 Ohms), 18
74561	Line Feed Check Post, 10		Type Bar (with Pallets) #31, 30	74826	Covering Strip - Black Gloss, 24
74562	Screw (6-40 x 3/4), 10	74664	Type Bar (with Pallets) #32, 30	74833	Copyholder - 6" - (Assem.), Black Gloss, 25
74563	Line Feed Check Lever, 10		Type Bar (with Pallets) #33, 30	74838	Bearing Cap, 1
74564	Detent Lever, 10	74665	Type Bar (with Pallets) #34, 30	74839	Motor Unit (Assem.) (77953 Motor), 26
74566	Screw (10-32 Shoulder), 10		Type Bar (with Pallets) #35, 30	74840	Motor Unit (Assem.), (72586 Motor), 26
74567	Screw (1/4-20 x 9/16), 17, 26, 27	74666	Type Bar (with Pallets) #36, 30	74841	Terminal Strap, 12
74568	Terminal Block, 17	74667	Type Bar (with Pallets) #37, 30	74852	Cord - 20" Long, 19
74569	Terminal Block, 22		Type Bar (with Pallets) #38, 30	74853	Power Cord (Assem.), 19
74572	Cable, 22	74668	Type Bar (with Pallets) #39, 30	74855	Cross Bar, 11
74573	Power Cable (in Base), 17		Strap, 18	74875	Ribbon Carrier, 11
74574	Line Cable (in Base), 17	74670	Screw (10-32 x 1-1/8), 18		
74575	Relay Cable (WD-1221, 1277), 18	74682	Contact Spring, 21		
74581	Selector Bar #1 - Rear, 22	74685	Contact Spring, 21		
74582	Selector Bar #2, 22	74686	Shift Vane, 4		

NUMERICAL INDEX

74876	Paper Roll Spindle (8 to 8-1/2") (Includes 74877 Spring), 21	78403 78437	Contact Brush, 28 Insulator, 28	80307 80308	Outlet, 27 Bushing - Fibre, 27
74878	Spindle Drag Spring, 2	78438	Bushing, 28	80309	Washer - Felt, 27
74879	Spring Post, 2,10	78443	Outer Contact Disc, 28	80310	Washer - Felt, 27
74882	Spring, 5	78451	Cover, 28	80311	Cup Washer, 27
74885	Send - Receive Lever, 18	78496	Outer Disc Contact Spring, 28	80312	Washer, 26,27
74889	Block, 13	78497	Inner Disc Contact Spring, 28	80313	Washer, 27
74890	Motor Stop Contact (Assem.), 9	78596	Washer, 12	80334	Contact Terminal, 28
74891	Shim, 23	78597	Screw (10-32 Shoulder), 12	80335	Clamping Plate, 28
74892	Shim, 22,23	78824	Spring, 12	80336	Insulator, 28
74894	Name Plate, 25	78826	Mounting Block, 12	80337	Bracket, 28
74898	Stud, 17	78858	Washer, 29	80338	Governor Adjusting
74899	Ball Bearing, 3	78905	Washer - Fibre, 29		Bracket, 28
74900	Washer, 3	78946	Spring Cushion Keytop (A -), 30	80340	Brush Spring Plate, 28
74901	Nut (15/32-32 Hex.), 3		Spring Cushion Keytop (B ?), 30	80341	Governor Brush and
74904	Shaft, 3	78947	Spring Cushion Keytop (C :), 30		Speed Adjusting Bracket
74909	Frame - Right, 2	78948	Spring Cushion Keytop (D \$), 30	80342	(Assem.), 28
74912	Pinion (7T) - 368 O.P.M., 27	78949	Spring Cushion Keytop (E 3), 30	80351	Screw (6-40 x 23/64), 15,
74913	Gear (30T) - 368 O.P.M., 27	78950	Spring Cushion Keytop (F !), 30	80352	17,28
74916	Gear Hub, 3	78951	Spring Cushion Keytop (G &), 30	80358	Screw (8-36 x 5/16), 27
74917	Retainer, 24	78952	Spring Cushion Keytop (H #), 30	80374	Center Contact Governor
74928	Post, 10	78953	Spring Cushion Keytop (I 8), 30	80392	(Assem.), 28
74932	Function Lever #7, 8	78954	Spring Cushion Keytop (J '), 30	80395	Ball Bearing, 27
74933	Pull Bar Stripper, 15	78955	Spring Cushion Keytop (K), 30	80396	Set of Gears, 26
74946	Insulator, 4	78956	Spring Cushion Keytop (L), 30	80397	Spacer Key Lever Spring,
74949	Lower Contact Lever, 18	78957	Spring Cushion Keytop (M .), 30	80398	22
74952	Screw (4-40 x 5/8), 18	78958	Spring Cushion Keytop (N ,), 30	80399	Paper Guide Strip, 11
74961	Spring, 6,7	78959	Spring Cushion Keytop (O 9), 30	80400	Side Bracket, 11
74962	Spring, 6,7	78960	Spring Cushion Keytop (P 0), 30	80401	Retarding Rod, 11
74964	Contact Spring, 18	78961	Spring Cushion Keytop (Q 1), 30	80402	Pulley, 11
74965	Spacer, 29	78962	Spring Cushion Keytop (R 4), 30	80403	Paper Carrier Belt, 11
74969	Bushing, 15	78963	Spring Cushion Keytop (T 5), 30	80405	Spring Bracket, 11
74972	Stud, 14	78964	Spring Cushion Keytop (U 7), 30	80407	Coil Spring, 11
74986	Screw (6-40 x 13/32), 4,11, 13,14,16,22,29	78965	Spring Cushion Keytop (V ;), 30	80412	Screw (4-40 x 15/32), 11
74987	Spring, 15	78966	Spring Cushion Keytop (W 2), 30	80413	Screw (6-40 Shoulder), 11
74988	Spring, 12	78967	Spring Cushion Keytop (X /), 30	80415	Baffle Plate, 11
74990	Insulator, 17	78968	Spring Cushion Keytop (Y 6), 30	80420	Pressure Roller Shaft, 11
74991	Insulator, 26,27	78969	Spring Cushion Keytop (Z "), 30	80421	Clamp, 11
74992	Bushing, 20	78970	Spring Cushion Keytop (Blank), 30	80422	Pressure Roller, 11
74994	Mounting Plate, 15,33	78971	Spring Cushion Keytop (Figs.), 30	80437	Sprocket Ring, 11
74995	Retainer, 15,33	78972	Spring Cushion Keytop (Ltrs.), 30	80439	Cover Paper Guide, 11
75229	Spring, 18	78973	Spring Cushion Keytop (Car. Ret.), 30	80444	Spacer, 11
75231	Bushing - Bakelite, 18,20	78974	Spring Cushion Keytop (Line Feed), 30	80446	Platen - Rubber - 8-1/2",
75400	Screw (6-40 x 1), 29	78975	Spring Cushion Keytop (S Bell), 30	80453	11
75436	Resistance (3000 Ohms), 18	78976	Spring Cushion Keytop (. .), 30	80459	Set of Gears, 27
75437	Test Key, 22	78977	Spring Cushion Keytop (Screw), 30	80460	Synchronous Motor Unit
75606	Spring, 23	78978	Spring Cushion Keytop (Blank), 30	80471	(Assem.), 27
75607	Washer, 23	78979	Spring Cushion Keytop (Margin Bell Hammer), 2	80478	Screw (6-40 x 1/4), 16,
75750	Washer - Bakelite, 18,22	78980	Spring Cushion Keytop (Margin Bell Shaft), 2	80479	28
76084	Washer - Felt, 9	79513	Plate, 9,20	80551	Cable Clamp, 17
76085	Friction Disc, 9	79523	Screw (2-56 x 25/32), 18	80510	Platen Crank (Assem.), 9
76086	Friction Spring, 9	80138	Spring Cushion Keytop (Margin Bell Pin), 1	80471	Clutch Spring, 23
76087	Nut (9/16-32 Special), 9	80255	Spring Cushion Keytop (Margin Bell Hammer), 2	80478	Spring Post, 10,11
76099	Washer, 17,24,25	80294	Spring Cushion Keytop (Margin Bell Pin), 1	80479	Collar, 11
76246	Bushing, 18	80299	Spring Cushion Keytop (Margin Bell Hammer), 2	80481	Paper Guide Post, 11
76284	Terminal Strap, 19	80303	Fan, 27	80483	Set of Parts to Convert
76295	Spring, 1				Friction Feed Printer
76296	Spring, 5				to Sprocket Feed, 11
76333	Bushing, 18				Paper Guide Post, 11
76461	Washer, 24				Screw (4-40 x 25/32), 29
76484	Fan, 27				Spring Post, 2
76699	Screw (10-32 Pivot), 16,17				Margin Bell Hammer, 2
77775	Copyholder - 6" - Walnut, 25				Margin Bell Shaft, 2
77911	Brush Holder Cap, 29				Cotter Pin, 1
77953	Motor - 1/25 H.P. - 110 V. - A.C. - 60 Cycle, 26				Spring Cushion Keytop (S '), 30
78011	Condenser - 1 MF. 20				End Shield (with Oiler),
78025	Screw (4-48 x 3/16), 26,27				27
78028	Screw {6-40 x 15/16}, 29				Clamping Stud, 27
78103	Screw (6-40 x 1-1/8), 29				Loading Plate, 11
78205	Resistor - 300 Ohms, 20				Screw (6-40 x 3/16
78206	Resistor Unit (Assem.) 150-300-600 Ohms, 20				Set), 11
78239	Armature, 26				Paper Rod Lever, 10
78240	Field Core, 26				Oiler, 27
78241	Field Coil, 26				Screw (10-32 x 1/2), 1,2
78287	Spacing Collar, 17				Platen - Steel Jacketed -
78301	Screw (10-32 x 5/8), 4				8-1/2", 11
78369	Plug, 19				Spring, 4
78398	Bushing, 28				Cover Arm, 24
78399	Outer Disc Brush Spring (with Brush), 28				Spring, 4
78400	Inner Disc Brush Spring (with Brush), 28				Spring, 10

NUMERICAL INDEX

81683	Rail - Left - Black Gloss, 24	82918	Bracket, 18	84901	Synchronous Motor Unit (Assem.), 27
81684	Strip - Black, 24	82919	Bearing, 18	84925	Set of Parts for Tabulator (Assem.) (Upper Case "G"), 16
81747	Insulator Block, 4	82920	Bushing, 18		
81825	Condenser, 29	82921	Break Lever, 18		
81841	Condenser, 18	82922	Adjusting Plate, 18	84927	Carriage Return Function Lever #2-B, 7,8
81889	Spring Bracket - End, 13	82923	Stop Lever, 18	84928	Line Feed Function Lever #12-A, 7,8
81893	Spring Bracket - Center, 14	82924	Plate, 18	86615	Rotor (Assem.) (with Bearings and Switch), 27
81895	Spring Post, 5	82925	Upper Contact Lever, 18	86616	Spring, 27
81936	Feed Lever, 14,33	82926	Contact Spring, 18	86617	Rotor (Assem.), 27
81956	Blocking Bail, 6	82927	Contact Spring, 18	86710	Oiler, 1,4
82012	Spring, 11	82929	Contact Spring, 18	86713	Screw (4-48 x 5/16), 27
82075	Spring, 4	82930	Contact Spring, 18	86732	Spring Cushion Keytop (TAB G), 16,30
82147	Type Bar Pallet (A↑), 7,30	82933	Sixth Vane Extension, 4	86758	Plate, 16
82148	Type Bar Pallet (D↔), 7,30	82934	Screw (4-40 Shoulder), 4	86759	Tabulator Bar, 16
82149	Type Bar Pallet (F→), 7,30	82935	Spring, 4	86760	Bearing, 16
82150	Type Bar Pallet (G↓), 7,30	82936	Letters Push Bar, 4	86761	Post, 16
82151	Type Bar Pallet (H↓), 7,30	82937	Screw (1/4-32 Pilot), 32	86762	Tabulator Stop, 16
82152	Type Bar Pallet (J↔), 7,30	82938	Spring, 13	86763	End-of-Line Tabulator Reset Stop, 16
82153	Type Bar Pallet (K↔), 7,30	83402	Name Plate (15-A), 26	86765	Nut (4-40 Special), 16
82154	Type Bar Pallet (L↔), 7,30	83403	Name Plate (15-B), 26	86766	Adapter Block, 16
82253	Platen - Steel Jacketed, 9	83405	Name Plate, 27	86768	Tabulator Latch, 16
82271	Function Lever #13, 8	83408	Screw (4-40 x 3/16), 26,27	86769	Function Lever #6, 8,16
82283	Synchronous Motor - 1/40 H.P. - 110 V. - A.C. - 60 Cycle, 27	83412	Locating Stud, 17	86770	Latch Bar, 16
82300	Motor Stop Locking (Assem.), 12	83413	Buffer, 17	86771	Bearing, 16
82322	Cover (Assem.) - Black Gloss, 24	83571	Eccentric, 12	86772	Latch Bar Extension, 16
82388	Cover Door (Assem.) - Right Side - Walnut, 25	83574	Paper Guide Plate - Black Gloss, 24	86773	Screw (6-40 Eccentric), 16
82389	Cover Door (Assem.) - Right Side - Black Gloss, 25	83718	Shift Vane #6 (Assem.), 4,6	86774	Link, 16
82399	Pad - Right Side, 24	83855	Set of Parts, 33	86776	Screw (6-40 Shoulder), 16
82400	Pad - Left Side, 24	83884	Screw (10-32 x 3/4), 1	86778	Post, 16
82401	Pad - Rear Lower, 24	83885	Nut (6-32 Hex.), 24,25	86779	Bell Crank Retainer, 16
82402	Pad - Rear Upper, 24	83920	Top Plate, 12	86777	Pawl, 16
82403	Pad - Front, 24	83976	Platen Crank, 9	86778	Screw (10-32 x 1-1/4), 20
82404	Spring, 24	83977	Spring Clip, 9	86779	Bushing, 28
82405	Spring, 24	84018	Pinion (7T), 27	86780	Post, 28
82406	Spring, 24	84019	Gear (25T), 27	86782	Spring, 6,7
82407	Spring, 24	84025	Type Bar Pallet (-), 7,30	86783	Set of Paper Guide Parts, 11
82408	Spring, 24	84042	Set of Gears, 27	86784	Motor Stop and Break Mechanism Plate (Assem.), 16
82409	Spring, 24	84047	Stop, 26	86785	Tabulator Bar (Assem.), 16
82410	Spring, 24	84060	Blank Printing Spacing Cut-out Lever 7-B, 7,8	86868	Tabulator Latch Bar (Assem.), 16
82411	Bracket, 24	84061	"Blank" Printing - Spacing Cut-out Lever (Assem.), 7	86869	Spacing Pawl (Assem.), 16
82412	Bracket, 24	84069	Type Bar Pallet (N⊕), 7,30	87154	Bell Crank Retainer (with Pawl), 16
82413	Cover Stop Arm, 24	84079	Pressure Roller Lever - Left, 87324	87325	Spring, 6
82414	Cover Detent Knob, 24	84081	Pressure Roller Lever - Right	87326	Spring, 6,8
82415	Cover Detent Spring, 24	84169	11	87327	Post, 4,32
82420	Type Bar Pallet (B⊕), 7,30	84351	Name Plate (15-E), 27	87328	Screw (2-56 x 3/16), 25
82421	Type Bar Pallet (V⊕), 7,30	84575	Type Bar Backstop, 13	87329	Bushing, 18
82423	Type Bar Pallet (C○), 7,30	84578	Spring, 9	87330	Set of Parts for Tabulator (Assem.) (Upper Case "Z"), 16
82425	Glass (11-19/32 x 6-1/4 x 1/8), 24	84734	Bearing Block, 5	87331	Bracket, 25,33
82440	Screw (6-40 x 7/16), 22,29	84735	Type Bar (with Pallets) #2, 30	87332	Bracket (with Rod), 25,33
82442	Spring, 2	84736	Type Bar (with Pallets) #3, 30	87333	Cover Front Plate (Assem.) - Black Gloss, 25
82463	Spring, 10	84737	Type Bar (with Pallets) #4, 30	87334	Cover Front Plate (Assem.) - Black Gloss, 25
82474	Terminal, 17,19,29	84738	Type Bar (with Pallets) #5, 30	87335	Screw (6-40 x 5/32), 6
82607	Spring Cushion Keytop (H Stop), 30,32	84739	Type Bar (with Pallets) #10, 30	87936	Stud, 1
82702	Screw (6-40 x 9/32), 29	84740	Type Bar (with Pallets) #11, 30	87937	Washer - Spring, 1
82714	Synchronous Motor - 1/40 H.P. - 110 V. - A.C. - 50 Cycle, 27	84742	Type Bar (with Pallets) #14, 30	87957	Lacing - Black, 24,25
82718	Shift Vane (with Extension), 4	84743	Type Bar (with Pallets) #17, 30	87963	Brush Holder Support (Assem.), 27
82728	Name Plate "On", 25	84745	Type Bar (with Pallets) #18, 30	87993	Bracket, 9
82729	Name Plate "Off", 25	84746	Type Bar (with Pallets) #20, 30	88856	Stud, 1,9
82733	Bearing Cap, 2	84747	Type Bar (with Pallets) #21, 30	88857	Operating Arm, 16
82740	Contact (Assem.), 9	84749	Type Bar (with Pallets) #22, 30	89077	Spacer, 27
82742	Motor Stop Mechanism (Upper Case H), 32	84750	Type Bar (with Pallets) #24, 30	89097	Washer, 27
82750	Set of Type Bar Pallets, 7	84752	Type Bar (with Pallets) #25, 30	89405	Cotter Pin, 27
82751	Type Bar Pallet (Z+), 7,30	84792	Function Lever #6, 8,16	89406	Spring Cushion Keytop (-), 7,30
82787	Spring, 6,8	84799	Spring Cushion Keytop (TAB Z), 16,30	89414	Spring Cushion Keytop (A⊕), 7,30
82788	Spring, 6,8	84894	Arm, 14,33	89415	Spring Cushion Keytop (D↔), 7,30
82839	Rotor (Assem.) (with Bearings and Switch), 27	84895	Detent Spring, 14,33	89416	Spring Cushion Keytop (F↔), 7,30
82840	Rotor (Assem.), 27	84896	Screw (10-32 Shoulder), 14, 33		
82841	Switch Commutator, 27				
82843	Spring, 27				
82845	Washer, 27				
82848	Brush Holder (with Brush), 27				
82850	End Shield (with Oiler), 27				
82865	Bracket, 18				
82917	Send - Receive Break Mechanism (Assem.), 18				

NUMERICAL INDEX

89417	Spring Cushion Keytop (G), 7,30	91600	Screw (6-40 x 31/32), 5	94015	Clutch Lever Bracket, 12,32
89418	Spring Cushion Keytop (H), 7,30	91617	Shim, 26	94094	Oil Hole Cover, 5
89419	Spring Cushion Keytop (J), 7,30	91657	Ribbon Lockout Lever (Assem.), 13,32	94693	Wick (5/16 Long), 4
89420	Spring Cushion Keytop (K), 7,30	91658	Extension, 13	94694	Button - Felt, 1
89421	Spring Cushion Keytop (L), 7,30	91659	Lockout Lever, 13	95050	Cord (Assem.) with Plug, 19
89422	Spring Cushion Keytop (Z+), 7,30	91683	Nut (15/32-32 Hex.), 19	95051	Cord, 19
89423	Spring Cushion Keytop (CO), 7,30	91739	Insulator, 22	95052	Cord (Assem.) with Plug, 19
89424	Spring Cushion Keytop (V①), 7,30	91740	Cord, 19	95053	Cord, 19
89425	Spring Cushion Keytop (B②), 7,30	91750	Cover Front Plate (Assem.) - Black Wrinkle, 25	95063	Plug - 3 Prong, 19
89426	Spring Cushion Keytop (N③), 7,30	91751	Copyholder - 6" - Black Wrinkle, 25	95064	Plug - 4 Prong, 19
89428	Line Cord (Assem.) with Plug - Black, 19	91752	Copyholder - 6" - (Assem.) - Black Wrinkle, 25	95935	Bushing, 29
89439	Plug, 19	91766	Cable Clamp, 21	95936	Retard Coil, 29
89472	Line Cord (Assem.) with Plug - Red, 19	91767	Cable Clamp, 21	95937	Condenser - .01 M.F., 29
89548	Contact Spring, 18	91837	Washer - Fibre, 26	95938	Condenser - .1 M.F., 29
89881	Wick - Felt, 3	92170	Bracket, 29		
89896	Oiler, 5,23	92216	Filter (Assem.), 29		
89897	Nut (10-32 Hex.), 5,23	92222	Transmitting Contact Filter (Assem.), 29	96158	Strap, 18
89917	Screw (4-40 Eccentric), 23	92227	Line Relay Radio Filter (Assem.), 29	96559	Pallet - P Ø, 30
89925	Terminal End, 20	92291	Condenser (1/10 M.F.), 29	97306	Lock Washer, 3
89969	Washer - Bakelite, 21	92309	Resistance (400 Ohms), 29	99250	Motor Filter (Assem.), 29
90101	Set of Spring Cushion Keytops, 7	92505	Shielding Tube, 29	99354	Container, 29
90103	Set of Parts, 7	92511	Roller, 23,33	99355	Washer, 29
90109	Fustat - 3.2 Amp., 19	92745	Paper Chute, 32	99356	Bracket, 29
90260	Spring, 23	92747	Bracket, 29	99357	Clip, 29
90263	Wound Stator (with Base), 27	92748	Screw (6-40 x 1-7/16), 29	99564	Keytop - P Ø, 30
90438	Felt Button, 23	92749	Wire, 29	99744	Resistor - 8000 Ohms, 18
90752	Lock Washer, 17	92750	Wire, 29	99745	Line and Selector Jack (Assem.), 18
90791	Lock Washer, 12	92814	Line Relay Cable, 17	99802	Clamp Plate, 18
91041	Wound Stator (with Base), 27	93075	Nut (15/32-32 Ring), 19	99803	Insulator, 18
91120	Spring, 22,23	93170	Cover Door (Assem.) - Right Side - Black Wrinkle, 25	99804	Insulator, 18
91175	Roller (Assem.), 4,32	93181	Line Test Key Door (Assem.) - Black Wrinkle, 25	99805	Plunger, 18
91222	Covering Strip - Black Wrinkle, 24	93183	Cover (Assem.) - Black Wrinkle, 24	99806	Bracket, 18
91223-	Paper Guide Plate - Black Wrinkle, 24	93754	Bail, 6	99807	Contact Spring Outer, 18
91280	Terminal, 19	93755	Roller, 6	99809	Contact Spring Inner, 18
91293	Cover Front Plate (Assem.) - Black Wrinkle, 25	93756	Housing, 6	99816	Relay Base, 18
91514	Rail - Left - Black Wrinkle, 24	93839	Bearing, 6	99817	Foot - Aluminum, 17
91515	Rail - Right - Black Wrinkle, 24	93882	Washer - Felt, 6	99818	Cord Guard, 17
91561	Line Test Key Door (Assem.) - Black Gloss, 24	93883	Function Lever Bail (Assem.), 6	99959	Cord Clamp, 17
91589	Fustat Adapter, 19	93884	Condenser Plate, 29	102100	Terminal, 19
		94001	Condenser (Assem.), 29	102985	Type Bar (with Pallet), 30
		94009	Transmitting Contacts Filter (Assem.), 29	103236	Plug - Black, 19
			Key Lever Guide - Rear, 22	103284	Fusetron - 3.2 Amp., 19
			Toggle Switch, 19	103285	Fusetron - 6.25 Amp., 19
				103286	Fusetron - 1.6 Amp., 19
				103287	Fusetron - 1.25 Amp., 19
				103288	Fusetron - 1.4 Amp., 19
				103289	Fusetron - .8 Amp., 19
				103290	Fusetron - .6 Amp., 19
				103536	Cord, 19
				103537	Cord, 19