

35 RECEIVING ONLY REPERFORATOR TABLE


ACTUAL WIRING DIAGRAM

CONTENTS	PAGE	2. ACTUAL WIRING DIAGRAM
1. GENERAL	1	2.01 Wiring diagram 5866WD covers the LT 300 (Bell 35A) 35 Receive Only Reperforator Table.
2. ACTUAL WIRING DIAGRAM	1	2.02 The actual wiring diagram presents a physical picture of each electrical component. The individual leads to each component are marked with their distant terminating points and wire color codes. The TF wiring field is part of the electrical service unit which is covered in another section.
1. GENERAL		
1.01 The electrical components installed on the 35 Receive Only Reperforator Table are illustrated in the attached actual wiring diagram.		


5866 WD

ISSUE	DATE	AUTH. NO.

NO.	NOTES
1	<p>WIRING LEGEND</p> <p>— DISTANT TERMINATING AREA — DISTANT TERMINAL DESIGNATION</p> <p>A-I-W-BL — WIRE COLOR CODE</p>
2	<p>COLOR CODE</p> <p>BK - BLACK W-BK WHITE BLACK</p>



TF WIRING FIELD (IN LESU-306)



APPROVALS	
D AND R	E OF M
<i>[Signature]</i>	<i>[Signature]</i>
E. NUMBER	
PROD. NO. 5866 WD	
ACTUAL WIRING DIAGRAM FOR LT-300	

DATE: 5-31-62
P.D. FILE NO.
DRAWN. GLZ. CHKD.
ENGD. J.A.C. APPD. <i>[Signature]</i>

TELETYPE CORPORATION

5866 WD