BELL SYSTEM PRACTICES
Teletypewriter and Data Stations

SECTION P34.532
Issue 2, November, 1963
AT&TCo Standard

28 MULTIMAGNET NONTYPING REPERFORATOR LUBRICATION

	CONTENTS PA	RAGRAPH
1.	GENERAL	1.01-1.04
2.	LUBRICATION	2.01-2.17
3.	ASSOCIATED BELL SYSTEM PRACTICES.	3.01

1. GENERAL

- 1.01 This section contains the specific lubrication procedures for the 28 multimagnet nontyping reperforator. The material herein, together with the section containing the general lubrication instructions on teletypewriter apparatus, provides the complete lubrication information for maintenance.
- 1.02 This section is reissued to revise various lubrication procedures in accordance with changes authorized for this apparatus by P98 series Bell System Practices listed at the end of the section and to include other authorized revisions and additions so as to bring the section generally up to date. Since this is a general revision, the marginal arrows ordinarily used to indicate changes have been omitted.
- 1.03 The lubrication symbols used herein are the same as those in the general section. However, the symbol **0** is used in this section to mean only one drop of oil. Symbols, such as 02, 03, or 04, are used to indicate respectively two, three, or four drops of oil.

P34.532 REPER-PORATOR


1.04 The apparatus should be lubricated before being placed in service as specified in the section covering the preparation of teletypewriter apparatus for installation. After a few weeks in service, it should be relubricated to make certain that all specified points have lubricant. Thereafter, because of varying conditions at each station, the apparatus should be lubricated as often as specified by local instructions. The following lubrication interval is suggested as a guide for use under operating conditions.

Operating Speed (Words per Minute)	Lubrication Interval (Whichever Occurs First)	
60	3000 hours or 1 year	
7 5	2400 hours or 9 months	
100	1500 hours or 6 months	

2. LUBRICATION

2.01 Multimagnet Nontyping Reperforator - Front View


Note: Ball bearings with one shield or both shields removed shall be lubricated by applying two drops of oil directly into each ball bearing.




28 MULTIMAGNET

P34.532 N

2.02 Multimagnet Code Selector Mechanism—See 2.01 Multimagnet Code Selector Mechanism



2.03 Feed Wheel Mechanism-See 2.01



EARING SURFACE	FEED WHEEL KNO
IVOT	DETENT ROLLER
PIVOT	DETENT LEVER

RATCHET TEETH **FEED WHEEL**

FELT WASHER FEED WHEEL

FELT WASHER DIE WHEEL

FELT WICKS (2) SPRING WICKS

HOOKS-EACH END SPRING (2 SPRINGS)


FELT WASHER FEED PAWL 28 MULTIMAGNET
NONTYPING
32 REPERFORATOR

2.04 Tape Shoe Arm Mechanism—See 2.01

TAPE SHOE

TAPE SHOE ARM


2.05 Magnet Release Contact Bail Assembly—See 2.01



28 MULTIMAGNET NONTYPING NONTYPING REPER-

AUXILIARY CONTACTS


2.07 Punch Slide Mechanism—See 2.01



28 MULTIMAGNET NONTYPING 32 REPER-

P34.532


2.08 Multimagnet Nontyping Reperforator-Left-side View



PUNCH MECHANISM

1 486 10


2.09 Rocker Arm Mechanism—See 2.08




28 MULTIMAGNET NONTYPING

P34.532 NONTYPI

2.10 Punch Mechanism—See 2.08




2.11 Multimagnet Nontyping Reperforator-Right-side View



28 MULTIMAGNET NONTYPING


P34.532 RIP

2.12 Rocker Bail Mechanism-See 2.11




Perforator Clutch Mechanism—See 2.11


2.13



P34.532 REPER-Page 15 FORATOR


2.14 Main Shaft Assembly-See 2.11





28 MULTIMAGNET
NONTYPING
P34.532 REPER-


2.16 Function Magnet Mechanism—See 2.15



2.15 Multituespel Nemyolog Reperiorator Top View

CENTRAL SECTION OF THE SECTION OF TH

2.17 Function Mechanism—See 2.15



28 MULTIMAGNET NONTYPING 32 REPER.

034,532 ^{NO}

3. ASSOCIATED BELL SYSTEM PRACTICES

3.01 The following Bell System Practices provide additional information that may be required in connection with this section.

Subject	Section
Alphabetical Index of 28-type Equipment, Bell System Practices, and Associated 28 ASR Station Drawings	P34.001
28 Multimagnet Nontyping Reperforator, Disassembly and Reassembly Routines(When	P34.432 Issued)

CHANGES AUTHORIZED BY P98 SERIES BELL SYSTEM PRACTICES

PAR. NO.	Mechanism	Authorized by Section
2.01	Ball Bearing	P98.999.174
2.02	Multimagnet Code Selector	P98.978